
## SO SIMPLE IT JUST WORKS

- · USE EXTERNAL POWER SOURCE TO POWER SERVO'S.
- · RATED FOR 8.4V AND 10 AMPS.
- · STANDARD SERVO CABLE SPACING.
- . #4 MOUNTING HOLES.
- · NO MORE SPLICING!

## SERVO POWER ADAPTER



AVAILABLE SOON, ONLY AT:

## FASTROBOTICS

MAKE ROBOTS FASTER