nav_msgs/OccupancyGrid Message

File: nav_msgs/OccupancyGrid.msg

Raw Message Definition

```
# This represents a 2-
D grid map, in which each cell represents the probability of
# occupancy.

Header header

#MetaData for the map
MapMetaData info

# The map data, in row-
major order, starting with (0,0). Occupancy
# probabilities are in the range [0,100]. Unknown is -1.
int8[] data
```

Compact Message Definition

std_msgs/Header header nav_msgs/MapMetaData info int8[] data

autogenerated on Wed, 02 Mar 2022 00:06:54