AquaPearl Series Installation Guide

Step-by-Step Commissioning for Wall-Mount and Under-Sink Configurations

1. Pre-Installation Site Checklist

Before opening the plumbing lines, verify that the installation location satisfies the following requirements:

- Water Inlet Pressure: Must measure between 15 PSI and 45 PSI (1.0 bar to 3.1 bar). If line pressure is below 15 PSI, install an auxiliary feed booster. If above 45 PSI, install an inline pressure-reducing valve (PRV).
- Electrical Power: A grounded 220V-240V 50Hz 3-pin wall outlet located within 1.2 meters of the unit.
- Physical Clearance: Maintain at least 10 cm of clearance on both sides and rear for heat dissipation from the booster pump enclosure.
- Cold Water Supply: Connect ONLY to municipal cold water supply. Never connect to solar geyser or hot water lines.

2. Required Tools and Wall-Mounting Steps

Tools Required:

- Electric impact drill with 8mm masonry drill bit
- Adjustable plumber wrench and 14mm open-end spanner
- Sharp utility tubing cutter (cut tubing square at 90 degrees; do NOT use scissors)
- Teflon PTFE thread seal tape
- Calibrated handheld TDS meter

Step-by-Step Wall Mounting:

1. Tape the included cardboard mounting template onto the wall at a minimum height of 45 cm above countertop level.
2. Drill two 8mm holes at marked centers, insert nylon wall anchors, and fasten masonry screws leaving 4mm proud.
3. Hang the purifier chassis onto the screw heads and verify horizontal alignment using a spirit level.

3. Under-Sink Installation and Plumbing Connections

1. Feed Water Connection: Shut the cold water angle stop under the sink. Install the 1/2 to 3/8 brass feed diverter valve with Teflon tape. Connect 3/8 white PE tubing from diverter to Pre-Filter IN port.

2. Drain Saddle Installation: Drill a 1/4 hole on the vertical section of the sink drain pipe ABOVE the P-trap. Mount the drain saddle clamp, aligning clamp hole with drilled hole. Insert 1/4 red waste tubing.

3. Faucet Mounting: Drill a 12mm hole on countertop or stainless sink rim. Fasten chrome dispensing faucet using brass locknut and rubber gasket. Connect 1/4 pure water tubing.

4. Mandatory First-Run Flushing Procedure (CRITICAL)

Why First-Run Flushing is Required:

Newly manufactured filter cartridges contain trapped micro-bubbles and natural loose food-grade carbon dust particles generated during transport vibration. Consuming water without completing this flushing procedure will result in a strange, chalky, or slightly bitter mineral taste.

Flushing Procedure Instructions:

1. Open the cold feed water valve and switch on electrical power.
2. Allow the internal storage tank to fill completely until the booster pump automatically shuts off (approx. 40 minutes).
3. Open the dispensing tap fully and completely drain the entire storage tank (approx. 9.5 liters). Discard this water (or use for household cleaning/plants).
4. Allow the tank to fill a second time and drain completely once more. Total flushed water must reach 15 to 20 liters.
5. After this two-cycle flush, close dispensing faucet. The purifier is now fully conditioned, and purified water will taste crisp, sweet, and pure.

5. Professional Installation Booking and Service Pricing

Pearlz Home Systems provides certified on-site professional installation across metro regions:

- Standard Installation Booking Fee: PKR 1,500 (covers wall mount, tap connection, drain saddle setup, TDS calibration).
- Booking Process: Schedule via Pearlz Mobile App, WhatsApp Desk (+92-42-111-PEARLZ), or email install@pearlzhome.example.
- Additional Plumbing Accessories: Non-standard drilling in granite countertops (PKR 800); extra tubing beyond included lengths (PKR 80/meter).

6. What Voids the Warranty During Self-Installation

Customers may perform self-installation, but the following actions will VOID the manufacturer warranty:

1. Drilling holes into or modifying the purifier casing, chassis, or internal electronic compartment.
2. Utilizing non-standard, low-grade third-party brass fittings or non-certified plastic tubing.
3. Operating the machine without an inline pressure-reducing valve when inlet water pressure exceeds 45 PSI.
4. Connecting the unit to an ungrounded or fluctuating electrical outlet lacking surge protection.
5. Improperly seating the quick-connect collets causing water leakages that flood surrounding kitchen cabinets (excluded from warranty under Section 3.2).