



Don't need buttons for JTAG programming...
Just tie RESET AND BOOT to 3V and GND respectively



Schematic	Schematic2_1			Update Date	2026-01-23
Create Date	2025-09-28			Part Number	
Page	buttons				
Drawn					
Reviewed				piques	
		VER	SIZE	PAGE	2 OF 3
		V1.0	A4	EasyEDA.com	



Schematic	Schematic2_1			Update Date	2026-01-23
Page	core			Create Date	2025-09-28
Drawn				Part Number	
Reviewed				piques	
	VER	SIZE	PAGE	3	OF
	V1.0	A4		3	3
			EasyEDA.com		