## (1.) Specification

- 1. Mono Line-out
- 2. Speaker size: 40mm
- 3. output voltage:3W (audio power)
- 4. Working frequency:100Hz-18KHz (audio)
- 5. sensitivity:60db+2db
- 6. signal to noise ratio:≥80dB
- 7. Blue tooth standard: 2.1+EDR
- 8. USB Charge
- 9. Battery type:3.7V 500mAh rechargeable lithium battery
- 10. Speaker dimension:50mm×50mm×51mm
- 11. Weight:97g
- 12. Working time:70-90mins13.Wrok distance: 10meters14.Charging time: 1-1.5hours

## (2). Accessories

- 1. Bluetooth Speaker 1pcs
- 2. USB cable 1pc
- 3. 3.5 mm Audio cable 1pc
- 4. Manual book 1pc

# (3).Manual

- 1.Turn on the speaker, switch the button to ON, Charging the position the blue light is lit up, and then hear ~ "guru" prompt, blue lights flashing at the same time
- 2.Open the cell phone or ipad Bluetooth function, search for the Bluetooth device, choose the GUESS to connect, when connect successfully u will hear Beep sound, then u can play music.
- 3.Audio cable connect to play music:switch the button to ON, Charging the position the blue light is lit up, and then hear ~ "guru" prompt, blue lights flashing at the same time.Use the Audio cable plug into the AUX location on the speaker,the speaker will say ""out input model" then connect your mobile phone or MP3 can play music.
- 4. When playing music if there are any "beep" sound, means the battery does not have enough power, need to charge the speaker.

## (4)Common problem solving methods

#### <1>Can not connect the blue tooth speaker successfully

- 1. Check whether turn on the speaker, and whether open the mobile phone Blue tooth function. Or u need to restart the speaker.
- 2. There are too many Blue tooth devices, difficult to search the Bluetooth device. Closed the others Bluetooth device.

#### <2> The voice is too small or distortion

- 1. Check the Bluetooth device volume, adjust the volume.
- 2.Use the mobile phone research the Bluetooth device.
- 3. The battery have no enough power ,plz recharge.

#### <3>The voice is off and on can not be consecutive

1. Check whether the distance is too far or speaker and BT device have obstacles

#### <4>The bluetooth indicator light is not lit up

- 1. The battery power not enough
- 2.restart the speaker

### **Federal Communications Commission (FCC) Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **ORIGINAL SOUNDTRACK TECHNOLOGY (SHENZHEN) LIMITED** may void the FCC authorization to operate this device.

**Note:** The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.