


Getting started with MS-125 mini speaker Mobile Bluetooth speaker



Model: MS-125







USING THE MS-125

Thanks you for purchasing the MS-125 mini speaker This unit is designed to provide years of trouble-free audio performance.

Please read these instructions carefully for proper operation and save for future reference.

RECHARGEABLE LITHIUM-ION BATTERY

This device uses an internal rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead, try charging it several times. If the battery does not recharge, please contact us for repair information. Please do NOT attempt to change the battery yourself. If the battery has died and you do not want us to replace your battery, you should follow the disposal instructions below.

RECHARGEABLE LITHIUM - ION BATTERY

WARNING/DISPOSAL OF UNIT

 Never dispose of used batteries/electronics with ordinary solid wastes, since they contain toxic substances.

MAINTENACE

This product bears the selective sorting symbol for waste electrical and electronic equipment (WEEE).

This means that this product must be handled pursuant to European Directive 2002/96/EC in order to be recycled or dismantled to minimize its impact on the environment. For further information, please contact your local or regional authorities.

Electronic products not included in the selected sorting process are potentially dangerous for the environment and human health due to the presence of hazardous substances.





OPERATION

Connecting with Bluetooth

To play audio from a Bluetooth device, you need to pair the device with the speaker.
You can pair up to eight devices.

- On your Bluetooth device, switch on Bluetooth and scan for devices in its Bluetooth menu.
- 2. Turn on the speaker. When powering up for the first time, the speaker is in discover mode for 2 minutes and then is ready for pairing. The status indicator flashes blue.
- 3. When "MS-125" appears on the device list of your Bluetooth device, select it to initiate pairing. (If a pass code is requested, enter 0000). The Bluetooth status light turns solid blue after pairing is established. The speaker is ready to play music.

RECHARGEABLE LITHIUM - ION BATTERY

- * Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/ electronics disposal, please dispose of the device in a waste bin for electronic devices.
- Many electronics retailers now recycle batteries and other electronic components at no charge. Check to see which ones in your area do so.

Caution: The battery used in this device may present a risk of fire, explosion or chemical burn if mistreated.

- * Unit shall not be exposed to excessive heat such as sunshine, fire, or the like.
- * Do not use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

CHARGING THE MS-125

The MS-125 is powered by a rechargeable battery inside the speaker. When the blue power light dims, or if you start to notice sound distortion at higher volume, it's time to recharge the battery. Connect the mini USB plug to the speaker and larger USB plug to a powered USB port, such as that a computer, or the optional AC adapter.

The light on the speaker will turn red whilst charging and blue when fully charged.

Note:

- You can continue to listen to the speaker while it is charging.
- If the battery level is too low, the Bluetooth connection may not operate correctly.

RECHARGEABLE LITHIUM -ION BATTERY

* Do not leave your battery discharged or unused for extended periods of time. When batteries are misused, they may explode or leak, causing burns and personal injury. If your battery leaks, use normal precaution and discard the unit immediately.

MAINTENACE

- Place the unit on a level surface away from sources of direct or excessive heat.
- Protect your furniture when placing your unit on a natural wood or lacquered surface. A cloth or other protective material should be placed between the unit and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water.
- Stronger cleaning agents, such as benzene, thinner or similar materials can damage the surface of the unit.

FCC STATEMENT:

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.