


ZeBuds

- QUICK START GUIDE -





USB-C CHARGING CABLE

CHARGING

Before the first time use, make sure to fully charge **ZeBuds** inside their charging box with the USB-C cable for about 2 hours.

ZeBuds and its charging case will reach maximum battery capacity in order to provide you with up to 12 hours playtime.


ZeBuds can deliver about 3 hours of battery life. When reaching low battery level, you will hear an audio indication in your earbuds inviting you to put them back in the charging case to recharge them.

It will take about 90 minutes to fully charge your earbuds in the charging case. Once the charging case is fully charged, you can recharge your earbuds up to 3 times until it reaches low battery.



LED INFORMATION

- There are 3 LED indicators in the charging case to indicate its built-in battery level.
- 3 LEDs ON = between 75% and 100%
- 1 LED ON = below 25% and requires your attention
- LED ON = below 25% and requires your attentio



In order to pair your **ZeBuds** with your smartphone, please follow the below instructions: Open the charging case and take out both earbuds. The white LED on the left earbud

will start flashing slowly to indicate it is in pairing mode

• Go to the Bluetooth' settings of your smartphone and search "ZeBuds"

Select "ZeBuds" in the list to initiate pairing
 Once pairing is confirmed, white LED on both earbuds will stay solid state for two seconds then turn Off
 Your left and right earbuds will connect to each other automatically thanks to the TWS

technology in order to provide you with Wireless Stereo audio signal

*You're now ready to enjoy your new **ZeBuds**Note: You can independently use your left or right earbud by storing the one you don't want to use back in the charcing case. The Bluetooth' pairing mode will automatically

want to use back in the charging case. The blueboah paining mode win automatically stop after 5 minutes of searching for device. To resume the pairing mode, please put both earbuds back in the charging case for a few seconds then take them out again.

HOW TO PAIR WITH ANOTHER SMARTPHONE

PAIRING

To pair your **ZeBuds** with another phone, please first forget **ZeBuds** from your smartphone's Bluetooth' list, then perform a new pairing procedure with another smartphone.

or Enameric		LEFT		RIGHT	
		Lange of the same		ga	
	Play / Pause	x2			
	Next track			x2	
	Volume control	Down x1		Up x1	
	Voice control	х3	or	х3	
	Answer call	x2	or	x2	

Press & hold

for 3 seconds

x2

or'

Press & hold

for 3 seconds

x2

use either earbud to conduct these operations

OPERATIONS

Reject call

End call

TECH SPECS EARBUDS:

Compatible with iOS and Android devices. 1 year international warranty.

CHARGING CASE: Dimensions: 46.5*58*22.3 mm - Weight: 40 g - Battery type: 400 mAh - Battery life: 9h of extra playtime - Charging time: 1h30 for full charge - USB-C charging port

Bluetooth® 5.0 - Dimensions: 17.8*43*19 mm - Weight: 5 g each - Battery type: 40 mAh Battery life; up to 3h of playtime - Charging time; 20 min for 1h listening / 1h30 full charge Dual microphone - Speaker impedance: 32Ω - Frequency: 20Hz/20KHz - IPX4 water

resistant - Operating temperature: -10°C to +60°C - DC 5 V 500 mA

WHAT'S IN THE BOX

1x USB-C charging cable 1x Quick start quide

ZeBuds with charging case

VUE D'ENSEMBLE






CHARGER

Avant d'utiliser vos écouteurs **ZeBuds** pour la première fois, veuillez les charger à pleine capacité dans leur boitler de charge pendant environ 2 heures en utilisant le câbile de charge USB-C fourni. Une fois la pleine charge atteinte, vos écouteurs **ZeBuds** et leur boitler de charge vous donneront jusqu'à 12 heures d'écoute musicale cumulées.


Les écouteurs **ZeBuds** peuvent offrir jusqu'à 3 heures d'autonomie. Une fois le niveau minimum atteint, usignal sonore sera émis dans les écouteurs afin de vous inviter à les recharger dans leur boîtier de charge.

Il faut environ 90 minutes pour recharger pleinement les écouteurs dans leur boitier de charge. À pleine charge, le boîtier offre 3 charges complètes de vos écouteurs avant d'atteindre son niveau minimum de batterie.



INDICATEURS LUMINEUX

- Le boîtier de charge est équipé de trois LED pour vous indiquer son niveau de charge.
- 3 LED allumées = Niveau de batterie entre 75% et 100%
- 1 LED allumée = Niveau de hatterie inférieur à 25% nécessitant votre attention
- I ED éteinte = 0% de hatterie



IUMFI AGE ci-decenne :

Afin de connecter vos écouteurs avec votre smartphone, merci de suivre les instructions

 Ouvrir le boîtier de charge et en extraire les deux écouteurs. La LED blanche sur l'écouteur gauche clignote, vous indiquant la disponibilité pour le jumelage. Aller dans les réglages Bluetooth" de votre smartphone et cherche l'appareil "ZeBuds". Sélectionnez "ZeBuds" dans la liste pour initier le jumelage.

 Une fois la connexion établie, les LED sur les deux écouteurs s'allumeront pendant quelques secondes puis s'éteindront. Vos écouteurs gauche et droit se connectent entre eux automatiguement grâce à la

technologie TWS de facon à yous fournir un signal stéréo de grande qualité. Vous être maintenant prêt pour profiter pleinement de vos écouteurs sans fil ZeBuds. Note: Vous pouvez utiliser indépendamment votre écouteur gauche ou droit en laissant

dans le boîtier de charge celui que vous n'utilisez pas. Le mode jumelage de vos écouteurs s'arrêtera automatiquement après 5 minutes de recherche si aucun smartphone n'est connecté. Afin de relancer le mode jumelage, vous devez replacer vos écouteurs dans le boitier pendant quelques secondes puis les sortir de nouveau.

COMMENT JUMELER AVEC UN AUTRE SMARTPHONE

Pour jumeler vos écouteurs avec un nouveau smartphone, veuillez dans un premier temps les oublier de la liste de périphériques Bluetooth" de votre smartphone existant afin de refaire la procédure de jumelage depuis le début.

	GAUCHE		DROITE
	Jan		Sa
Lecture / Pause	x2		
Chanson suivante			x2
Contrôle du volume	Baisser x1		Augmenter x1
Commande vocale	х3	ou'	х3
Répondre à un appel	x2	ou'	x2
Refuser à un appel	Appui long pendant 3 secondes	ou'	Appui long pendant 3 secondes
Terminer à un appel	x2	ou'	x2

CALICHE

DROITE

OPÉRATIONS

'utilisez l'un ou l'autre des écouteurs pour ces opérations

I ÉCOUTEURS : Bluetooth* 5.0 - Dimensions : 17.8*43*19 mm - Poids : 5 g chacun - Type de batterie : 40 mAh Autonomie : jusqu'à 3h d'écoute - Temps de charge : 20 min pour 1h d'écoute / 1h30 pour une charge complète - Double microphone - Impédance des enceintes : 32Ω

Fréquence : 20Hz/20KHz - Résistance à l'eau IPX4 - Température de fonctionnement : -10°C to +60°C - DC 5 V 500 mA | BOÎTIER : Dimensions : 46.5°58°22.3 mm - Poids : 40.0 - Tupe de batterie : 40.0 mAh - Autonomie : 9h d'écoute

supplémentaire - Temps de charge : 1h30 pour une charge complète - Port de charge USB-C Compatible avec les appareils iOS et Android.

Garantie internationale d'un an

DANS LA BOÎTE ZeBuds et boîtier de charge

SPEC TECH

1x Câble de charge USB-C

1x Guide de démarrage



Scan & Get





Scannez pour obtenir plus d'informations Escanear para mas informaciones Scansiona per maggiori informazioni Scannen Sie für weitere Informationen Scanner voor meer informatie Escanea para mais informações Zeskanui, aby uzyská viecei informaci,

> дополнительной информации 扫描获取更多信息 掃描獲取更多信息 詳細については、スキャン สแกนทาข้อมูลเพิ่มเติม 자세하 내용은 스캐너

Считайте QR-код для получения

Or visit www.mykronoz.com/support

- SAFETY & REGULATORY NOTICES -

SAFETY INSTRUCTIONS

product or injury to you.

To prevent possible hearing damage, do not listen at high volume levels for long periods of time.



- Use of earbuds will prevent your ability to hear other sounds.
- Use your earbuds with caution when engaging in any activity that requires your full attention.
 This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a tow never allow children to lake with this product.
- Never try to dismantle the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Please contact customer service for any assistance.
- tor any assistance.

 Avoid exposing your product to rain, moisture or other liquids to protect against damage to the

 Do NOT expose the earbuds to moving water (e.g., from a faucet, etc.). Do NOT wear the earbuds while showering or bathing, or when participating in water sports, e.g.,

Do NOT submerge the earburds in water.

- swimming, waterskiing, surfing, etc. Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the earbuds.
- Read all the instructions before using the charging case. Do not expose charging case to water, rain, liquids or snow.
- Use of a power supply or charger that is not recommended may result in a risk of fire or injury.
- Do not use the charging case in excess of its output range. Risk of explosive if battery is replaced by an incorrect type. Dispose of used batteries

according to the instructions

INFORMATIONS DE SÉCURITÉ

 Pour éviter tout dommage auditif, n'écoutez pas à un volume élevé pendant de longues périodes.



- L'utilisation d'écouteurs vous isole des bruits ambiants. Merci de ne pas les utiliser lors d'activités requérant toute votre attention à l'environnement.
- Cette boite contient de petites pièces qui pourraient s'avérer dangereuses pour de jeunes enfants. Ce produit n'est pas un jouet, merci de ne pas le mettre entre les mains d'enfants en bas âge. Ne jamais essayer de réparer ou démonter vous-même ce produit afin de prévenir tout risque de
- blessure ou de choc électrique. Aucuns des composants de ce produit ne peuvent être réparé ou remplacé sans avoir contacté au
- préalable notre service client.
- · Ne pas exposer le produit à la pluie, une forte humidité, ou tout autre liquide afin d'éviter

d'endommager ce dernier de facon irréversible ou de vous blesser.

 Ne pas utiliser les écouteurs sous l'eau ou lors d'activités aquatiques comme la baignade, la nage. les sports nautiques y compris lors d'une douche. · Laisser le produit exposé à de très chaudes ou très froides températures réduira de facon significative la performance de sa batterie interne.

Ne pas immerger les écouteurs

de feu ou de blessures

 L'utilisation d'un chargeur non certifié n'est pas recommandée et pourrait occasionner des risques Merci de prendre connaissance de toutes les instructions de sécurité avant d'utiliser votre produit.

REGULATORY NOTICES

USA FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (i) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTIONS

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment operantes, uses and can radiate radio frequency energy and, if not installed and used in

- accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

 Reviert or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.
 FCC ID: 2AA7D-ZEBDS

RF EXPOSURE STATEMENTS This equipment complies with FCC radiation exposure requirement set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure

CANADA ISED STATEMENT

compliance.

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undestred operation of the device.

This Class B digital apparatus complies with Canadian ICES-0003.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation set autorisée aux deux conditions suivantes : (I) l'appareil ne dois produire de prouillace act (2) l'utilisateur de l'appareil doit accepter tout brouillace radioélectrique

subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF EXPOSURE STATEMENTS

This device complies with the ISED RSS-102 RF exposure requirement set forth for an uncontrolled environment and are safe for intended operation as described in this manual.

Cet appareil est conforme aux exigences d'exposition RF de l'ISED RSS-102 définies pour un environnement non contrôlé et est sûr pour le fonctionnement prévu comme décrit dans ce manuel.

CE DIRECTIVE

KRONOZ LLC, hereby declares that the device is in compliance with the essential requirements and

other relevant provisions of directives 2014/53/EU and 2012/19/EU. The original EU declaration of conformity may be found at https://www.mykronoz.com/assets/certifications-ce-zebuds.pdf KRONOZ I I C déclare que cet appareil est conforme aux exigences essentielles et aux autres dispositions perfinentes de la directive RE Directives 2014/53/EU et 2012/19/EU. La déclaration de conformité complète est disponible sur ; https://www.mvkronoz.com/assets/certifications-ce-zebuds.pdf

DISPOSAL AND RECYCLING INFORMATION



After the implementation of the European Directive 2012/19/EU in the national legal system, the following applies; electrical and electronic devices may not be disposed of with domestic waste. Consumers are oblided by law to return electrical and electronic device at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.

©2019 Kronoz LLC, all rights reserved, Kronoz LLC, Avenue Louis-Casaï 18, 1209 Geneva, Switzerland All brands or product names are or may be trademarks of their respective owners. Pictures and specifications are not contractual. Les marques citées sont des marques déposées par leur fabricant respectif. Photos et caractéristiques non contractuelles. Designed in Switzerland - Assembled in China



JOIN US @MYKRONOZ









© 2019 KRONOZ LLC. All rights reserved.