

SnapTo Wireless Charger

User Manual

Model: 99MO122011

•	Package Contents		
	0	1 x SnapTo Wireless Charger	
	0	1 x Wall Mount Kit	
	0	1 x USB-C to USB-A Cable	
	0	2 x SnapTo Tabs	
	0	1 x Quick start guide	
•	Install the SnapTo tabs		
	0	Remove the plastic placeholder tabs from your Moshi case.	
	0	Peel the adhesive liner from the SnapTo metal tab.	
	0	Place the tab into your case and press firmly for 30 seconds.	
	0	Repeat for the 2nd tab.	
•	How to	How to charge wirelessly with SnapTo Wireless Charger	
	0	Plug the included USB-C to USB-A cable into the SnapTo Wireless Charger, the	
		n connect it to any USB Type-A wall charger (not included). A USB-C to USB-C	
		Cable and charger (such as Moshi's Rewind C) also works.	
	0	Charging automatically begins after attaching your phone (installed in a Moshi S	
		napTo case) to the SnapTo Wireless Charger.	
	0	For optimal performance, use a high-output wall charger over 5 W (12 W recom	
		mended) for better charging efficiency.	
	How to install the wall mount kit		
	0	Make sure the mounting surface is clean and dry.	
	0	Peel off the adhesive liner from the wall mount kit.	
	0	Firmly press the wall mount kit onto the clean and dry mounting surface for 30 s	
		econds.	
	0	After 24 hours has passed, insert the SnapTo Wireless Charger into the wall mou	
		nt kit.	

O Plug the supplied USB-C to USB-A cable into SnapTo Wireless Charger, then co

and charger also works.

nnect to any USB Type-A wall charger (not included). A USB-C to USB-C Cable

O Charging automatically begins after attaching your phone (installed in a Moshi S napTo case) to the SnapTo Wireless Charger.

How to remove the wall mount kit

O Pull the white adhesive strip down (not towards you) and pull slowly to release the wall mount kit. The adhesive strip may stretch up to 12 in (30 cm) before the mount releases from the wall.

LED behavior

O Pull the white adhesive strip down (not towards you) and pull slowly to release the wall mount kit. The adhesive strip may stretch up to 12 in (30 cm) before the mount releases from the wall.

Foreign Object Detection Troubleshooting

- Remove any metal objects like coins or keys between your device and SnapTo W ireless Charger.
- Unplug the power adapter from SnapTo Wireless Charger then plug it in again.
- O If the problem still exists, please contact support@moshi.com.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

<u>FCC Caution</u>: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example – use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IC

This device complies with Industry Canada licence–exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.