#### **Operating Procedures**

Step 1. Batteries

Properly insert one AAA battery into the pen.

## Step2. Power on

Hold down the power button for three seconds. When the green power light illuminates, the device is on.

#### *Step3.* Mode

There are two modes: IRS and MOD. The mode is changed each time the mode button is pressed. The pen is automatically set to IRS when the pen is turned on.


# **Step4.** Setting

Use the setting card to do ID setting. The pen will emit a beeping sound after the new settings have been made.

#### **Step5.** Power off

Hold down the power button for three seconds. When the power light goes off, the device has shut down.

#### Feature Explanation



- Optical Sensor Tip: The pen contains a high-quality optical sensor tip. Do not strike or touch the pen tip
- Indicator Light: LED light indicates the mode and battery level

IRS Mode Red light MOD Mode Green light

3 Mode button: One mode button for both settings

Interactive Response System. This feature is used with Live Interactive Web School

MOD On-Demand mode selection: This feature is used with LiveABC certain book series

## **Product Specifications**

Dimensions	14cm×2.5cm×2.5cm
Weight	24 kg (batteries excluded)
Power Source	1 AAA battery
Energy Saving Function	Automatically shuts off after approx. (60 minutes)
Usage Time	30-40 hours (based on average usage)
Power Indicator	LED light
Button	Mode button
Frequency	2407~2475MHz

#### **Accessories**

Wireless connection dongle, setting card (sold separately)



**Note:** The IRS Interactive Response System requires a wireless connection DONGLE and setting card



#### Strap Connector Loop: Connects to a neck or wrist strap for added convenience

# **Operating Procedures**

#### **Batteries**

- 1. Please use rechargeable or alkaline batteries for best performance.
- 2. To prevent leakage, remove batteries when the device will be out of use for an extended period of time.
- 3. Batteries should be changed by an adult or under the supervision of an adult to prevent harm to children.

- 1. For best performance, hold the pen tip against the book cover or page at a 70 degree angle.
- 2. Sensor points are located on the covers and pages of books in the LivePen series. Do not scratch, stain or mark these areas.

#### Storage

- 1. Properly store the device when not in use to prevent accidental damage.
- 2. Do not place the pen in hot or damp areas or allow liquids to come into contact with the pen tip.
- The optical pen tip contains high-tech precision components. Do not place objects inside the pen tip or puncture the tip with sharp objects.
- 4. LED Light Indicator Table:

	Normal Battery Lev	vel Low Battery Lev
IRS	Green light	Slow flashing green light
MOD	Red light	Slow flashing red light

# LIVE PEN IRS Product Warranty

■ Product name:	IIVÊ P	ŜN ∏RS	Smart Pen

Product name: LIVE PEN LLING Smart Pen					
■ Serial Number:	Date of Purchase:				

- I. This warranty provides free maintenance for the period of one year from the date of purchase. If damage results from improper usage or occurs after the warranty expires, a maintenance fee will be charged even if no components are replaced.
- II. The warranty does not cover the following types of damage:
  - 1. Damage caused by drops, water, corrosion, or foreign objects entering the device or any use of the device which results in damage to any part of the pen.
  - 2. Damage to internal components caused by faulty batteries.
  - 3. Damage due to failure to follow instructions, negligence, misuse, malicious files or inappropriate testing.
  - 4. Damage caused by opening or repairing the product without official authorization and also damage caused by using the device for purposes beyond the scope of its
  - Damage caused by natural disasters or other unavoidable catastrophe.
  - Damage caused by improper packaging when the device is mailed in for repairs.
  - 7. Expendable components and accessories (including batteries) are not covered
- III. This warranty document requires the LiveABC company seal or that of the retailer to become effective. This warranty document cannot be replaced if lost.
- IV. To ensure the best possible customer service, please do not remove the internal serial number sticker.

IRS Pen Customer Service Contact Information

Hebron Soft Ltd. (02)2578-7838

E-COM Technology corp. (02)2392-3812



Model: EC30616

This device compiles with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause hamful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

MPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

#### FCC INFORMATION

The Federal Communication Commission Radio Frequency Interference Statement includes the following

paragraphs:
The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no grantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on , the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

  Increase the separation between the equipment and receiver.

  Increase the separation between the equipment and receiver.

  Increase the separation between the equipment and receiver.

  Increase the separation that to which the receiver is connected.

  Consult the dealer or an experienced radio/TV technician for help.
- The user should not modify or change this equipment without written approval form Hebron Soft Ltd. Modification could void authority to use this equipment.