




USER MANUAL

Fit for Model No.E527 series.



1 Main parameters

Material: plastic and electronic components Batteries: Car battery: 4.8V AA rechargeable battery; Remote controller battery: 2 pcs of 1.5V AA batteries.




2 Battery Installation

1. Open the cover of battery case locates in the back of controller, inserts 2 pcs of 1.5V AA batteries into the battery case, and then screw the cover (Fig 2A).

2. Please screw out the cover at the back of car by screwdriver, open the cover as the arrow showed, insert 1pcs of 4.8 V AA battery, then screw the cover (Fig 2B).








Notice: This product shall be charged for two to three hours. The supporting USB charger shall not be used for other devices other than this product.

3 Installing the sprinkler head and filling the water tank

1. Open the colorful box, unpack the blister packing in the upper left corner of the remote control car, take the car out, rotate the fountain, and install the sprinkler head. (Fig 3A)

2. To operate the function of spraying, open the water tank and fill it with clean water (in order to avoid damaging the car, the water tank should be empty, when the remote control car is not used or the function of spraying is not performed for a long period). (Fig 3B)





4 2.4G Auto Coding

- 1. After installing the batteries on the car and the remote controller, turn on the power of both. There is a sound of DI from the car, and the indicator on the remote controller and the lights on the car would be flashing slowly. That means the car is in a state of coding, the auto-coding would be successful if the car with DI-DI sound.
- 2. Each remote controller could be only coded with one car. There is no any interference if auto-coding is success.
- 3.It could be re-auto-coded with other car or remote controller by turning off the power of

5 Basic Operation & Functions

1.Turn ON/OFF

• Press the ON/OFF key, there will be a start-up sound; to press the key again after starting. (Fig5A)

2.Horn Kev

• To press the Horn Key on remote controller after starting the car, the car would emit a simulated sound.

3.Forward/Backward

• To push the Left Handle forward/backward, the car would go forward/backward (Fig 5B) 660 degree Rotation

4.Turn Left/Right

• To push the Left Handle forward/backward, Right Handle turns left/right, the car would turn left/right. (Fig 5C).







the sound station.

• To press the DEMO key, the car could operate a series of the functions automatically; to exit this function through pressing any key.

3. Auto off

any signal from the remote controller by 60sec.

• When the car goes forward/backward, to change the direction directly, the car would be with braking sound and motion.


• The product is remote controlled by 2.4GHz, so many cars could be played together by players.

7 Recharging

Notice: Please push the power switch to "OFF" position if the product will not be used for a long time. Take the batteries out of the remote controller and the truck for storing. Please charge the battery for 4 to 5 hours, 8 hours for initial use.







hand over(draw back) slowly with a series of mechanical sound, flashing lights at the top of cab, lighting up of the front and back lights(Fig 5E).

7.Siren

on(Fig 5D).

• After starting the fire truck, press the Siren Key, the fire truck would emit a sound for alarming. At the same time, the light at the top of cab would flash up. To press the key again, it could be switched to the sound of stand-by.

8. Simulated Pumper Function

5. 660 degree Rotation of Operation Station

Rotation, the Operation station would do a

motion of left/right rotation with sound. At the

same, the alarm light on the top of the cab would

flash and the lights of front and back would light

• After starting the car, to press the Left/Right

6.Up&Down, In&Out of Scaling Ladder

• After starting the car, to press the key of Up&

Down of Scaling Ladder, the scaling ladder of

at the same time, the second condole would

• Press the spray button in the remoter, the sprinkler head sprays water, when loosen the spray button, the sprinkler head stops spraying water (on the condition that there is water in the water tank)

These functions could be multiple used for simulating operation.

6 Advanced Functions

1. Mute Switch

• After starting the truck, to press the Horn key for a long time, the car could change to a mute condition. To press the Horn key again, it could be switched to

2.DEMO Function

• After turning on the remote controller, the car would be auto off without receiving

4.Braking Function

5. Multi-playing function

8 Notice

- 1. Don't play the toy on the road, select a safe place for operating to avoid
- 2. Plays the toy in water may cause short-circuit damage. Please use the dry cloth to clean the car.
- 3.If abnormal speed or reaction, it may be because of insufficient battery power, please charge the battery.
- 4. The batteries should be charged under adult supervision. Please use the batteries recommended
- 5.Please install the battery in a correct polarity.
- 6.Do not mix new and old batteries together, short-circuited.
- 7.Please charge the battery before initial use.
- 8.Please check the plug, case and other units of charger regularly to make sure that it is not broken. Don't use again if you find abnormality of the charger.
- 9.Please do not connect the product to different performance power.

CAUTION: Please do not aim at eyes or face when spraying water.

Frequency bands: 2405MHz to 2475MHz

Maximum output power: -15.79dBm(Declaration for Europe)

Manufacturer: Doubleeagle Industry (China) Limited.

Address: Xingda Industrial Park, Chenghai

District, Shantou City, Guangdong Province, China.

Importer: JAMARA e.K.

Address: Inh. Manuel Natterer

Am Lauerbühl 5 - DE-88317 Aichstetten Germany

CHOKING HAZARD-small parts, not for children under 3 years.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- measures: -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.