

Operational description

It functions chiefly as a data sending and receiving machine to the IC tag Use is shown as follows.

1. The equipment is connected as shown in following figures.



- 2. FRWA-C01U It supplies power to the Host Controller.
- 3. The IC tag is held up on the antenna side.
- 4. The power supply and data are transmitted from the antenna to the IC tag by transmittig the command from the host controller and it communicates.



(FATH-3040U: Loop antenna on the PCB)

5. FRWA-C01U acquires the data of the IC tag according to the communication, and transmits the acquired data to the host controller.