CRAZON





User Manual

Thank you for your purchase of our product, understanding or operation of this product, please refer to the manual

*Pictures and objects may be different please forgive



s equipment should be installed and operated with minimum distance 20cm between the radiator and your body This transmitter must not be co-located or operating in conjunction with any other antenna or transmitte. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

DIY off-road vehicle (camera version)










Manual


3.7V Li-poly battery 4*1.5V AA battery USB Line

- 1. 3.7V Li-poly battery for the car (included)
- 2. 4*1.5V AA battery for the transmitter(not included)
- 3. User manual (included)


- 2-







BATTERY INSTALLATION DIAGRAM



1. Open the battery box by the screwdriver 2.put on the 3.7V battery.


3. Put on the battery box cover and screw up the screw.



- 4-


ASSEMBLE

ASSEMBLY COMPONENT DESCRIPTION



DISASSEMBLY COMPONENT

Assemble the accessories follow to the arrow as picture 2 shown



- 5-

Notice: You must aim to the hole when assembling

Operation Steps.

BINDING

There is a ID between the transmitter and receiver, this is called binding. Please control the wifi signal and 2.4G signal when settle as it will brings annoying. 1.Please press the binding button when turn on the transmitter, the green LED light will flash 20 seconds.


2.Do not press the rocket and direction button when binding, the car will bind to the transmitter automatically




TRANSMITTER OPERATION WAY.

THROTTLE


As shown, pull the rocket to you, the car goes forward. Push the rocket, the car goes backward.






OPERATION

1. When you face to the car back, if you turn the rotation to right, the car will turn right. If you turn the rotation to left, the car will go left.





2. When the car runs in high speed, push the rocket, it will brake. (Notice: Please drive low speed for practising first before driving in high speed. When the car becomes slowly, please charge it.)

MOBILE PHONE OPERATING WAY

- 6-

1 Please scan the OR-code to download the APP, When finish, your phone will show the DIY camera car APP.



Turn on the car, enter your mobile phone settle and turn on the wifi, find Settle wifi hotspot in the list, press connect until connected. Open the APP, press the logo , enter real-time section.



3. Enter control section, start playing our Camera car, as picture shown.



1.Turn left 2.Turn right 3. Forward 4.Backward

- 7-

CAMERA ADJUSTING

USB charging way

1. As picture 3 shown, you can adjust the camera to left and right



2. As picture 4 shown, you can adjust the camera up and down



ADJUST CHASSIS HEIGHT

As shown in Figure 5, the front wheel will be squeezed by hand, and then counterclockwise rotation of the lock plate, the front wheel plate down.
As shown in Figure 6, the front wheel is tightly pressed by hand, and then the locking plate is rotated





3. As shown in Figure 7, the first hand to squeeze the rear wheel, and then push the lock to the left,

4. As shown in Figure 8, the first hand wheel after the pinch, and then push the lock to the right, the rear wheel up





MAINTAIN

Regular maintenance of the product after using, ignoring this step may improve engine and chassis damage probability

OPERATION MAINTENANCE

As shown in Figure 9, clean the rotating shaft and the debris on the tire, otherwise the motor will overheat or damage. And it's hard to control.

2. Place the car in place when not in use. If the chassis or front shock absorber is bent, the left and right steering radius will be uneven

 As shown in Figure 10, if the steering is not average, can be bent by hand, the car on the horizontal surface to determine whether or not the balance

