# BLUETOOTH EAR BUDS C1 USER MANUAL

3 Connection diagram 4 The way to change earhook 5 How to use 5.1 General functions

Table of contents

# 1 Introduction 2 Package content 5.2 Pairing to mobile phone 5.3 Charging your device-6 Technology specification 7 After-sales service and support

# 1.Introduction

Thank you for choosing the Stereo Ear Buds. This manual will help you operate the Ear Buds, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Ear Buds.

# Safety Rules

- Please follow the rules depicted in this manual closely to ensure your safety. Before using this Ear Buds, we would strongly encourage you to read through this user 2\ Be more wary of any edges, uneven surfaces, metal.
- parts, accessories and its packaging so as to prevent any possible injury or damage. 3\ Do not modify, repair or dismantle this Ear Buds. Doing so may result in fires, electric shocks. complete breakdown of this Far Buds, etc. All of which, are not covered under warranty.
- 4\ Do not use any diluents or volatile liquid to clean the
- 5\ Do not use the Ear Buds in a hazardous location.

# 2.package content



1X Wireless Far Buds C1 1X USB Charger cable 1X User Manual

# 3. Connection Diagram

pause/Turn off Answer call/ Fnd call/ Transfer call voice

# 4. The way to change earhook











# 5.1.General Functions

Desired Result	Required Action
Turn on	Press the "O" button for 3 seconds when the device is off. (Red LED slowly flashes and a tone voice beeps)
Enter the pairing mode	When the device is off, Press the "o" button for 6 seconds.(Blue LED and Red LED quickly flash alternately with two beep tone voice
Pairing	In pairing Mode use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)
	2
	Turn on  Enter the pairing mode

C1 USER MANUAL

Short click "O" to play when the device is pausing and short click "@" to pause when the device is playing Short press the "+" button for Next music Volume up Long press the "+" button for Volume up Previous / Short press the "-" button for Previous music Volume down Long press the "-" button for Volume down Press the "O" button for 3 seconds when Turn off the device is on (A tone voice been and all Low battery The Red LED flash Plug the charger to port of the device. Charging \_\_\_\_ Short Press the " O " button while a call Answer call

Desired Result



## Short Press the "@" button while on going End call Double Press the "@" button to transfer Transfer call vo ice the call voice between the mobile phone and device while on going call Press the " @ " button for 1~2 seconds Reject call to reject call when the call is ringing \_\_\_\_ Battery status will be shown on the top rig Battery power corner of the phone screen after connected (Only support inhone, iPad)

Short press the "O"button to enable Multipoint

disable the Multipoint at pairing mode

at pairing modeDouble press the "O" button to

Required Action

# Desired Result | Required Action ong press"+"button for 6 seconds at pairing mode to clear the paired device list.

Last number redial Double click "O" button on connect state.

## 5.2. Pairing to Mobile phone or other device

To use your Ear Buds, you must first pair your Ear Buds with a phone or a computer. Once your Ear Buds is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

C1 USER MANUAL

# Pairing to a phone and Entertainment:

- Turn on your phone and ensure its Bluetooth function
- Turn on the Ear Buds go to the paring mode.
- Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- . After a few second the phone will list the device as a discover device. Select it and follow your phone instruction to select this pairing.
- Then your phone will request a passkey or PIN, enter 0000 as your PIN or nasskey
- Your phone will confirm the pairing, and then press Yes/Ol
- Finally, select to connect with device from your phone.
- You can play music; watch TV/movie and play game with your phone, then your can hear all the sound or music form the device. Also you can control the player by operating the device. Example, volume up and next music.

# Pairing to a computer and Entertainment:

C1 USER MANUAL

- If there is no Bluetooth function supported by your You must select a qualified charger from a regular manufacture You must charge the Ear Buds if it has been not used for more computer, a Bluetooth adapter is necessary. Fix the adapter with your computer and ensure its Bluetooth Please don't use the USB charger on any other phone lack device.
  - 6. Technical specification

C1 USER MANUAL

# Value

Parameter

10 m
40Hz-20KHz
10mW
≥90dB
≤3.0%
About 5.5 Hours
About 1.5Hours
555.8X27X18mm
14. 5g

If your device is not performing as it should please take it to

7. After-sales service and support

your local service providers or dealer for service.

to the Ear Buds.

2\There is no sound when playback

there is no guarantee that interference will not occur in a 3\How can I know the Ear Buds has been fully charged? particular installation. If this equipment does cause harmful Ans: When the indicator LED turns red to blue when it is interference to radio or television reception, which can be determined by turning the equipment off and on, the user is charging, it has been fully charged. encouraged to try to correct the interference by one or more

C1 USER MANUAL

4\why the Ear Buds cannot connect with second phone? Ans: Please set the Ear Buds to multipoint mode.

1\Why is there no power even when the Ear Buds is power

Ans: Ensure the battery is being charged up to 6 hours for

Ans: Check the connection between your device with

phone or computer, if the connection is not

Far Buds is naired and connected with your

target phone or other master device.

first time using. The LED is lighted when it starts

established, please reconnect again. Make sure the

Connect the Far Buds to phone A

## MEASURES: Once again enter to pairing mode (phone one, will disconnect), and connect the Ear Buds to phone B. -- Reorient or relocate the receiving antenna. and then use phone A paired device list to reconnect

-- Increase the separation between the equipment and

WARNING: This device complies with Part 15 of the FCC

Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received.

including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply

with the limits for a Class B digital device, pursuant to Part

15 of the ECC Rules. These limits are designed to provide

reasonable protection against harmful interference in a

residential installation. This equipment generates, uses

and used in accordance with the instructions, may cause

harmful interference to radio communications. However,

and can radiate radio frequency energy and, if not installed

changes or modifications not expressly approved by the

could void the user's authority to operate the equipment.

party responsible for compliance

- Connect the equipment into an outlet on a circuit different
- from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician

FCC RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

of the following

C1 USER MANUAL

Enable/Disal

C1 USER MANUAL

function is activated.

same operation

playback on your device.

the indicator LED turns red to blue.

5.3. Charging your device

Turn on the device and go to the paring mode.

Bluetooth software for more information.

Open the Bluetooth software (such as BlueSoleil)

software of your computer as a discover device.

Open your media player to play music, watch

installed on your computer, and selects "Search your

Bluetooth devices" function Refer to user manual of the

After a few second the "device name" will list in Bluetooth

Select this icon and click right button of mouse to select

TV/move and play game, then all the sound will be

The device is convenient to connect to AC charger or a USB

charger with Micro USB port marked with Make sure that

your device is full charged for at least 6 hours before initial

use. Insert one terminal of your charger to AC main or USB

port of PC and other terminal to Micro USB. While charging.

the red LED light constantly. When charging is completed,

"pairing" item then select "connect with audio device" with