

JY-BT232

Stereo Bluetooth Headphone Instruction Manual

SAFETY PRECAUTIONS

- 1. Please read, follow and keep these instructions
- 2. Heed all warnings on the product and in the operation instructions
- 3. Stop using this product immediately if it causes discomfort or pain. When using this product, it is recommended that you limit volume to help avoid harm to your ears and danger resulting from being unable to hear what is going on around you.
- 4. Keep the device out of extreme heat and humidity.
- 5. Do not use the device near water, such as sinks, bathtubs, swimming pools, washing machines, tubs of water, etc.
- 6. Observe all signs and instructions that require an electrical device or radio product to be switched off in designated areas, such as petrol/refuelling stations, hospitals, blasting areas, potentially explosive atmospheres or aircraft.
- 7. Using a headphone while driving can distract you and increase the likelihood of an accident. If driving conditions demand it (such as bad weather, high traffic density, presence of children in the car, difficult road conditions), pull off the road and park before making or answering calls.
- 8. Power time may differ depending on personal habits.
- 9. Please do not rotate the headset when the head band has been set / pushed to the lowest position.
- 10. This appliance should be used in moderate climates.
- 11. To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
- 12. The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.
- 13. Only use attachments/accessories specified or provided by the manufacturer.

WARNINGS!

- 14. To prevent possible hearing damage, do not listen at high volume levels for long periods.
- 15. Do not turn up the volume too high, doctors warn against prolonged exposure to high volume.
- 16. Stop using the product or lower the volume if you feel your ears ringing.
- 17. Prolonged listening at high volume could lead to hearing damage.



Bluetooth wireless technology

Bluetooth wireless technology allows you to connect compatible devices without cables. A Bluetooth connection does not require that the phone and the headset be in line of sight, the distance between the devices is up to 10 meters (30 feet). The closer the phone and the headset are to each other, the better is the performance. The connection is subject to interference from distance and obstructions or other electronic devices. The headset is

compliant with Bluetooth Specification 2.1+ EDR. Check with the manufacturers of other devices to determine their compatibility with this device.

There may be restrictions on using Bluetooth technology in some countries/locations. Check with your local authorities or service provider.


PACKAGE CONTENTS

- Bluetooth Stereo Headphone
- USB charging cable
- Instruction manual
- 3.5mm audio cable

Features:

Bluetooth 2.1 + EDR Calling function

OVERVIEW OF THE HEADPHONE



- 1. Volume up (Next track)
- 2. Multi-function button (pairing, play/pause, answer/end calls)
- 3. Volume down (Last track)
- 4. Power on/off switch,
- 5. Blue LED (power and pairing status indication)
- 6. AUX IN
- 7. Red LED (battery charging and low-voltage indication)
- 8. USB Charging port
- 9. 3.5mm Audio cable

Charging the Wireless Headphone




 To charge the headphone, plug the included USB charging cable into your headset and computer (or an optional USB charger). When the headset battery is very low, the red LED will continually flash and a full charge can take up to three hours with solid red LED light. The red LED will turn off when charging has been finished.

CHARGING LI-POLYMER BATTERY SAFELY

- ❖ The headphone has a non-removable lithium-polymer battery.
- ❖ Do not try to remove the battery. Do not dispose of the headphone in a fire, the battery may explode.
- ❖ Dispose of the headphone in accordance with the applicable laws and regulations in your area for the disposal of lithium-polymer batteries.
- ❖ Non-compliance with the conditions of use of the lithium-polymer battery may cause a fire, explosion or chemical burn.
- ❖ Do not allow battery leakage to come into contact with eyes or skin. In case of contact, flush eyes or skin with plenty of water and seek medical advice.
- ❖ Do not expose the lithium-polymer battery to a temperature higher than 60 °C.
- Do not disassemble, crush, short-circuit or incinerate your battery as it may cause fire, injury, burns, or other hazards.
- ❖ Before your first time use, please recharge your headphone.
- Do not overcharge your player, or it may shorten the battery's life.
- The times of charge/discharge are no less than 300 cycles.
- The li-polymer battery is consumptive material, so recharge it periodically is needed even if the player is not be used.

Connecting the Wired Headphone



- Turn OFF the power on/off switch.
- Connect 3.5mm audio cable to AUX IN
- Connect the 3.5mm audio cable to any 3.5mm audio jack of audio device.

Connecting the Wireless Headphone

- Turn ON the power on/off switch.
- Power on the Bluetooth device (e.g. MP3, mobile phone, smart phone or tablet to be paired with the headphone). Turn on Bluetooth feature on your device and set to search the Bluetooth headphone. See the instruction of your Bluetooth device.
- Press and hold the multi-function button for six seconds (It could be seven seconds if the headphone has never been paired with Bluetooth devices before) to turn the headphone on; the headphone would automatically enter pairing mode then the Red and Blue LED blinks rapidly
- (The headphone could search the last paired Bluetooth device for 3 minutes and it would shut down automatically if without pairing)
- In the Bluetooth device menu, select "CHBT08" from the list.
- When the headphone status light turns solid blue, a Bluetooth connection is made
- Power Off your headphone by pressing the Multi-function button for four seconds with the red LED shortly flashing and then going off.

Using the headphone

Listen to music or make a call. Play/ Pause.

- 1. Select an audio track or video clip.
- 2. Tap (press less than one second) the Multi-function button to play / pause the audio track or video clip.
- 3. Short press the volume up / down button to have "next / last track" function
- 4. Long press (less than one second) the volume up / down button to adjust volume to your favourite

Answer an incoming call

 Connect the headphone to a smart phone. Short press (less than one second) the Multi-function button to answer an incoming call.

End a call.

Short press (less than one second) the Multi-function button to end the call

Redial last call

- press the multifunction button two times. This function only in the use of hands-free set when available, for more information, please refer to the mobile phone user manual.

Reject an incoming call.

Press the Multi-function button for three seconds (two times).

Adjust the volume during a call

long press the volume increase / decrease button.

I FD indications

Flashing Blue	Bluetooth: A connection is made; your headphone is ready to use.
	,
Flashing Red	Bluetooth: A rapid blink indicates pairing is achieved; a slower blink indicates the headphone is connectable, but not yet connected.
Slow Flashing Red	The battery is in low power
Short Flashing Red	When you turn off the headphone successfully, the red LED will short flash and go off
Solid Red	Charging, and the red LED will turn off if charging finished.
Red and Blue Fiashing alternatively	Ready for pairing.
No light	Your headphone is powered off.

TECHNICAL SPECIFICATION

Headset

Driver Unit: 40 mm

Sensitivity: 100dB S.P.L at 1KHzImpedance: 32Ω

 Maximum input Power: 100 mW RF receive sensitivity: -80dBm Signal-to-noise ratio: ≥70dB

 Frequency response: 20Hz - 20kHz Bluetooth working range : ≤10m

Microphone

Φ4mm Omni-directional microphone

Battery

Li-polymer battery: 300mAh

- Battery life: ≥12 hrs (continuously operating)
- \geqslant 170 hours of standby time
- Charging time: ≤2 hrs

TROUBLE SHOOTING

See below for solutions to common problems.

Symptom	Solution
LEDs are not light	Use the provided USB charging cable to charge the battery by referring to the "charging the wireless headphone" in this guide Check if the headphone is receiving power from your computer's USB port; if not, try another USB port on your computer. Then turn on your computer to charge the headphones Try re-pressing the multi-function button
Bluetooth not connecting?	Try powering off the headphone, and then power it back on by pressing the Multi-function button. If failed to pair within 3 minutes, re-establish pairing between the headphone and your Bluetooth device by referring to "connecting the wireless headphone" in this guide Try using the headphone with a different Bluetooth device Make sure the Bluetooth feature is activated of your device.
Distorted sound? No sound at all? Microphone not working?	Trying moving the headphone closer to your Bluetooth device. The wireless status light on the headphone turns solid blue when the headphone is in range (up to 10m) with Bluetooth device Make sure the headphone is selected as the active output audio device on your Bluetooth device Adjust the volume settings to an audible level on both your headphone and Bluetooth devices Check if the red LED is flashing (the battery is in low voltage). Then charge the battery immediately.

TRADEMARKS

CARREFOUR is a registered trademark of Carrefour group. All other company names are trademarks, registered trademarks or service marks of their respective owners.

Declaration of Conformity

Hereby, Carrefour declares that this Bluetooth device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The declaration of conformity may be consulted at: CMI - 2 Avenue du Pacifique - Les Ulis - 91940 COURTABOEUF Cedex FRANCE

Net weight: 160 g



Recycling

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2002/96/EC in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

For further information, please contact your local or regional authorities.

For FCC

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.