


17015 SEVEN PINES DR., BLDG. #1 SPRING, TX 77379 832.717.4331

3.31 x 2.92 in

4-panel



































Paired or connected to audio device مقترن أو متصل بجهاز الصوت Dipasangkan atau disambungkan ke perangkat audio Сдвоено или свързано към аудио устройство Spárováno nebo připojeno ke zvukovému zařízení Danner par med eller er tilsluttet lydenhed Mit Audiogerät gekoppelt oder verbunden Emparejado o conectado a un dispositivo de audio Σε σύζευξη ή σύνδεση με συσκευή ήχου Couplé ou connecté au périphérique audio Upareno ili povezano s audiouređajem

Abbinato o connesso a dispositivo audio Аудио құрылғысымен жұптастырылған немесе оған қосылған

Savienots pārī vai pievienots audio ierīcei Susieta arba sujungta su garso įrenginiu Audioeszközhöz párosítva vagy csatlakoztatva Gekoppeld of verbonden met audioapparaat Paret eller koblet til lydenhet

Emparelhado ou conectado a dispositivo de áudio Emparelhado ou conectado ao dispositivo de áudio Împerecheat sau conectat la dispozitivul audio Связано или подключено к аудиоустройству Spárované alebo pripojené ku zvukovému zariadeniu

Sparowane lub połączone z urządzeniem dźwiękowym

Seznanjen ali povezan z zvočno napravo Laitepari tai yhteys muodostettu äänilaitteen kanssa Upareno ili povezano sa audio-uređajem Ihopkopplad eller ansluten till ljudenhet จับคู่หรือเชื่อมต่อกับอุปกรณ์ระบบเสียงแล้ว

Ses aygıtına eşleştirilmiş ya da bağlı Утворено пару або встановлено підключення з аудіопристроєм オーディオ デバイスにペアリングまたは接続されています 오디오 장치에 페어링되거나 연결됨 已配对或已连接到音频设备

配對或連線到音訊裝置

Parrer

Siejama

Párosítás

Lavt pågår

Parowanie

Párovanie

Seznanjanje

Uparivanje

Eşleştiriliyor

Утворюється пара

Parkopplar

กำลังจับคู่

Pairing Low battery يتم الآن الإقران بطارية ضعيفة Baterai lemah Memasangkan Сдвояване Изтощена батерия Párování Vybitá baterie Lavt batteriniveau Koppeln Schwacher Akku Batería baja Emparejando Σύζευξη Batterie faible Association Uparivanje Niska razina napunjenosti baterije Batteria scarica Abbinamento Төмен батарея заряды Жұптастырылуда Zems akumulatora uzlādes līmenis Savienošana pārī

Akumuliatorius senka Accu bijna leeg Apparatenpaar vormen Dårlig batteri Niski stan baterii Bateria fraca A emparelhar Bateria fraca Emparelhando Se împerechează Nivel scăzut al acumulatorului Выполняется связывание

Низкий заряд батареи Takmer vybitá batéria Nizko stanje akumulatorja Akku lopussa Laiteparin muodostus käynnissä Baterija na izmaku Svagt batteri เเบตเตอรี่อ่อน Düşük pil


Низький заряд батареї

ローバッテリ

배터리 부족

電池電力不足

Χαμηλό επίπεδο φόρτισης μπαταρίας Az akkumulátor töltöttségi szintje alacsony




Chargement en cours Punjenje In carica Зарядталуда Notiek uzlāde Įkraunama Töltés Opladen Lader Ładowanie A carregar Carregando Se încarcă

Nabíjanie Polnjenje Lataus käynnissä Puni se Laddar กำลังชาร์จ Şarj ediliyor Триває заряджання 正在充电

Зарядка

充電中





Regulatory logos 法規標誌 Remove ear cup to view regulatory label. 取下耳罩可查看管制标签。

Impreso en China Impresso na China 中国印刷 청뀨작썹 짧씨



L14113-B21

RMN/型號/型号: HSA-G002H

© Copyright 2017 HP Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.


First Edition: December 2017

xxxxx/SDPPI/2018

TA-2018/xxxx APPROVED

Complies with **IMDA Standards** DB106008

IC:9043A-G002H



Breve pressão

Pressão > 1 segundo

hovormi.

krátke stlačenie

stlačenie dlhšie ako 1 s

no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Consult the dealer or an experienced radio/TV technician for help.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Fold 1:

4-panel

accordion

pressione breve

pressione >1 secondo

hívások között.

Rövid lenyomás

>1 másodperces lenyomás

accordion

Flat size:

Folded size:

3.31 x 2.92 in

16.5354 x 11.69 in

Color Side 1:

17015 SEVEN PINES DR., BLDG. #1

Кратко натискане

Натискане за >1 секунда

SPRING, TX 77379

832.717.4331