MA-3569 TWS Earphone



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

Getting Started

- Remove the product from the packaging.
- Please retain packaging until after you've checked and counted all the parts and the contents against the Package Contents list.

Package Contents

- True Wireless Bluetooth Earpods (Pair)
- Charging Case
- USB Charging Cable
- Two pairs of silicon eartips
- Instruction Manual

Features

- True wireless Earpods connect to each other without any wires
- Portable & lightweight with on-the-go charging case
- Built-in microphone for hands-free calls
- Built-in controls for play/pause & answering calls
- Great for use at work or home or on-the-go
- Rechargeable Storage case charges your earpods even when you're on the go

Safety Instructions

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not use the unit with wet hands.

Do not put objects into any of the openings.

Keep the unit free from dust, lint etc.


Do not use this unit for anything other than its intended use.

Keep the unit out of reach of children.

This product is not a toy.

Do not use the headset at excessive volume levels, as damage to hearing may occur.

Description of Parts:



1	Dust-proof Mesh	
2	MF (Multi-Function) / Phone Button	
3	LED Light Indicator / Built-In Microphone	
4	Charging Slot	
5	Charging LED Indicator	
6	Charging Case Power Indicator	
7	Charging Case Power ON/OFF Switch	
8	Charging Port	

INSTRUCTIONS FOR USE

Charging Instructions

The Charging Case and Bluetooth Earpods come with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Use only the supplied USB cable for charging.

To charge the Charging Case (without Bluetooth Earpods inside the charging slots)
Connect the USB cable to a computer USB port or any USB charging source, and the Micro

USB plug to the charging port of the Charging Case. The Charging LED indicator flashes red to indicate that its built- battery is being charged. It takes 1-2 hours for the case to charge fully. When the battery is fully charged, the Red LED light will remain on.

To charge the Bluetooth Earpods

- 1. After fully recharging the Charging Case, disconnect the USB cable.
- 2. Put the Bluetooth Earpods into the charging slots correctly and securely.
- 3. Short press the Power ON/OFF Button on the Charging Case to begin charging the earpods (with Blue Power Indicator), the LED light indicator on the Earpods turn red to indicate that the battery is being charged. It takes 1-2 hours for the Earpods to fully charge. When the battery is fully charged, the LED light will turn blue.

Turn on/off the Bluetooth Earpods

Press and hold the **MF** button for 3-5 seconds to turn ON or OFF the Earpods.

A. Pairing <u>either one</u> of the Bluetooth Earpods with Bluetooth devices (smart phone or tablet etc)

- Press and hold the MF button for 3-4 seconds to turn on, an indication tone will be heard and the LED will flash red and blue.
- Bring the Bluetooth Earpod and Bluetooth device (smart phone or tablet etc) no further than 3 feet apart from each other.
- Activate the Bluetooth function on your mobile device. Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.
- Once you have activated Bluetooth on your mobile device, select the "SL TWS
 Earbuds" from the list of available Bluetooth devices.
- If required, enter the password '0000' to confirm & finalize pairing.
- Once paired successfully, another indication tone will be heard and the LED will flash blue slowly.
- You can now start to use the Earpod.
- If pairing is unsuccessful, turn off the device first and then re-pair following the above steps.
- Once you have paired the Bluetooth Earpod with a mobile device, the Earpod will remember this mobile device and will pair automatically when its Bluetooth is activated within the range, during subsequently pairing. You do not need to re-pair any previously connected devices.
- The Bluetooth Earpod will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.

Making a call with the Bluetooth Earpod in Bluetooth mode Basic operation

Function	Operation	Button
Answer incoming	Incoming Call	Short press the Phone button to answer an
call		incoming call.

Reject Incoming Call	Incoming Call	Press the Phone button 2 seconds and release
End call	Incoming Call	After your phone conversation, Short press the Phone button
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

Play Wireless Music

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired successfully with the Bluetooth Earpod to stream wireless music. Once it is paired, play music from your device.

Function	Operation	Button
Pause	Playing music	Short press the MF button will pause the music
Play	Pausing	Short press the MF button will resume the music
Next track	Playing music	Press and hold the MF button for 2 seconds (and release)

Note: Other functions including volume increase/decrease, next/previous track, you may need to control through your source device.

B. Pairing <u>both</u> Bluetooth Earpods with Bluetooth devices (smart phone or tablet etc)

- The right Earpod is set as the host Earpod by default. Ensure the Bluetooth Earpods are turned off. Press and hold the **MF** button on both Earpods for 3-5 seconds simultaneously, you would hear an indication tone from each Earpod.
- After few seconds, you would hear another indication tone. The LED light indicator
 on the right Earpod (host Earpod) will flash red and blue, and the left Earpod
 (subordinate Earpod) will flash blue slowly.
- At this point, activate the Bluetooth function on your mobile device, and search for Bluetooth devices near you.
- Once you have activated Bluetooth on your mobile device, select the "SL TWS
 Earbuds" from the list of available Bluetooth devices.
- Once paired successfully, an indication tone will be heard from the right Earpod (host Earpod) and the LED on both units will flash blue slowly.

REMARK: If you would like to change the left Earpod as the host Earpod, follow below steps to get it done:

- a. Ensure the Bluetooth Earpods are turned off. Press and hold the **MF** button on both Earpods for 3-4 seconds simultaneously to turn on, they will pair together automatically after few seconds with the right Earpod (as the host Earpod), and the left Earpod (as the subordinate Earpod).
- b. The LED light indicator on the right Earpod (the host Earpod) will flash red and blue,

- and the left Earpod (the subordinate Earpod) will flash blue slowly.
- c. At this time, short press the MF button on the right Earpod twice, then, press and hold the MF button for 3-4 seconds to turn it off (and the subordinate Earpod will also turn off). This will cancel their initially pairing.
- d. After that, press and hold the **MF** button on both Earpods for 3-4 seconds simultaneously to turn on, you would hear an indication tone from each Earpod.
- e. Short press the MF button on the left Earpod twice, and you would hear another indication tone after a few seconds.
- f. The left Earpod will now become the host Earpod (and the right Earpod will become the subordinate Earpod). The LED light indicator on the left Earpod (as the host Earpod) will flash red and blue, and the right Earpod (as the subordinate Earpod) will flash blue slowly.
- g. At this point, activate the Bluetooth function on your mobile device, and search for Bluetooth devices near you.
- h. Once you have activated Bluetooth on your mobile device, select the "SL TWS Earbuds" from the list of available Bluetooth devices.
- i. Once paired successfully, another indication tone will be heard will be heard from the host Earpod and the LED on both units will flash blue slowly.

Making a call with the Bluetooth Earpods in Stereo pairing mode Basic operation

Function	Operation	Button
Answer incoming	Incoming Call	Short press the Phone button of any Earpod
call		to answer an incoming call.
Reject Incoming Call	Incoming Call	Press the Phone button of any Earpod for 2
		seconds and release
End call	Incoming Call	After your phone conversation, short press
		the Phone button of any Earpod
Redial last number	Standby mode and	Short press the Phone button of any Earpod
	connected to a device	twice

Note: Only host Earpod supports phone conversations.

Play Wireless Music in Stereo pairing mode

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Earpods to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Pause	Playing music	Short press the MF button of one Earpod will pause the
		music
Play	Pausing	Short press the MF button of one Earpod will resume the
		music
Next track	Playing music	Press and hold the MF button for 2 seconds (and release)

Note: Other functions including volume increase/decrease, next/previous track, you may need to control through your source device.

Care and Maintenance

Read the following recommendations before using the Bluetooth Earpods. Following these you will be able to enjoy the product for many years.

- Do not expose the Bluetooth Earpods to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the device.
- Do not expose the device to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the device in a fire as it will result in an explosion.
- Don't expose the device to contact with sharp objects as this will cause scratches and damage.
- Don't let the device fall on the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the device as it may get damaged if you are not professional.

Specifications

Bluetooth specification	Bluetooth 4.2
Operating distance	33 feet
Working time	Music: up to 1 hour
	Talk: up to 2.5 hours
Charging input voltage	DC 5V
Charging time	1-2 hours
Built-In Battery	Charging Box: 350mAh
	Bluetooth Earpod: 45mAh (each)
Size	Charging Case: 2.17" (L) x 1.10" (D) x 2.66" (H)
	Bluetooth Earpod: 0.75" (L) x 0.71" (D) x 1.85" (H)
	(each)
Weight	Charging Case: 1.16 oz
	Bluetooth Earpod: 0.14 oz (each)

(Note: Battery life & charging time may vary based on usage & types of devices used.)

FCC Instructions

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is

no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in USA, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@mtradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.