### **EXHIBIT C - EUT INTERNAL PHOTOGRAPHS**

Model: BF-P108


**EUT – Battery off View** 



**EUT – Cover off View** 



**EUT – Main Board Top View** 



**EUT – Main Board Bottom View** 



#### Model: BF-P118


**EUT – Battery off View** 



**EUT – Cover off View** 



**EUT – Main Board Top View** 




**EUT – Main Board Bottom View** 



 $EUT-Keyboard\ with\ LCD\ Top\ View$ 



**EUT – Keyboard with LCD Bottom View** 



**EUT – Antenna View 1** 



EUT – Antenna View 2



#### **EUT – Battery Label View**

## **ER-118**



# **NOTICE**

- Don't disassemble
- Don't throw into fire
- Don't change the battery in danger place
- Don't charging in danger place
- Don't short circuit
- Don't charging too long



Li-ion battery DC7.4V === 1700mAh