
© EXPLOSIVE VIEW





HIGH SPEED RACING INSTRUCTION MANUAL



BEFORE DRIVING

- Read the manual with parent or guardian(responsible adult).
- Check the range of your radio operation.
- Make sure that all screws and nuts are properly tightened.
- Always use fresh battery for transmitter and receiver to avoid losing control the model.
 Make sure that no one else is using the same radio frequency as you are using,
- Make sure that no one else is using the same radio frequency as you are using
 if you cannot control your car,stop driving immediately.
- Check the neutral trigger position.

DURING RUNNING

- $\bullet \ Do \ not \ run \ on \ a \ public \ street. This \ could \ cause \ accidents, personal \ injuries \ and/or \ property \ damage.$
- Do not run near pedestrians or small children.
- Do not run in small or confined areas.

AFTER RUNNING


• Disconnect the car battery pack before switching off the transmitter. This will prevent the car from losing control.

BATTERY SAFETY

- Be careful when handing the battery pack.It will be not after running.
- If the wire is frayed or worn, a short circuit can cause a fire or burn.
- \bullet Non-rechargeable batteries are to be recharged.
- \bullet Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.

OVERVIEW ©


KIT CONTENTS



START UP GUIDE

CHARGING THE BATTERY PACK

Always use the included charger for the included battery pack. Do not use any other packs. Charging time for an empty pack is about 4 hours. Do not charger the battery pack longer than 4 hours to avoid overheating and battery damage.






A CAUTIONS

After the first time charging the battery pack


Empty battery pack for 4 hohrs, if you are not sure about the battery level, empty the batter pack by driving the R/Ccar before charging the battery pack.


PREPARING THE CHASSIS



OPERATION

TRANSMITTER OPERATION





Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

	Reorient or relocate the receiving antenna.
	Increase the separation between the equipment and receiver.
	Connect the equipment into an outlet on a circuit different from that to which
the receiver is connected.	
	Consult the dealer or an experienced radio/TV technician for help.
Thi	is device complies with Part 15 of the FCC Rules.
following two conditions:	
(1) this device may not cause harmful interference, and	

(2) this device must accept any interference received, including interference that may cause undesired operation.