Bluetooth Speaker User Manual

Mini Speaker
USER MANUAL Bluetooth Speaker

In the box

- Mini Speaker
- 3.5mm AUX Cable
- Keychain
- Micro USB Charging Cable
- User Guide

Charging the Mini Speaker

1. Plug the small end of the Micro USB cable into the Micro USB charging port on the side of the speaker.
2. Plug the other end into a USB port on your computer or other device made for USB charging.
3. The LED indicator light on the front of the speaker lights up RED when charging. It will shut off when fully charged.

Micro USB Charging Port
Micro USB Charging Cable
Speaker
PC

Make sure you charge the speaker for at least 5 hours before using it for the first time.

Location of controls

1. LED indicator light
2. Power/Volume knob
3. Keychain hole
4. Micro USB charging port
5. AUX IN jack

Pairing the speaker with a Bluetooth enabled device

1. Turn the Power/Volume knob to the right to turn the speaker ON.
2. A tone will be heard and the LED indicator light will be flashing BLUE.
3. Keep the speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.
4. Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.

within 3 feet

If there are no paired devices in range when the speaker is turned on, it will go into pairing mode automatically. If a stored device is in range, the speaker will connect to it automatically.

On other Cell Phones/Devices

• Review the instruction manual that came with your phone/device.

5. When the Bluetooth enabled device finds the speaker, select 'Bluetooth Speaker' from the list of found devices.
6. If required, enter the password 0000. Select OK or Yes to pair the two units.
7. After a successful pairing, a tone will sound and the LED indicator light will flash BLUE every 2 seconds.

NOTE: If you would like to connect the speaker to another device, you must unpair the speaker from the currently paired device first. On your device's Bluetooth settings, select 'Bluetooth Speaker',then select 'unpair'. When the speaker has been unpaired, it automatically goes into pairing mode again.

This service does not typically work on many Bluetooth enabled devices in the market today, and are used to assist in the explanation of the pairing process. Your Bluetooth enabled devices interface and interaction with the Bluetooth Speaker may slightly differ from the illustrations above.

Playing Music

To enjoy wireless music on your Mini Speaker, make sure you are connected to a Bluetooth enabled device. Once connected you can press PLAY on your Bluetooth enabled device. When playback has begun, you can control the music with your connected device (which must have the AVRCP Bluetooth profile).

Most media enabled smart phones will display "Connected to phone audio and media" when connected to the Wireless Speaker. This means you can make phone calls and enjoy your music.

On a BlackBerry
• Go to SETTINGS/OPTIONS > BLUETOOTH
• Enable BLUETOOTH (Make sure Bluetooth is turned ON)

On an Android Phone
• Go to SETTINGS > BLUETOOTH > MENU > Search for devices (Make sure Bluetooth is turned ON)

On an iPhone
• Go to SETTINGS > GENERAL > BLUETOOTH (Make sure Bluetooth is turned ON)

Using as a wired speaker

1. Turn on the speaker.
2. Connect one end of the 3.5mm AUX Cable to the AUX IN jack on the side of the speaker, and the other end of the cable to an external device's headphone jack (smartphone, tablet, MP3 player).
3. Use the controls on your connected device to control music playback.
4. Turn the Power/Volume knob on the front of the speaker to adjust the volume, or you can use the volume control on your connected device.

3.5mm AUX cable

Troubleshooting tips

I can pair the Mini Speaker with my Bluetooth device, but I cannot hear any music.
• Make sure your Bluetooth device supports A2DP profile.
1. Make sure the Mini Speaker is turned ON before beginning the pairing process.
2. Turn up the volume on your Bluetooth device or the speaker.
3. You may have to unpair the speaker, then re-pair to your device.

I cannot get the Mini Speaker into pairing mode.
1. Make sure the Mini Speaker is turned ON before beginning the pairing process.
2. The speaker will emit a tone and the LED indicator light will be flashing BLUE.
3. The speaker is now in pairing mode.

My Bluetooth device is not able to pair with the Mini Speaker.
1. Make sure the Mini Speaker is turned ON before beginning the pairing process.
2. Keep your Mini Speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. The speaker will emit a tone and the LED indicator light will be flashing BLUE.
4. Check that YOUR device's Bluetooth feature is turned ON.
5. Try repeating the pairing process, see "Pairing the speaker with a Bluetooth enabled device".

Using your Mini Speaker

Powering ON/OFF
• To turn ON, turn the Power/Volume knob on the front of the speaker to the right.
• To turn OFF, turn the Power/Volume knob on the front of the speaker to the left.

Adjusting the volume
• Turn the Power/Volume knob on the front of the speaker to adjust the volume to the desired level.

NOTE: You can also adjust the volume from your connected device's volume control.