Introduction

Thank you for purchasing the GameStick Dock. Before starting, please take a couple of minutes to read this guide to setting up and using your GameStick Dock.

What's in the box

- 1 x GameStick Dock
- 1 x Mains Power Supply Unit (region speci_ic)
- 1 x 1.5m HDMI Cable

You will need

- •GameStickTM
- •TV with HDMI connection

Set up your dock

Pull both ends of the Dock to slide apart.

Insert GameStick so the micro USB is facing right and the HDMI port is facing the back of the dock.

Close the Dock.

Attach HDMI cable C to the GameStick through the opening in the back of the Dock.

Connect power adapter and press power on.'

Optional connectivity

USB Ports E – Use to increase memory capacity or to connect peripheral devices such as a keyboard or mouse.

SD Card Slot F – Insert SD card (up to 64GB) (not included).

Ethernet port G - Connect your Ethernet cable (not included) to the Ethernet port on the back of the Dock and ensure it is plugged in to your router.

Charging your controller

Place the controller on top of the dock so that the pins D align with those on the controller. When positioned correctly the LED strip on the front of the controller will start _lashing to indicate it is charging.

Need more help?

For more information and further support go to www.gamestick.tv/support Looking after your GameStick Dock

Whilst every precaution has been taken to ensure your safety every electrical device should be handled with care at all times and follow these guidelines Observe ALL warnings, precautions and instructions.

Always unplug your Dock and switch o_ power supply when not in use.

Store it in a cool, dust free area, out of direct sunlight.

Do not expose to extreme temperatures or direct sunlight for any length

of time. If the Dock becomes too hot to touch unplug it (including all cables) immediately and stop use.

Do not get the Dock or any cables wet. If you wish to clean the Controller please do so using a dry cloth. Do not expose to liquids, chemicals or _luids as these may damage your device.

Do not modify or attempt in any way to tamper with the Dock.

•

INDUSTRY CANADA NOTICES (IC):

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device

Avis d'Industrie Canada (IC):

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil

For warranty information please visit www.gamestick.tv/warranty

Android is a trademark of Google inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. Portions of this package are reproduced from work created and shared under the Creative Commons 3.0 Attribution licence. The Bluetooth word, mark and logos are all owned by Bluetooth SIG, Inc. HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing, LLC. © PlayJam Ltd. All rights reserved.

License Agreement

GameStick and third-party software license terms can be found at www.gamestick.tv Use of GameStick constitutes acceptance of as well as agreement to those license terms

Information in this document, including URL and other internet web site references, is subject to change without notice.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must be co - located for operating in conjunction with any other antenna or transmitter.