Free music

Warm Tips.

J. In order to svoid damage to your hearing and prolong the speaker to avoid damage to your hearing and prolong the speaker in high volume environment.

Z. Where is fault occurs, please immediately turn off the power switch, unplug the USB plug, prevent speaker and other components damaged.

3. Over use of battery will affect the Bluetooth distance and use-life, please charge in time.

7. Restore to factory settlings in Bluetooth connection mode, long press "M"key for 3 seconds, the blue light will blink rapidly, restoring the speaker to factory settlings.

Connect the Micro EP charging cable to speaker's Micro Connect the Micro EP charging cable to a EV Cannect the original conditions and will charge is reached.

5.Mode Switch(Bluetcooth-TF Card-AUX-FM)
When speaker is on with TF Card inserted, click "W' key to swit
ch to switch through different modes one by one in this order.
Bluetcooth-TF Card - FM - AUX - Bluetcoth
(FM Mode: Connecting the USB cable to be FM Antenna, long
press "play v pause" automatic search platform.Some items do
not have AUX, FM modes).

hang up. 3. When the Speaker is in standby /music mode, double press the "Play/Pause/Phone" key to re-dial the last call.

4.Hands free phone call operation

7.When a phone call is incoming, the blue light remains on.
Short press the "Play/Pause/Phone" key to answer;
long press the "Play/Pause/Phone" key to reject the call.

2. When on an active call, short press "Play/Pause/Phone" to

A fond press "Vol-/Previous sond", increase speaker volume and 5. long press "Vol-/Previous sond", increase speaker volume and 5. long press appear volume; and will hear a prompt when maximum volume is reached.

3. Short press "Vol+/Next song", the speaker will play the next

will resume playing music again;

2. Short press "Vol-/Previous song", the speaker will play the
previous song:

 Short press "Play/Pause/Phone"key to pause music or pause music to answer a call. A second short press second

3. When you play music

When pairing, the blue light will blink louickly; use cell phone or computer or other device search device name "A 10", click to connect, blue light turn off when connection out of range.

Follow the operating instructions of your Bluetooth device for pairing with the speaker. Typically this is done by going to the "Bluetooth", "Set Up'sr. "Connect" menu and selecting the option to search for Bluetooth devices.

2.Bluetooth Connection

TON/OFF

Slide ON/OFF switch to the right to power on. The blue light will come on. Slide ON/OFF switch to the left; the blue light will blink and the unit will power off.

Typi-Next song


3.TF Card Slot

5.Vol-/Next song

2.TVOH-Vext song

2.DV/OFF

2.DV/OFF



Function Keys:

DIM. I

A10 Minimalist Style Reflective Light B1-Speaker One Tower

Dear customer:


Thank you for purchasing A10 Mini Wireless Speaker, Please read this user guide carefully before operation and save these instructions for future reference.

Packaging included:

1. Portable Speaker ------ 1 p 2. Usb line (FM Antenna) ------- 1 pc 3. User manual ------ 1 pr

Features:

Active Suspension Lighting Effect Minimal Art Aluminum Anode Captivating sound. Glowing design Designed for modern life





Powerful Sound



56



Features:





Hands Free

Specifications:

- · Output Power: 3W
- · Discharge Current: 5V/0.5A
- · Battery: 300mah 3.7V
- Product Size:Ø71x42mm
- · Speaker Weight: 160g
- · Music Play Time: 1-2 hours
- · Speaker Output frequency range:150Hz-20KHz

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Shenzhen Minsuo Import & Export Co.Ltd

R