

Layer 3 Pantone Cool Gray 3 C						
Layer 2 Mechanical Dieline/Drawing - DO NOT PRINT						
Layer 1 Reference/Info DO NOT PRINT						
changes from last revis						
RevA: NEW ARTV	VORK					
PART COLOR:						
code	description			revision	_	
[iSP80]	Compliance	Compliance		REV B		
created		checked		date 0.4.4.0.004.7		
EMMA		Dan Morookian		04.10.2017		
product name / description ION Audio - Solar Stone		Class	Epoxy	Ink	scale	
ION Audio	- Solar Stone	GIOW	∟роху	IIIK	1:1	
Product Development Artwork Poless						

CONFIDENTIALITY NOTICE This document contains information/data that is confidential and the property of

all copies of the original document.

Numark Industries. Unless you are the intended recipient (or authorized to receive for the intended recipient), you may not read, print, retain, use, copy, distribute or disclose to anyone the message or any information contained in this document. If you have received the document in error, please advise the sender by reply e-mail, and destroy



Layer 3 Par	ntone Cool Gray 3	С			
Layer 2 Me	chanical Dieline/D	rawing - DO NO	T PRINT		
Layer 1 Ref	ference/Info DO	NOT PRINT			
PART COLOF	R:			revision	
[iSP80]	Compliance			REV B	
EMMA		Dan Moroo	kian	04.1	0.2017
product name / descrip	- Solar Stone	Glow	Epoxy	lnk	scale 1:1
Product Dev	elopment			Artwo	rk Relea

CONFIDENTIALITY NOTICE This document contains information/data that is confidential and the property of Numark Industries. Unless you are the intended recipient (or authorized to receive for the intended recipient), you may not read, print, retain, use, copy, distribute or disclose to anyone the message or any information contained in this document. If you have received the document in error, please advise the sender by reply e-mail, and destroy

all copies of the original document.



INSTRUCTIONS:

Connecting to 1 Solar Stone Glow (via Bluetooth):

- Power On Solar Stone Glow.
 Press the Bluetooth Connect button to enter Bluetooth Pairing Mode.
 Navigate to your Bluetooth device's settings menu, find "Solar Stone Glow",
- To disconnect Bluetooth link from the Solar Stone Glow, press and hold the Bluetooth button for 2 seconds.

Linking 2 Solar Stone Glow speakers for stereo sound:

- 1. Power on each Solar Stone Glow.

- If necessary, disconnect any Bluetooth devices that are currently connected,
 Press the Link button on both Solar Stone Glow speakers.
 Once the stereo link is confirmed, press the Bluetooth Connect
- button on the Left channel to enter Bluetooth Pairing Mode.
 5. On your Bluetooth device, navigate to your Bluetooth settings menu,
- 6. To disconnect the stereo link, hold the Link button on the left speaker for 3 seconds.

To enable or disable the voice prompts, press the Link and Bluetooth buttons simultaneously.



FOR MAX BATTERY LIFE:

- Expose unit to several hours of sunlight daily
 Fully charge the battery before using
 Fully charge the battery after each use
 It is okay to leave SOLAR STONE GLOW plugged in
 If the battery fails to charge, contact ION AUDIO






US Address: Ion Audio,LLC 200 Scenic View Dr. Cumberland,RI 02864

Harkortstr. 12-32 40880 Ratingen

Bluetooth®



CONFIDENTIALITY NOTICE This document contains information/data that is confidential and the property of Numark Industries. Unless you are the intended recipient (or authorized to receive for the intended recipient), you may not read, print, retain, use, copy, distribute or disclose to anyone the message or any information contained in this document. If you have received the document in error, please advise the sender by reply e-mail, and destroy

Epoxy Ink

Artwork Release

ION Audio - Solar Stone Glow

Product Development

all copies of the original document.



INSTRUCTIONS:

Connecting to 1 Solar Stone Glow (via Bluetooth):

- Power On Solar Stone Glow.
 Press the Bluetooth Connect button to enter Bluetooth Pairing Mode.
 Navigate to your Bluetooth device's settings menu, find "Solar Stone Glow",
- To disconnect Bluetooth link from the Solar Stone Glow, press and hold the Bluetooth button for 2 seconds.

Linking 2 Solar Stone Glow speakers for stereo sound:

- 1. Power on each Solar Stone Glow.
- If necessary, disconnect any Bluetooth devices that are currently connected,
 Press the Link button on both Solar Stone Glow speakers.
 Once the stereo link is confirmed, press the Bluetooth Connect
- button on the Left channel to enter Bluetooth Pairing Mode.
 5. On your Bluetooth device, navigate to your Bluetooth settings menu,

- 6. To disconnect the stereo link, hold the Link button on the left speaker for 3 seconds.

To enable or disable the voice prompts, press the Link and Bluetooth buttons simultaneously.



FOR MAX BATTERY LIFE:

- Expose unit to several hours of sunlight daily
 Fully charge the battery before using
 Fully charge the battery after each use
 It is okay to leave SOLAR STONE GLOW plugged in
 If the battery fails to charge, contact ION AUDIO






US Address: Ion Audio,LLC 200 Scenic View Dr. Cumberland,RI 02864

Harkortstr. 12-32 40880 Ratingen

Bluetooth®



PART COLOR:

ode	description		revision
[iSP80]	Compliance		REV B
reated		checked	date
EMMA		Dan Morookian	04.10.20

Epoxy Ink ION Audio - Solar Stone Glow

Product Development

Artwork Release

CONFIDENTIALITY NOTICE This document contains information/data that is confidential and the property of Numark Industries. Unless you are the intended recipient (or authorized to receive for the intended recipient), you may not read, print, retain, use, copy, distribute or disclose to anyone the message or any information contained in this document. If you have received the document in error, please advise the sender by reply e-mail, and destroy all copies of the original document.