User Manual

Vidonn

Wireless Bone Conduction Headphones

Model: Q2

Bone conduction wireless headphones+MP3

User guide

Specifications

Power output	750 mW
Headphones	10.8mm driver
Frequency response	250Hz~20KHz
Rechargeable Lithium-ion battery	3.7v, 175mA
Battery life	up to 3 hours
Charging time	approx. 1.5 hours
Weight	approx. 31g
Size	111mm(W)*120mm(L)*44mm(H)

Charge

- Charge the headphones with the included Micro USB charging cable, the USB output should be 5V, 0.5A or above, the headphones will be fully charged in approximately 1.5 hours.
- 2. The LED indicator is red while charging, it will turn into blue when the headphones are fully charged.
- 3. When the power is less than 30%, the LED indicator will flash red and then turn off automatically when power runs out.

Wearing

Hang the speaker on ears as follow, make the speaker close to ear.

Wireless mode:

1. Pairing:

While F1 is power off, press the Power on/off button for 3 seconds, the LED flashes red and blue alternately and there is voice prompt by the word "Pairing", the LED flash blue after paired.

Enter into pairing mode again:

Press and hold the Play/Pause button for 3 seconds while paired,

the LED flashes red and blue alternately, there is voice prompt by "Pairing", the LED flash blue after paired.

Note:

After paired, the headphones will pair with device automatically if the device's Bluetooth is on, if the headphones don't pair automatically, you may need to pair manually in device's "Settings-Bluetooth", choose "Q2".(This depends on the model of devices)

2. MP3 mode:

Single click the Power on/off button while power is on, enter into MP3 mode.

3. Instruction of buttons:

- 3.1 Press Volume + button to increase the volume.
- 3.2 Press Volume button to decrease the volume.
- 3.3 Press Play/Pause button once to play or pause the audio.
- 3.4 Press and hold Volume + button for 3 seconds to move one track backward.
- 3.5 Press and hold Volume button for 3 seconds to move one track forward.

Incoming calls

- 1. To answer an incoming call on your device, press the Play/Pause button once.
- 2. To ignore an incoming call on your device, press and hold the Play/Pause button for 3 seconds.
- 3. To end an active call on your device, press Play/Pause button once.

Note: The functions on controller box, includes Play/pause, Answer/Reject calls and switch etc support iOS and most android mobile devices.

Functions:

Button	Action	LED status	Voice prompt
Power on/off	Press and hold Power on/off button for 3 seconds(it enter into pairing mode automatically when turn on first time)	LED flash red and blue alternately	power on/power off
Switch mode	Single click Power on/off button while power is on	Wireless mode: blue MP3 mode: green	Pairing/MP3
Paired	/	Solid blue	Your device is connected
Pairing	Press and hold Play/Pause button for 3 seconds	LED flash red and blue alternately	Pairing

Play/Pause	Single click Play/Pause button	Wireless mode: Play: blue breathing light Pause: solid blue MP3 mode: Play: green breathing light Pause: solid green	
Answer/End call	Single click Play/Pause button	/	
Reject call	Press and hold the Play/Pause button for 3 seconds	/	
Increase	Single click	/	
volume	Volume+ button	,	-
Decrease volume	Single click Volume- button	/	There is one beep if reach maximum
Next song	Press and hold Volume + button for 3 seconds	/	
Previous song	Press and hold volume – button for 3 seconds	/	/
Prompt tone language switch	Click volume + and volume - button once simultaneously while power is on	/	
Low power alert	/		Prompt"Battery low, please charge"
Charging	/	Solid red	/

Charging	/	LED off	/
completed			
Connect to	connect the	Solid blue and	/
PC/laptop	controller with	green	
	PC/laptop by		
	USB data cable		
	while power off,		
	press and hold		
	the Power		
	on/off button		
	for 3 seconds,		
	and the PC		
	display		
	"removable		
	disk"		

Warning

To ensure the normal use of the product, please be sure to observe the following safety precautions

- 1. Do not use the headphones while showering or bathing.
- 2. Do not place this product where it may fall into (or be drawn into) a bathtub or a water basin.
- 3 Do not put this product into or immerse into water or other liquids.
- 4. When the headphones fall into the water, do not rush to remove them by hand. Disconnect the headphones' power supply immediately.
- 5. Be careful not to get objects hit the headphones or Do not splash the liquid into the earphone.
- 6 Use this unit only for its intended use as described in this manual.

- 7. Never drop or insert an object into any opening.
- 8. Protect the power cord from being walked on or pinched, particularly at plug outlets, convenience receptacles and the point where is exits the unit.
- 9. Do not allow cord to touch hot surfaces, wrap cord loosely around the unit when storing.
- 10. The unit should be situated away from direct sunlight or heat sources such as radiators, electric heaters, heat registers, stoves, or other units(including amplifiers) that produce heat. Avoid placing on top of stereo equipment that radiates heat.
- 11. Do not overload the electrical outlet. Use only the power source as indicated.
- 12. Don not carry this unit by its cord or use the cord as a handle.
- 13. Never operate this unit if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. If the unit's power supply cord or plug is damaged, do not attempt to fix it yourself.
- 14. To avoid the risk of electric shock, do not disassemble or attempt to repair the unit. Incorrect repair can cause risk of electric shock or injury to persons when the unit is used.

Lithium-polymer battery warnings

This device contains a Lithium-Polymer battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

Use only the supplied cable to recharge the battery. Improper charging may damage the battery and the device.

Do not attempt to open the rechargeable battery or battery pack. There are no serviceable parts inside.

Keep the battery out of reach of children. If swallowed, consult a physician immediately.

Do not dispose of battery in a fire as it may explode. The battery may also explode if damaged.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.