
# Welcome Guide

Arisen Dawn

Bedienungsanleitung | 取扱説明書 | Guide d'Utilisation Manuale dell'Utente | Manual de Instrucciones 使用说明书 | دليل الترحيب



# **Using Your Dawn**

Verwenden Sie Ihre Dawn | Dawn の使用方法 Utilisation de vos Dawn | Usare le tue Dawn Usar Tus Dawn | Dawn 使用方法 Dawn

#### Turn them on

Schalten Sie sie ein | 電源を入れる | Allumez-les Accendile | Enciéndelas | 开启耳机 | اعمد إلى تشغيلها

### · Pair them with your device


Pairen Sie sie mit Ihrem Gerät | お使いの機器とペアリング Jumelez-les avec votre appareil Sincronizzale con il tuo dispositivo Emparéjalas a tu dispositivo | 和你的设备配对 اعد إلى إثر إنها مع الجهاز






# Wear your Dawn

Tragen Sie Ihre Dawn | Dawn の装着方法 Mettez vos Dawn | Indossa le tue Dawn Ponte tus Dawn | 佩戴耳机 | Dawn



# Charge your Dawn

Ihren Dawn aufladen | Dawn 本体の充電 Chargez votre Dawn | Ricarica il tuo Dawn Carga tu Dawn | 给 Dawn 充电 | Dawn



**▶** 4

# Controls

Steuerung | 操作方法 | Contrôles | Comandi Controles | 操作方法 | をしている。



#### Play / Pause

Play / Pause | 再生 / 一時停止 Lecture / Pause | Play / Pausa Reproducir / Pausa | 播放 / 暂停 تشغيل / إيقاف تشغيل مؤقت

#### Double Click

Zweimal drücken

ダブルクリック

Double-clic

Doppio click

Hacer Doble Clic

按两次 | さず はず は 対 対 対 対

#### Re-Dialing

Wahlwiederholung

リダイアル

Num é rotation

Discado

Composizione

重播 डायलन



Pairing mode Pairing-Modus ペアリングモード Mode jumelage Modalità accoppiamento Modo emparejamiento 配对模式

#### Press and hold for 1 second

Eine Sekunde gedrückt halten

1秒間長押し

Pressez pendant 1 seconde

Premi per 1 secondo

Presionar y mantener 1 segundo

按住并保持1秒

الضغط باستمرار لمدة ثانية



#### Answer / end call

Anruf annehmen / beenden 電話に出る / 終了 | Décrocher / Raccrocher Rispondi / chiudi la chiamata Responder / terminar llamada 接听 / 挂断 | الرد على المكالمة / إنهاء المكالمة

#### Press and hold for 1 second

Eine Sekunde gedrückt halten

1秒間長押し

Pressez pendant 1 seconde

Premi per 1 secondo

Presionar y mantener 1 segundo

按住并保持1秒

الضغط باستمرار لمدة ثانية

#### Reject call

Anruf ablehnen

着信を拒否

Rejeter un appel

Rifiuta la chiamata

Rechazar Ilamada

拒接来电

رفض المكالمة



#### Press

Drücken | クリック | Pressez | Premi

Presionar | 按一下 | Idinated

# Put current call on hold and answer incoming call

Aktuellen Anruf halten und ankommenden Anruf annehmen

通話を保留し、新規着信に出る

Mettre l'appel en cours en attente et répondre à l'autre appel entrant

Metti la chiamata corrente in attesa e rispondi alla chiamata in arrivo

Poner llamada en espera y responder llamada en entrada

保留当前通话并接听新的來电

تعليق المكالمة الحالية والرد على المكالمة الواردة



#### Volume up / down

Lautstärke hoch / runter | 音量アップ / ダウン Augmenter / Baisser le volume Aumenta / abbassa il volume Subir / bajar volumen | 音量调高 / 调低

رفع مستوى الصوت / خفضه

#### Press and hold for 1 second

Eine Sekunde gedrückt halten 1秒間長押し

Pressez pendant 1 seconde

Premi per 1 secondo

Presionar y mantener 1 segundo

按住并保持1秒

الضغط باستمرار لمدة ثانية

#### Skip Forward

Nächster Titel 次の曲 Saut Avant Brano successivo 下一曲

Próxima Pista

تخطي إلى الأمام

## **LED Indicator Guide**

LED-Indikator Erklärung | LED表示の説明 Guide de l'indicateur LED | Guida segnali dell'indicatore LED Guía de Indicador LED | LED指示灯说明 | LED



#### Flashing blue

Blau blinkend | 青の点滅 | Voyant bleu clignotant Blu lampeggiante | Azul intermitente 蓝色LED闪烁 | الوموض باللون الأزرق

#### Powered on / Incoming call

Eingeschaltet / Eingehender Anruf 電源オン / 着信 | Allumé / Appel entrant Acceso / Chiamata in arrivo Encendido / Llamada entrante 开机 / 来电 | قد التشغيل / مكالمة واردة



#### Rapidly flashing blue

#### Pairing mode

Pairing-Modus | ペアリングモード | Mode jumelage Modalità sincronizzazione | Modo emparejamiento 配对模式 | وضع الإقران



#### Flashing red

Rot blinkend | 赤の点滅 | Voyant rouge clignotant Rosso lampeggiante | Rojo intermitente 红色LED闪烁 | الوميض باللون الأحمر

#### Low power

Niedriger Energiestand | パッテリー残量低 Batterie faible | Bassa carica residua | Batería baja 电量低 | طفة منخفضة

#### Steady red

Durchgehend rot | 赤の点灯 | Voyant rouge fixe Rosso fisso | Rojo fijo | 红色LED常亮 | أحمر ثابت

#### Charging

Ladend | 充電中 | En charge | In carica Cargando | 充电中 | قيد الشحن

Steady blue Durchgehend blau 青色ライトの点灯 Voyant bleu fixe Blu fisso Azul fijo 蓝色LED常亮

إضاءة ثابتة باللون الأزرق

#### Fully charged

Voll geladen | 満充電 | Charge complète Carica completa | Carga completa كم الشحن بالكامل | 充满电



#### Having connection problems? Remove Dawnfrom your device's Bluetooth history, ensure they are less than 3 feet away then try pairing again.

Sie haben Verbindungsprobleme? Löschen Sie die Dawn aus dem Bluetooth-Verlauf Ihres Geräts, stellen Sie sicher, dass diese weniger als 90 cm von Ihrem Gerät entfernt sind und wiederholen Sie den Pairingvorgang.

ペアリングが出来ない場合、ペアリングの履歴を一度削除し、お使いの機器と Dawn の距離が90cm以内であることを確認した上で、再度ペアリングを行って下さい。

Vous avez des problèmes de connexion ? Supprimez les écouteurs Dawn des périphériques Bluetooth enregistrés sur votre appareil, assurez-vous qu'ils sont à moins d'un mètre de celui-ci et réessayez.

Problemi di connessione? Rimuovi le Dawn dalla cronologia bluetooth del dispositivo. Assicurati che siano a meno di un metro di distanza dal dispositivo e riprova.

¿Problemas de conexión? Elimina tus Dawn del registro de conexión Bluetooth de tu dispositivo, acércalos a menos de 90 cm del dispositivo y empareja de nuevo.

连接不上?删除 Dawn 的配对记录,确保 Dawn 和设备距离不超1米再尝试配对。

هل تعاني من مشاكل بالاتصال؟ أزل سماعات Dawn عن سجل Dawn على جهازك، واحرص على أن تكون على بُعد 3 أقدام على الأقل، ثم حاول الإفران مرة أخرى.

# **Specifications**

Spezifikationen | 製品の仕様 | Spécifications | Specifiche Especificaciones | 产品参数 | المواصفات

Input	5 V / 0.1 A
Range	20 m / 66 ft
<b>∕kG</b> Weight	14 g / 0.5 oz
Size	31 × 25 × 17 mm 1.2 × 1 × 0.7 in

#### Attention

Achtung | 注意 | Attention | Attenzione | Atención 注意 | نحنیرات



#### Use original or certified cables

Verwenden Sie originale oder zertifizierte Kabel 純正または認証されたケーブルをご使用下さい N'utiliser que des câbles originaux ou certifiés Usare cavi originali e/o certificati Usar cables originales y/o certificados 使用原装或者通过认证的线材 ستخدم と



#### Don't expose to liquids

Setzen Sie das Gerät keinen Flüssigkeiten aus 水分に触れないようにして下さい Ne pas exposer à des liquides Evitare il contatto con liquidi Evitar el contacto con líquidos 请勿接触液体 | ビューレッチを



#### Don't disassemble

Nehmen Sie das Gerät nicht auseinander 危険ですので分解しないで下さい Ne pas désassembler | Non smontare No desarmar | 请勿拆卸 | ビューリー



#### Avoid dropping

Lassen Sie das Gerät nicht fallen 過度な衝撃を与えないで下さい Eviter de le faire tomber Non farlo cadere Evitar caídas 避免跌落产品 ではいいである。



#### Avoid extreme temperatures

Vermeiden Sie extreme Temperaturen 極端な温度下では使用しないで下さい Eviter les températures extrêmes Tenere lontano da temperature estreme Mantener alejado de temperaturas extremas 避免在过高或过低温环境使用

تجنب الحرارة المرتفعة

#### **FCC Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio / TV technician for help.

### **RF Warning Statement**

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

# **Customer Service**

Kundenservice | カスタマーサポート | Service Client Servizio ai Clienti | Atención al Cliente | 客服支持 | خدمة العملاء



#### 12-month limited warranty

12 Monate beschränkte Herstellergarantie 12ヶ月保証 | Garantie de 12 mois Garanzia limitata 12 mesi Garantía limitada de 12 meses 12个月质保期 | ضمانة 12 شهراً محدودة



#### Lifetime technical support

Lebenslanger technischer Support テクニカルサポート | Support technique à vie Supporto tecnico a vita Asistencia técnica de por vida 终身客服支持 | الدعم الفني مدى الحياة

support@airsen-tech.com

# For FAQs and more information, please visit:





MAKING SUPERB TECHNOLOGY ACCESSIBLE TO EVERYONE

Product Number W7 Arisen WindBuds