Using Your Selfie Stick Wie Sie Ihren Selfie Stick verwenden

白揚り椿の使い方 Utilisation de Votre Selfie Stick Utilizzare la tua Asta per Selfie Usar tu Selfie Stick

1. Turn it on

Welcome Guide Allumez-le Bluetooth Selfie Stick



使用自拍杆

Schalten Sie ihn ein 電源を入れます Accendila Enciéndelo



2. Pair it with your phone via Bluetooth

Pairen Sie ihn via Bluetooth mit Ihrem Smartphone

スマートフォンとBluetoothペアリングします Connectez-le à votre téléphone via Bluetooth

Sincronizzala al tuo telefono via Bluetooth Emparéialo a tu teléfono mediante Bluetooth 通过蓝牙和你的手机配对



3. Slide your phone into the cradle

Schieben Sie Ihr Smartphone in die Halterung スマートフォンをマウントに取り付けます Glissez votre téléphone dans le support Riponi il tuo telefono nel supporto Desliza el teléfono hacia el interior del soporte 将手机安装在支架中

4. Adjust cradle position

Passen Sie die Halterung an マウントの位置を調節します Ajustez la position du support Regola la posizione del supporto Coloca el soporte en posición 调节支架的位置



5. Open your phone's camera

Öffnen Sie die Kamera Ihres Smartphones スマートフォンのカメラを起動します Allumez l'appareil photo de votre téléphone Apri la fotocamera sul tuo telefono Accede a la cámara de tu teléfono 打开手机的相机

6. Take a selfie

Machen Sie ein Selfie ご自身を撮影します Prenez un selfie Scatta un selfie Haz una selfie 开始自拍



1 Ensure your phone and the cradle are fully secure before use.

Achten Sie darauf, dass vor der Nutzung Ihr Smartphone und die Halterung sicher fixiert sind.

で使用前にお使いのスマートフォンとマ ウントが正常に動作するか確認して下


Assurez-vous que le téléphone est bien attaché avant chaque utilisation. Assicurati che il telefono e il supporto siano ben assicurati prima dell'utilizzo.

Antes de suar, asegúrate que tu teléfono y el soporte estén firmes. 使用前请确保手机和支架完全安全。

Charging Your Selfie Stick

Wie Sie Ihren Selfie Stick laden 白揚り棒太体の充電方法 Chargement de Votre Selfie Stick Mettere in carica la tua Asta per Selfie Cargar tu Selfie Stick 给自拍杆充电





▶ 5

For FAQs and more information please visit:

Bedienungsanleitung | 取扱説明書 Guide d'Utilisation | Manuale dell'Utente Manual de Instrucciones | 使用说明书



anker.com/support









Specifications

Spezifikationen 製品の仕様 Spécifications Specifiche Especificaciones 产品参数

لسننسا	Size (when retracted)	18.8 × 5 × 3.5 cn / 7.4 × 2 × 1.4 ir
₩	Length (when extended)	73 cm / 28.7 in
KG	Weight	136 g / 4.8 oz
	Input	5 V / 0.1 A
	Runtime	20 h

▶ 7

Attention

Achtung | 注意 | Attention Attenzione | Atención | 注意



To preserve battery lifespan, use and recharge at least once every 4 months

Bitte verwenden und laden Sie den Akku mindestens alle 4 Monate um die Lebensdauer zu erhalten バッテリーの寿命を長く保つために、少 なくとも4ヶ月に一度使用および満充電し て下さい

Pour préserver la durée de vie de la batterie, utilisez et rechargez-la au moins une fois tous les 4 mois Per mantenere la durata della vita della batteria, utilizzarla e ricaricarla almeno una volta ogni 4 mesi

Para prolongar la vida útil de la batería, usar v recargar al menos una vez cada 4 meses

为保证电池使用寿命,请每四个月至少使 用和给产品充由一次

Use original or certified cables

Verwenden Sie originale oder zertifizierte Kabel 純正または認証されたケーブルをご使用

下さい N'utiliser que des câbles originaux ou certifiés

Usare cavi originali e/o certificati Usar cables originales y/o certificados 使用原装或者通过认证的线材



Don't expose to liquids

水分に触れないようにして下さい Ne pas exposer à des liquides Evitare il contatto con liquidi Evitar el contacto con líquidos 请勿接触液体



▶ 8

Don't disassemble

Nicht auseinander nehmen 危険ですので分解しないで下さい Ne pas désassemble Non smontare No desarmar 请勿拆卸



過度な衝撃を与えないで下さい Ne pas faire tomber Non farlo cadere Evitar caídas



Avoid extreme temperatures

Extreme Temperaturen vermeiden 極端な温度下では使用しないで下さい Eviter les températures extrêmes Mantenere Iontano da temperature estreme Mantener alejado de temperaturas

extremas



Avoid dropping Nicht fallen lassen

避免跌落产品



避免在过高或过低温环境使用

▶ 10

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2 this device must accept any interference received including interference that may cause undesired

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful. interference to radio communications. However, the no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measur (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio / TV technician for help.



The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Customer Service

Kundenservice | カスタマーサポート Service Client | Servizio ai Clienti Atención al Cliente | 客服支持



18-month limited warranty 18 Monate heschränkte Herstellergarantie

18ヶ月保証 Garantie limitée de 18 mois Garanzia limitata 18 mesi Garantía limitada de 18 meses 18个月质保期



\ Lifetime technical support

Lebenslanger technischer Support テクニカルサポート Support technique à vie Supporto tecnico a vita Asistencia técnica de por vida 终身客服支持





1-800-988-7973 | Mon-Fri 9:00-5:00 PST (US) 03-4455-7823 | Mon-Fri 9:00-17:00 (日本) 069-9579-7960 | Mon-Fri 6:00-11:00 (DE) 400-0550-036 | Mon-Fri 9:00-17:30 (中国)

▶ 12

11