



Halo Owner's Manual


© Anker Technology Co., Limited. All rights reserved. ZOLO and the ZOLO logo are trademarks of Anker Technology Co., Limited, registered in the United States and other countries. All other trademarks are the property of their respective owners. Model No.: Z6000

51005000682 V01



At a Glance





① **+** / **-**

Press to increase/decrease volume.

② 🔊

- · Press to play/pause.
- Press twice to skip to next track.

3 🐉

• Press to mute/unmute the microphone.

• Long press for 8 seconds to restore factory settings.

4 LED ring

· Blue/Cyan alternatively breathing: Booting.

Yellow dot traveling: Wi-Fi setup.

• Blue ring light on and fade out: Wi-Fi connected.

Cyan dot rotating: Alexa waking up.

Cyan ring breathing: Alexa listening.Cyan dot traveling: Alexa thinking.

Cyan/Blue ring breathing: Alexa talking.White partially light on: Volume adjusting.

Green ring breathing: Alarm/Timer ringing.

⑤ Alexa button

- Press to start/stop voice control.
- Press to turn off the alarm/timer.

3

- Long press for 3 seconds to enter Bluetooth pairing mode.
 Control calls when Bluetooth paired.
- (7) Power LED
- 8 3.5mm AUX line-out socket
- Power socket

01 English











Connecting to Power Supply

Plug the supplied power adaptor into Zolo Halo and then into a power outlet.

 \blacktriangleright Zolo Halo will automatically turn on and the power LED will light on.

Downloading the Zolo Play App

What you need:

- A Wi-Fi router supporting the 2.4 GHz and 8O2.11 b/g/n bands; 5 GHz band not supported.
- A smartphone or tablet connected to a Wi-Fi network.
- A smartphone or tablet running iOS 9.0 (or above) or Android 6.0 (or above).

Download the free app from the App Store (iOS devices) or Google Play (Android devices).

Setting up

Run the Zolo Play app, tap [Add Device] or "+" on "DEVICE LIST" to start Wi-Fi setup. Always follow the instructions in the app to complete Wi-Fi setup.



* (Wi-Fi name) varies when connecting to a different Wi-Fi network.



03 English English 04

Talking to Zolo Halo

You can talk to Amazon Alexa on your Zolo Halo. With Alexa, you can ask to play music, hear the news, check weather, control smart home devices, and more.

① From the home page of Zolo Play app, tap [Amazon Alexa]. Sign in with your Amazon account to use Alexa voice control. If you do not have an Amazon account, create a new one.

2 Always say the wake up word "Alexa" first and then your request.

- ➤ Zolo Halo will respond instantly.
- ➤ To learn what are proper commands to ask Alexa, see the "Things to Try" instructions at the end of this manual.
- ➤ To explore more Things to Try with Alexa, go to www.amazon.com/MeetAlexa and download the Amazon Alexa app on your iOS or Android device.


Online Resources

To enjoy various music services in Zolo Play App, go to the home page, select from the listed services and do as the instructions.

Multi-room Mode Playback

Go to the "DEVICE LIST" page in Zolo Play app, follow the instructions to switch between multi-room mode and solo mode.





Connecting to an External Speaker

You can connect Zolo to an external speaker with a 3.5mm AUX cable (not supplied).



For best performance, make sure the external speaker is placed as far away from Zolo Halo as possible.

Bluetooth Pairing

With Zolo Halo, you can enjoy audio and make calls from Bluetooth-enabled devices.

- 1) Long Press % for 3 seconds to enter Bluetooth pairing mode.
- ➤ The white Bluetooth indicator flashes quickly.
- ② Enable Bluetooth on your device and select **[Zolo Halo]** to start pairing and connection.

➤ The white Bluetooth indicator lights on constantly.

05 English English 06

Specifications



Specifications are subject to change without notice.

Input: 9 V -- 1.5 A

Rated power consumption: 5 W

Power adaptor rating: Input: 100-240 V_{\sim} , 50-60 Hz; Output: 9V == 1.5 A

Impedance: 4 Ω

Driver: 1.75"

Frequency response: $60~\mathrm{Hz}$ - $20~\mathrm{KHz}$

Wi-Fi network compatibility: IEEE 8O2.11 b/g/n Bluetooth version: V4 2

Bluetooth range: 10 m / 33 ft

Weight: 318 g / 11.2 oz

Troubleshooting

- 1) Zolo Halo does not respond.
 - Use the supplied adaptor to connect it to a power supply.
 - Press the Alexa button to see if Zolo Halo responds to your requests.
- 2 Zolo Halo cannot connect to my Wi-Fi network.
 - Replug in the adaptor to restart. Follow the instructions in the app to complete Wi-Fi setup.
- 3 There is no response after I give voice commands.
 - Make sure you have set up a Wi-Fi connection between Zolo Halo and your device.
 - Check whether you use the proper commands when talking to Alexa. Always say the
 wake up word "Alexa" first when making any request. For details, see the "Things to
 Try" instructions at the end of this manual.
 - · Repeat your question. Speak naturally and clearly in English.
 - Make sure Zolo Halo is at least 8 inches away from walls or other objects that may cause interference (such as microwaye ovens).
- Check whether there are any Internet connection problems.
- Check whether you have muted the microphone on Zolo Halo.
- ④ When using services provided by third parties (such as listening to music, controlling smart devices, etc.), a voice prompt will ask me to loain to its account and get authorization from

07 English English 08

the third party. What should I do?

 Download and run the Alexa app, and then log in to your Amazon account. Find "Skills" from the menu, search for your desired skill, and then follow the on-screen instructions to enable the skill.

⑤ Do I need to upgrade the software of Zolo Halo manually?

No. It will automatically upgrade when new version is detected. When upgrading, you
will see orange LED ring breathing, please do not operate.



Things to Try | Dinge ausprobieren | Trucs à essayer | Sezioni da scoprire Cosas que probar | 実践項目 | الخِرات التي يمكك تجريتها

Music | Musik | Musique | Musica | Música | 音楽 | الموسيقى

- Alexa, play music.
 Alexa, shuffle my Dinner Party playlist.
- Alexa, what song is this?

Shows, Podcasts & Radio | Shows, Podcasts und Radio | Émissions, podcasts et radio Spettacoli, podcast e radio | Programas de televisión, podcasts y radio 番紙、Podcast、ラジオ | العروض بدوالشرات صوتانه والرابط ا

- Alexa, play the program Radiolab.
- Alexa, play the program Radiolal
 Alexa, play FSPN radio.

Alarms & Timers | Wecker und Timer | Alarmes et minuteries | Allarmi e timer Alarmas y temporizadores | アラームとタイマー | السنبيات والموقات |

- Alexa, set an alarm for 7 a.m.
- Alexa, set a timer for 45 minutes.

- · Alexa, show me coffee.
- Alexa, order dog food.

Questions & Answers | Fragen und Antworten | Questions et réponses | Domande e risposte Preguntas y respuestas | نشلة والورية | الشلة والورية ا

- Alexa, tell me a joke.
- · Alexa, Wikipedia Abraham Lincoln.

News, Weather & Traffic | Nachrichten, Wetter und Verkehr

Actualités, météo et infos trafic | Notizie, meteo e traffico | Noticias, el tiempo y el tráfico ニュース、天気、交通情報 | الأخبار، والأموال الجوية، وحركة المرور ا

- * Customize these features in the Alexa App. | Diese Funktionen in der Alexa-App anpassen Personnalisez ces fonctionnalités dans l'application Alexa. | Personalizzare le caratteristiche dall'app Alexa. | Personalice estas funcionalidades en la aplicación Alexa. | これらの機能は Alexa アプリでカスタマイズできます。 | Alexa にも はは、これらの機能は Alexa アプリでカスタマイズできます。 | Alexa といっと はないしょう はいましま はいましま (Alexa アプリアカスタマイズできます。) Alexa という はいましま (Alexa アプリアカスタマイズできます。) Alexa という はいましま (Alexa Proposition Alexa Pro
 - Alexa, play my Flash Briefina.
 - Alexa, What's the weather?
 - Alexa, how is my commute looking?

* Control supported smart home devices like Philips Hue Lights with Zolo Halo. To get started, go to the Alexa App. | Unterstützte Smart Home-Geröte wie Philips Hue Lights mit Zolo Halo steuern. Öffnen Sie die Alexa-App. um loszulegen. | Appareils Smart Home avec contrôle vocal, notamment Philips Hue Lights d'Alexa. Pour commencer, rendez-vous sur l'application Alexa. | Controlla i dispositivi smart home supportati come le luci Philips Hue con Zolo Halo. Per iniziare, accedere all'app Alexa App. | Controlle dispositivos de hogar intelligente

compatibles como bombillas Philips Hue con Zolo Halo. Para empezar, vaya a la aplicación Alexa. | Zolo Holo では、制御に対応した Philips Hue 照明などのスマートホームデバイスを制御できます。開 始するには、Alexa アプリに移動してください。| Alexa に للحد، العقل الى تطليق Philips Hue Lights و السلة Zolo Halo المنافعة المدعومة مثل

- Alexa, dim Hue Lights to 30%.
 Alexa, turn on the fan.
- Use These Anytime | Immer verwenden | Utilisez-les à tout moment | Scegli sempre Utilicelos en cualquier momento | これらはいつでも使用できます | تور یا یف شرایها الفروخیسا
 - Alexa, stop.
 - Alexa, volume five.



Important Safety Information

- Avoid dropping.
 Do not disassemble.
- · Do not submerae in water.
- Do not submerge in water.
- \cdot This product is exclusive for indoor use only.
- \cdot The product shall not be exposed to dripping or splashing water.
- Do not install near any heat sources.
- · Do not place any sources of danger on this device (e.g. liquid filled objects, lighted candles).
- · Use original power adaptor only.
- · Clean with a dry, soft lint-free cloth. Do not use any corrosive cleaner or oil.
- · To avoid hearing damage, do not listen for extended periods at high volume.

Notice



Declaration of Conformity

This product complies with the radio interference requirements of the European Community. Hereby, Anker Technology Co., Limited declares that the radio equipment type Z6000 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://zoloaudio.com

BT Maximum output power: 4.5 dBm; Wi-Fi Maximum output power: 15 dBm

BT Frequency band: 2.4G band (2.4O2GHz-2.48OGHz) Wi-Fi Frequency band: (2.412GHz-2.462GHz)

English 1

© Anker Technology Co., Limited. All rights reserved. ZOLO and the ZOLO logo are trademarks of Anker Technology Co., Limited, registered in the United States and other countries. Model: Z6OOO

51005000683 VOI





This product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Follow local rules and never dispose of the product and rechargeable batteries with normal household waste. Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human health.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received. including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

(1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

2 English

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This device is acting as slave and operating the 2.4GHz (2412-2462 MHz) band. Ad Hoc function is supported but not able to operate on non-US frequencies.

Trademark



amazon alexa

Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.

Google Play and the Google Play logo are trademarks of Google Inc.

"Android" is a registered trademark of Google Inc. in the United States and other countries.

"iOS" is a registered trademark of Apple Inc. in the United States and other countries.



The Wi-Fi CERTIFIED® Logo is a certification mark of Wi-Fi Alliance®.

63 Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Anker Technology Co., Limited. is under license.

English 3



The Spotify Software is subject to third party licenses found here: www.spotify.com/connect/third-party-licenses

Other trademarks and trade names are those of their respective owners.

Customer Service



12-Month Limited Warranty



6-Month Extended Warranty



Lifetime Technical Support

* Additional Legal Rights for Consumers

For consumers, who are covered by consumer protection laws or regulations in their country of purchase or, if different, their country of residence, the benefits conferred by Zolo's Limited Warranty are in addition to all rights and remedies conveyed by such consumer protection laws and regulations, including but not limited to these additional rights.

For FAQs and more information, please visit https://zoloaudio.com.

Anker Technology Co., Limited Room 1318-19, Hollywood Plaza, 610 Nathan Road, Mongkok, Kowloon, Hongkong

Wichtige Sicherheitsinformationen

- Nicht fallenlassen.
- · Nicht zerlegen.
- · Nicht in Wasser tauchen.
- · Dieses Produkt darf ausschließlich in Innenbereichen verwendet werden.
- · Das Produkt keinen Flüssigkeitstropfen oder -spritzern aussetzen.
- · Nicht in der Nähe von Wärmequellen installieren.
- Stellen Sie keine möglichen Gefahrenquellen auf dieses Gerät (z. B. mit einer Flüssigkeit gefüllte Gegenstände, brennende Kerzen usw.).
- · Nur den Original-Netzadapter verwenden.
- · Mit einem trockenen, weichen, fusselfreien Tuch reinigen. Weder scharfe Reinigungsmittel noch Öl verwenden.
- · Zur Vermeidung von Gehörschäden nicht über längere Zeiträume bei hoher Lautstärke verwenden.

Hinweis



Dieses Produkt entspricht den EU-Bestimmungen zur Störfestigkeit.



Dieses Produkt ist mit hochwertigen Materialien und Komponenten für Recycling und Wiederverwertung konzipiert.

4 English Deutsch 5





Dieses Symbol bedeutet, dass das Produkt nicht als Hausmüll entsorat werden darf, sondern einer angemessenen Sammelstelle für das Recycling zugeführt werden muss. Beachten Sie die örtlichen Bestimmungen und entsorgen Sie das Produkt und die Akkus nicht im normalen Hausmüll, Durch die ordnungsgemäße Entsorgung von Altprodukten und Akkus tragen Sie zur Vermeidung von Umwelt- und Gesundheitsschäden bei.

Kundenservice



12 Monate eingeschränkte Garantie



6 Monate verlängerte Garantie



Technischer Support für die Produktlebensdauer

* Weitere Verbraucherrechte

Für Kunden, die durch Verbraucherschutzgesetze oder -bestimmungen im Land des Kaufs bzw. im Land ihres Wohnsitzes geschützt sind, verstehen sich die durch die eingeschränkte Garantie von Zolo gewährten Vorteile zusätzlich zu allen Rechten und Rechtsbehelfen unter den einschlägigen Verbraucherschutzgesetze und -bestimmungen, einschließlich, iedoch nicht beschränkt auf, diese zusätzlichen Rechte,

Antworten auf häufig gestellte Fragen und weitere Informationen finden Sie unter https://zologudio.com.

Informations importantes de sécurité

- Ne pas faire tomber.
- · Ne pas démonter.
- · Ne pas immerger dans l'eau.
- · Ce produit est destiné exclusivement à une utilisation en intérieur
- · Le produit ne doit pas entrer en contact avec des gouttes ou des éclaboussures.
- · Ne pas installer près d'une source de chaleur.
- · Ne placez rien de dangereux sur cet appareil (par exemple, objets remplis de liquide ou bougies allumées).
- Utiliser uniquement l'adaptateur d'alimentation d'origine.
- · Nettover à sec avec un chiffon doux non pelucheux. Ne pas utiliser de nettovant corrosif ni d'huile.
- · Pour éviter tout dommage de l'audition, ne pas écouter à un volume élevé pendant une période prolongée.

Avis



Ce produit est conforme aux exigences en matière d'interférences radio de la Communauté européenne.



Ce produit a été conçu et fabriqué avec des matériaux et composants de haute qualité, qui peuvent être recyclés et réutilisés.



Ce symbole signifie que le produit ne doit pas être jeté avec les déchets ménagers, mais doit être transmis à un établissement de collecte adapté pour permettre son recyclage. Respecter les rèales de votre collectivité et ne jamais jeter le produit et les batteries rechargeables avec les déchets ménagers. La mise au rebut appropriée des produits et des batteries rechargeables usagés contribue à réduire les conséquences négatives pour l'environnement et la santé humaine.

6 Deutsch Français 7



Service client

Garantie limitée de 12 mois



Garantie prolongée de 6 mois



Assistance technique à vie

* Droits supplémentaires du consommateur

Pour les consommateurs qui sont couverts par des lois ou règlements de protection des consommateurs dans leur pays d'achat ou, s'il s'agit d'un autre pays, dans leur pays de résidence, les avantages conférés par la garantie limitée de Zolo s'ajoutent à tous les droits et recours prévus par lesdits lois et règlements de protection des consommateurs, y compris mais sans pour autant s'y limiter, les présents droits supplémentaires.

Pour plus d'informations et afin de consulter la FAQ, veuillez vous rendre à l'adresse : https://zoloaudio.com.

Informazioni importanti sulla sicurezza

- Non fare cadere il prodotto.
- Non smontare il prodotto.
- · Non immergere il prodotto in acqua.
- · Questo prodotto è destinato esclusivamente per uso in ambienti interni.
- Non esporre il prodotto a schizzi o aocciolamenti.
- Non posizionare vicino a fonti di calore.
- · Non posizionare eventuali fonti di pericolo su questo dispositivo (per esempio, aggetti contenenti liquido, candele accese).
- Utilizzare solo l'adattatore di alimentazione originale.
- · Pulire con un panno asciutto e morbido. Non usare detergenti corrosivi o olio.
- · Per evitare danni acustici, l'ascolto non deve avvenire a livelli di volume alti per lunahi periodi.

Attenzione



Il prodotto rispetta i requisiti relativi alle perturbazioni radioelettriche della Comunità Europea.



Il prodotto è progettato e realizzato con materiali e componenti di alta qualità, riciclabili e

Italiano 9 8 Français





Questo simbolo indica che il prodotto non deve essere smaltito tra i rifiuti domestici e deve essere consegnato presso un centro di raccolta per il riciclo. Seguire le normative locali e non smaltire il prodotto e le batterie ricaricabili tra i rifiuti domestici. Il corretto smaltimento dei prodotti usurati e delle batterie ricaricabili scariche aluterà a prevenire potenziali conseguenze negative sull'ambiente e sulla salute umana.

Servizio clienti



Garanzia limitata di 12 mesi



Garanzia estesa di 6 mesi



Supporto tecnico per l'intero ciclo di vita

* Diritti aggiuntivi del consumatore

Per i consumatori che beneficiano delle norme o dei regolamenti a tutela del consumatore nella nazione di acquisto, ovvero, se differente, nel Paese di residenza, i benefici conferiti dalle garanzie limitate di Zolo si considerano integrativi dei diritti e dei rimedi previsti da tali leggi e regolamenti a tutela dei consumatori, inclusi senza alcuna limitazione.

Per consultare le domande frequenti e ottenere ulteriori informazioni, visitare il sito Web https://zoloaudio.com.

Información de seguridad importante

- Evite las caídas.
- No desmonte el producto.
- · No sumerja el producto en agua.
- · Este producto está destinado exclusivamente al uso en interiores.
- No exponga el producto a salpicaduras.
- · No instale la unidad cerca de fuentes de calor.
- · No coloque ninguna fuente de peligro cerca del dispositivo (líquidos, velas encendidas, etc.).
- · Utilice solamente el adaptador de alimentación original.
- · Límpielo con un trapo limpio, suave y sin pelusas. No utilice ningún aceite o limpiador corrosivo.
- · Para evitar daños auditivos, no utilice el producto a un volumen elevado durante largos períodos de tiempo.

Aviso



Este producto cumple los requisitos de interferencias radioeléctricas de la Comunidad Europea.



Este producto se ha diseñado y fabricado con materiales y componentes de gran calidad que pueden reciclarse y reutilizarse.

10 Italiano Español 11



Este símbolo indica que el producto no debe desecharse como residuo doméstico, sino que debe depositarse en un lugar de recogida adecuado para su reciclaje. Siga las normativas locales y no deseche nunca ni el producto ni las pilas recargables con residuos domésticos normales. La correcta eliminación de los productos y pilas recargables ayuda a evitar posibles consecuencias negativas para el medio ambiente y la salud humana.

Servicio de atención al cliente



Garantía limitada de 12 meses



Garantía extendida de 6 meses



Asistencia técnica de por vida

* Derechos legales adicionales para consumidores

Los consumidores están protegidos por las leves o normativas de protección del consumidor vigentes en el país de compra del producto o, si es diferente, en su país de residencia. A las ventajas proporcionadas por la garantía limitada de Zolo se suman los derechos y recursos que otorgan dichas leyes y normativas de protección del consumidor, entre los que se incluyen, sin limitación, estos derechos adicionales,

Para consultar las preguntas frecuentes u obtener más información, visite https://zologudio.com.

安全に関する重要情報

- 落とさないでください。
- 分解しないでください。
- 水に浸さないでください。
- この製品は屋内使用専用です。
- 製品に水滴や水しぶきがかからないように注意してください。
- 熱源の近くに設置しないでください。
- · このデバイスの上に危険な状態の原因となるもの(液体の入った物体、火のついたロウソクなど)を設置しな いでください。
- ・ 純正の電源アダプタのみを使用してください。
- ・ 糸くずのない柔らかく乾いた布で拭いてください。腐食性の高い洗浄液やオイルは使用しないでください。
- ・聴覚障害を避けるため、長時間、大きな音量で聴かないでください。

カスタマサービス



(冒) 12ヵ月限定保証 (②) 6ヵ月延長保証 (೨) ライフタイムテクニカルサポート

* 消費者のための追加的な法的権利

購入国、または居住国の消費者保護法または規制が適用される消費者は、消費者保護法、規制などで認められるあ らゆる権利と解決策に加えて、Zolo の限定保証で認められた保証が受けられます。また認められる権利は、これ らの追加的な権利に限定されません。

よくある質問や詳細については、https://zoloaudio.com をご覧ください。

日本語 13 12 Español

ةمهمل قمالسلا تامولعم

- تجنب إسقاط المنتج.
- لاتفككه. لاتغمره بالماء.
- هذا المنتج مصمم للاستخدام الداخلي فحسب.
- بجب ألا يتعرض المنتج لقطرات سوائل أو رشها.
 - لا تثبته بالقرب من أي مصادر للحرارة.
- لا تضع أي مصادر خطر على هذا الجهاز (مثل الأغراض التي تحتوي على سوائل أو الشموع المضاءة). استخدم محول طاقة التيار الأصلى فقط.
- نظف المنتج باستخدام قطعة قماش جافة وناعمة وخالية من الوبر. لا تستخدم أي زيت أو منظف التآكل.
- لتفادي إلحاق الضرر بالسمع، لا تستمع إلى الموسيقي لفترات زمنية طويلة على مستويات صوت عالية.

خدمة العملاء



🗐 ضمان محدود لمدة 12 شيرًا 🌘 فترة ضمان ممددة 6 شيرًا 👤 دعم تقني دائم

* الحقوق القانونية الاضافية للمستهلكين

بالنسبة إلى المستهلكين المحميين بموجب قوانين أو أنظمة حماية المستهلك المعتمدة في بلد الشراء، أو في بلد الإقامة إذا كانت مختلفة، فإن هكذا قوانين وأنظمة لحماية المستهلك تُغطّي الفوائد التي يمنحها ضمان Zolo المحدود، إضافةً إلى كل الحقوق والتّعويضات، بما في ذلك على سبيل المثل لا الحصر، هذه الحقوق الإضافية. للاطلاع على الأسئلة الشائعة ومعرفة مزيد من المعلومات، يرجى زيارة الموقع https://zoloaudio.com.

ةىبارغل 14

@ZoloAudio 👿 @ZoloAudio



service@zologudio.com



+1 (8OO) 988 7973 (US) Mon-Fri 9:OO - 17:OO (PT) +44 (O) 16O4 9362OO (UK) Mon-Fri 6:OO - 11:OO (GMT)

+49 (O) 69 9579 796O (DE) Mon-Fri 6:OO - 11:OO +86 400 0550 036 (中国)周一至周五 9:00 - 17:30

+81 O3 4455 7823 (日本) 月-金9:00 - 17:00