What's In the Box

Packungsinhalt | パッケージ内容 | Contenu du pack Contenuto della confezione | Contenido | 包装清单 | محتوى العلبة








Wie Sie Ihren PowerTouch verwenden | PowerTouchの使用方法 Utilisation de votre PowerTouch | Utilizzare il tuo PowerTouch Usar tu PowerTouch | PowerTouch的使用方法 استخدام PowerTouch الخاص بك

Plug it into a USB charger

Verbinden Sie ihn mit einem USB Ladegerät USB急速充電器に接続 | Branchez-le dans un chargeur USB Collegalo ad un alimentatore USB | Enchúfalo a un cargador USB اعمد إلى توصيله بشاحن 连接USB充电器 | USB



 Place your phone or tablet on the center of vour PowerTouch

Platzieren Sie Ihr Smartphone oder Tablet in der Mitte des PowerTouch

PowerTouchにお使いの携帯電話やタブレットを置きます Placez votre téléphone ou tablette au centre de votre PowerTouch

Posiziona il tuo telefono o tablet al centro del PowerTouch Coloca tu teléfono o tableta en el centro de tu PowerTouch 将你的手机或平板放在PowerTouch的中心位置

ضع الهاتف أو الكمبيوتر اللوحى في وسط PowerTouch

Plugged in

Flashing blue (3 seconds), then off

Blau blinkend (3 Sekunden), dann aus

者色ライトが3.時間占領1.た後、当灯

يومض المؤشر باللون الأزرق لمدة 3 ثوان ثم ينطفي

苗角灯闪烁3秒后熄灭

Aus Iオフ | Voyant éteint

Spento | Apagado | 想灭

Off

غیاب (شار ۵

Branché | Acceso Enchufado | 接通电源 Voyant bleu clignotant pendant 3 secondes Blu lampeggiante (3 secondi), poi spegnimento Azul intermitente 3 segundos, luego apagado

Ready to charge

Bereit zum Laden | 充電可能 Prêt à charger Pronto per la carica Listo para cargar | 准备充电 جاهز للشحن



Eingesteckt | 電源と接続



Blau blinkend | 責色ライトの点滅 Bleu clignotant | Blu lampeggiante Azul intermitente I 蓝色 I FD 阅纸 أزرق واسمض

(e. =<u>.</u>)

Rapidly flashing blue

Blu lampeggiante (rapido

Azul intermitente rápido

الوميض باللون الأزرق بشكل سريع

Мигает синим цветом

茲角IFD快速闪烁

Schnell blau blinkend

書色ライトの早い古波

Steady blue Durchgehend blau | 青色ライトの点灯 Voyant bleu fixe I Blu fisso Azul fijo I 茶色I FD常亮 الضاءة ثابقة باللون الأزرق

Unsupported device detected

Nicht unterstütztes Gerät erkannt 非対応機器を検知 Appareil non supporté détecté Vovant bleu clignotant rapidement Dispositivo non supportato rilevato Dispositivo no soportado detectado 检测到不支持的设备 تم اكتشاف جهاز غير مدعوم

You can choose to turn the indicator off by pressing the button on the back of PowerTouch.

Sie können den Lichtindikator mit dem Knoof auf der Rückseite des PowerTouch abschalten PowerTouch背面のボタンを押すと、LEDランプをオフにできます。



Lädt | 充電中 En charge | In carica Cargando | 充电中 قند الشحن

Fully charged

Voll geladen | 満充電 Chargé | Carica completata Carga completa | 充电完成 اكتمل الشحن



رقم المنتج Product Number A2516 Wireless Charger SM-A448-V01

Bedienungsanleitung | 取扱説明書 | Guide d'Utilisation Guida d'Utilizzo | Manual de Instrucciones دليل الترحيب | 使用说明书

Welcome Guide

PowerTouch 5

Vous pouvez choisir d'éteindre la LED en appuvant sur le houton au dos du PowerTouch

È possibile spegnere l'indicatore led premendo il tasto sul retro del PowerTouch.

Puedes apagar el indicador presionando el botón en el dorso de PowerTouch

按 PowerTouch 背面按钮可关掉指示灯

يمكنك اختيار إيقاف تشغيل المؤشر عبر الضغط على الزر في الجهة الخلفية من .PowerTouch



For the fastest and safest charge, use your PowerTouch with an Anker® charger, USB chargers with an output lower than 5 volts / 2

amps may not work. Verwenden Sie für die schnellste und sicherste Ladung Ihres PowerTouch ein Anker® Ladegerät. USB Ladegeräte mit geringeren Output als 5V/2A

funktionieren möglicherweise nicht. 高速かつ安全に充電するために、Anker®製の急速充電器と 一緒にご使用下さい。USB急速充電器の出力が5V/2A未満 の場合、充電が適切に行われない場合があります。

Pour une charge sûre et rapide, utilisez votre PowerTouch avec un chargeur Anker®, Les chargeurs USB avant un courant de sortie inférieur à 5V/2A peuvent ne pas fonctionner.

Per ricariche più rapide e sicure, utilizza il tuo PowerTouch con un Alimentatore Anker®, Alimentatori con uscite inferiori a 5 volt / 2 ampere potrebbero non funzionare

Para recargas más rápidas y seguras, usa tu PowerTouch con un cargador Anker® Cargadores USB con salida menor de 5 voltios / 2 amperios podrían

no funcionar. 为保证安全快速充电,请配合Anker®充电器一起使用 PowerTouch。输出电压低于5V/2A的USB充电器可能导 致无法正常充电。

لضمان الشحن بأعلى سرعة وأمان، استخدم PowerTouch مع شاحن من®Anker. قد لا تعمل شواحنUSB ذات الاخر اج الأقل من 5 فولت

Specifications

Especificaciones | 产品参数 | しからして

Spezifikationen | 製品の仕様 | Spécifications | Specifiche

Input	5 V == 2 A
Cutout	DC 5V, 0.95A

Size	92 × 92 × 14 mm 3.6 × 3.6 × 0.6 in
Weight	97 g / 3.4 oz

Attention

Achtung | 注意 | Attention | Attenzione | Atención تحذير ات | 注意



Use original or certified cables Verwenden Sie originale oder zertifizierte Kabel 練正または認証されたケーブルをで使用ください N'utiliser que des câbles originaux ou certifiés Utilizzare cavi originali e/o certificati Usar cables originales v/o certificados 使用原装或者通过认证的线材 استخدم كاللات أصلية أو معتمدة



Avoid extreme temperatures Vermeiden Sie extreme Temperaturen 極端な温度下では使用しないでください Eviter les températures extrêmes Tenere Iontano da temperature estreme

Mantener aleiado de temperaturas extremas

游免在过高或过低温环境使用 | تحنب الحراءة المرتفعة |



Don't expose to liquids

Setzen Sie das Gerät keinen Flüssigkeiten aus 水分に触れないようにしてください

Ne pas exposer à des liquides Evitare il contatto con liquidi Evitar el contacto con líquidos 请勿接触液体 | どっぱん



Avoid dropping

Lassen Sie das Gerät nicht fallen 過度な衝撃を与えないでください Ne pas faire tomber

Non far cadere Evitar caídas 避免跌落产品 | تجنب إسفاطه

Don't disassemble Nehmen Sie das Gerät nicht auseinander

危険ですので分解しないでください Ne pas désassembler Non smontare No desarmar

请勿拆卸 | ど道みり



Kundenservice Lカスタマーサポート L Service Client Servizio Clienti | Atención al Cliente | 客服支持 | خدمة العملاء



18-month limited warranty

18 Monate beschränkte Herstellergarantie 18ヶ月保証 | Garantie de 18 mois Garanzia valida 18 mesi | Garantía limitada de 18 meses



ضمانة 18 شير أمحدونة | 18个月质保期

الدعم الفني مدى الحباة | 终身客服支持

Lifetime technical support Lebenslanger technischer Support テクニカルサポート | Support technique à vie Assistenza post-vendita a vita Asistencia técnica de por vida



support@anker.com







anker.com/support











This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

the user is encouraged to try to correct the interference by one or more of the following measures:

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,

FCC STATEMENT:

Reorient or relocate the receiving antenna.

FCC Radiation Exposure Statement

Increase the separation between the equipment and receiver.

Consult the dealer or an experienced radio/TV technician for help.

with minimum distance 10cm between the radiator & your body

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.