## What's In the Box

Packungsinhalt | パッケージ内容 | Contenu du pack Contenuto della confezione | Contenido | 包装清单 | محتوى العلبة








Wie Sie Ihren PowerTouch verwenden | PowerTouchの使用方法 Utilisation de votre PowerTouch | Utilizzare il tuo PowerTouch Usar tu PowerTouch | PowerTouch的使用方法 استخدام PowerTouch الخاص بك

Plug it into a USB charger

Verbinden Sie ihn mit einem USB Ladegerät USB急速充電器に接続 | Branchez-le dans un chargeur USB Collegalo ad un alimentatore USB | Enchúfalo a un cargador USB اعمد إلى توصيله بشاحن 连接USB充电器 | USB



• Place your phone or tablet on the center of vour PowerTouch

Platzieren Sie Ihr Smartphone oder Tablet in der Mitte des PowerTouch

PowerTouchにお使いの携帯電話やタブレットを置きます Placez votre téléphone ou tablette au centre de votre PowerTouch

Posiziona il tuo telefono o tablet al centro del PowerTouch Coloca tu teléfono o tableta en el centro de tu PowerTouch 将你的手机或平板放在PowerTouch的中心位置

ضع الهاتف أو الكمبيوتر اللوحى في وسط PowerTouch

Flashing blue (3 seconds), then off Branché | Acceso Blau blinkend (3 Sekunden), dann aus 者色ライトが3.時間占領1.た後、当灯 Voyant bleu clignotant pendant 3 secondes Blu lampeggiante (3 secondi), poi spegnimento Azul intermitente 3 segundos, luego apagado

## Ready to charge

Bereit zum Laden | 充電可能 Prêt à charger Pronto per la carica Listo para cargar | 准备充电

## Plugged in

Eingesteckt | 電源と接続 Enchufado | 接通电源

جاهز للشحن



Flashing blue Blau blinkend | 責色ライトの点滅 Bleu clignotant | Blu lampeggiante Azul intermitente I 蓝色 I FD 阅纸 أزرق واسمض



### Steady blue Durchgehend blau | 青色ライトの点灯 Voyant bleu fixe I Blu fisso Azul fijo I 茶色I FD常亮 الضاءة ثابقة باللون الأزرق

(e. = ....<u>.</u>)

Rapidly flashing blue

Blu lampeggiante (rapido

Azul intermitente rápido

الوميض باللون الأزرق بشكل سريع

Мигает синим цветом

茲角IFD快速闪烁

Schnell blau blinkend

書色ライトの早い古波

Unsupported device detected Nichtunterstütztes Gerät erkannt

非対応機器を検知 Appareil non supporté détecté Vovant bleu clignotant rapidement Dispositivo non supportato rilevato Dispositivo no soportado detectado 检测到不支持的设备 تم اکتشاف جهاز غیر مدعوم

## You can choose to turn the indicator off by pressing the button on the back of PowerTouch.

Sie können den Lichtindikator mit dem Knoof auf der Rückseite des PowerTouch abschalten PowerTouch背面のボタンを押すと、LEDランプをオフにできます。



Lädt | 充電中 En charge | In carica Cargando | 充电中 قند الشحن

## Fully charged

Voll geladen | 満充電 Chargé | Carica completata Carga completa | 充电完成 اكتمل الشحن



رقم المنتج Product Number A2512 Wireless Charger SM-A447-V01

Bedienungsanleitung | 取扱説明書 | Guide d'Utilisation Guida d'Utilizzo | Manual de Instrucciones دليل الترحيب | 使用说明书

Welcome Guide

PowerTouch 10

苗角灯闪烁3秒后熄灭

Aus Iオフ | Voyant éteint

Spento | Apagado | 想灭

Off

غیاب (شار ۵

يومض المؤشر باللون الأزرق لمدة 3 ثوان ثم ينطفي

Vous pouvez choisir d'éteindre la LED en appuvant sur le houton au dos du PowerTouch

È possibile spegnere l'indicatore led premendo il tasto sul retro del PowerTouch.

Puedes apagar el indicador presionando el botón en el dorso de PowerTouch.

按 PowerTouch 背面按钮可关掉指示灯

場合があります

يمكنك اختيار إيقاف تشغيل المؤشر عبر الضغط على الزر في الجهة الخلفية من .PowerTouch



For the fastest and safest charge, use your PowerTouch with an Anker® Ouick Charge 2.0 / 3.0 charger. USB chargers with an output

lower than 5 volts / 2 amps may not work. Verwenden Sie für die schnellste und sicherste Ladung Ihres PowerTouch ein Anker® Ouick Charge 2.0 / 3.0 Ladegerät. USB Ladegeräte mit einem Output geringer

als 5V/2A funktionieren möglicherweise nicht. 高速かつ安全に充電するために、Anker®製のOuick Charge 2.0 / 3.0 急速充電器と一緒にご使用下さい。USB急速充電 器の出力が5V/2A未満の場合、充電が適切に行われない

Pour une charge sûre et rapide, utilisez votre PowerTouch avec un chargeur Ouick Charge 2.0 / 3.0 Anker®. Les chargeurs USB avant un courant de sortie inférieur à 5V/2A peuvent ne pas fonctionner.

Per ricariche più rapide e sicure, utilizza il tuo PowerTouch con un Alimentatore Quick Charge 2.0 / 3.0 Anker®. Alimentatori con uscite inferiori a 5 volt / 2 ampere potrebbero non funzionare.

Para recargas más rápidas y seguras, usa tu PowerTouch con un cargador Quick Charge 2.0 / 3.0 Anker®, Cargadores USB con salida menor de 5 voltios / 2 amperios podrían no funcionar.

为保证安全快速充电、请配合Anker® Quick Charge 2.0.7 3.0充电器一起使用PowerTouch。输出电压低于5V/2A 的USB充电器可能导致无法正常充电。

لضمان الشحن بأعلى سرعة وأمان، استخدمPowerTouch مع شاحن Ouick Charge 2.0 / 3.0 من®Anker.قد لا تعمل شواحن USB ذات الإخر اج الأقل من 5 فولت / 2 أمبير

## Specifications

Especificaciones | 产品参数 | しからして

Spezifikationen | 製品の仕様 | Spécifications | Specifiche

| ⇨ | Input  | DC 5V, 2A   |
|---|--------|-------------|
| Û | Output | DC 9V, 0.5A |

| Size      | 92 × 92 × 14 mm<br>3.6 × 3.6 × 0.6 in |
|-----------|---------------------------------------|
| KG Weight | 96 g / 3.4 oz                         |

## Attention

Achtung | 注意 | Attention | Attenzione | Atención 注意 | さに



Use original or certified cables Verwenden Sie originale oder zertifizierte Kabel 練正または認証されたケーブルをで使用ください N'utiliser que des câbles originaux ou certifiés Utilizzare cavi originali e/o certificati Usar cables originales v/o certificados 使用原装或者通过认证的线材 استخدم كاللات أصلية أو معتمدة



Avoid extreme temperatures Vermeiden Sie extreme Temperaturen 極端な温度下では使用しないでください Eviter les températures extrêmes Tenere Iontano da temperature estreme Mantener aleiado de temperaturas extremas 游免在讨高或讨低温环境使用 | تحنب الحراء الم تفعة |



### Don't expose to liquids

Setzen Sie das Gerät keinen Flüssigkeiten aus 水分に触れないようにしてください

Ne pas exposer à des liquides Evitare il contatto con liquidi Evitar el contacto con líquidos 请勿接触液体 | どっぱん



Evitar caídas

Avoid dropping Lassen Sie das Gerät nicht fallen 過度な衝撃を与えないでください Ne pas faire tomber Non far cadere



## 避免跌落产品 | تجنب إسفاطه

Don't disassemble Nehmen Sie das Gerät nicht auseinander

危険ですので分解しないでください Ne pas désassembler Non smontare No desarmar

请勿拆卸 | ど道みり

### Customer Service

Kundenservice Lカスタマーサポート L Service Client Servizio Clienti | Atención al Cliente | 客服支持 | خدمة العملاء



### 18-month limited warranty

18 Monate beschränkte Herstellergarantie 18ヶ月保証 | Garantie de 18 mois Garanzia valida 18 mesi | Garantía limitada de 18 meses



# ضمانة 18 شير أمحدونة | 18个月质保期

الدعم الفني مدى الحباة | 终身客服支持

Lifetime technical support Lebenslanger technischer Support テクニカルサポート | Support technique à vie Assistenza post-vendita a vita Asistencia técnica de por vida





## For FAOs and more information, please visit:











This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

FCC STATEMENT:

Reorient or relocate the receiving antenna.

FCC Radiation Exposure Statement

Increase the separation between the equipment and receiver.

Consult the dealer or an experienced radio/TV technician for help.

with minimum distance 10cm between the radiator & your body

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

the user is encouraged to try to correct the interference by one or more of the following measures:

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.