

USER MANUAL QUICK INSTALLATION GUIDE **MGR450B**




**BLUETOOTH® (Audio Streaming)
Marine Gauge Digital Media
AM/FM Receiver**

FEATURING ZERO STANDBY CURRENT DRAIN




OPERATION QUICK START GUIDE

EN




SOURCE MODES



All rights reserved. No part of this publication may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of BOSS AUDIO SYSTEMS Inc.


TUNER SETUP



GETTING STARTED

AUDIO MENU	Short press to mute restore volume Turn the unit on, press and hold again to turn the unit off Press to pause, press again to resume playback
▶/II	Tuner/Weather Band Mode: Press to enter into Manual Seek mode, press and hold to enter into Auto Seek mode Media Playback Mode: Press to Track Up/Down, press and hold for Fast/Forward/Rewind
SRC	Press to scroll and select available Source
PRESET Fn	Press to scroll and select Presets 1 ~ 6 Press and hold to enter into Tuner Function modes: A-STORE / M-STORE / LOCAL / AREA / RDS / AF / TA / PTY
Q BAND	Decrease volume, press to increase volume Tuner/Weather Band Mode: To change different band, press and hold to access Auto Store mode, the strongest stations of the selected band will be saved in preset channel automatically (FM1, FM2, AM1, WB1) Media Playback Mode: Press to access into search Folder/file music mode Returns to previous item
DISP ENTER	Tuner Mode: Press to view RDS receiver information Media Playback: Press to view ID3 information
AUDIO MENU	Press to access into the Audio Menu mode for adjustments: EQ / XBASS / BASS / MIDDLE / TREBLE / BALANCE / FADER / READOUT / SUBW / SUBW LPF / SUBW LEVEL
MENU	Press and hold to access into the System Menu: BT RECONNECT / BEEP ON/OFF / ABOUT / RESET

C



AUDIO and SYSTEM SETUP

D



- Press the SRC button to select RADIO
- Press ▶/II to MUTE, press again to UNMUTE
- To advance stations press ▶
- To skip previous stations press ▲
- Press the DISP button to display RADIO information
- Press the PRESET button to recall PRESETS 1 ~ 6

BLUETOOTH OPERATION

PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION

Note: The mobile device must be within 33ft (10m) of the MGR450B for Bluetooth to function properly.
1) Power on the MGR450B by pressing and holding down the Power button for 1 second, the Bluetooth icon will start to flash signalling that the MGR450B is now ready for Bluetooth pairing.

NOTE: You have 2 minutes before you must restart this procedure over again.

2) Now that the MGR450B is in pairing mode:

ANDROID users:

- Go into the Settings Menu of your ANDROID device
- Enter the Bluetooth Menu and press SCAN
- "Boss Audio MGR450B" will now be displayed under AVAILABLE DEVICES
- If prompted, enter passcode: "0000"

iOS users:

- Go into the Settings Menu of your iOS device
- Enter the Bluetooth Menu
- "Boss Audio MGR450B" will now be displayed
- If prompted, enter passcode: "0000"
- If the MGR450B is not seen, repeat the above steps to refresh the "Device List"
- When the BT connection is successful you will see BT CONNECTED message on the MGR450B LCD display, you are now ready to stream music from your devices favorite media player to the MGR450B

RECONNECTION

1) Power on the MGR450B and your last paired device Bluetooth

2) The unit will now automatically be reconnected

3) If your device was previously paired with the MGR450B, but it wasn't the last paired device:
a. Ensure no other devices are currently paired
b. Press and hold MENU button to manually connect / reconnect to the MGR450B

4) If the device is out of range from the MGR450B, it will disconnect automatically:

5) The MGR450B will reconnect to the device once in range, a confirmation message will be displayed on the LCD

BLUETOOTH STREAMING MUSIC

- Press the SRC button to select BT AUDIO
- Press ▶/II to start PLAY, press again to PAUSE
- To skip songs or advance tracks press ▶, press and hold to FAST FORWARD
- To select the previous track press the button ▲, press and hold to FAST REWIND
- Press the DISP button to display song ID3 information



USB OPERATION

- Press the SRC button to select USB
- Press ▶/II to start PLAY, press again to PAUSE
- To skip songs or advance tracks press ▶, press and hold to FAST FORWARD
- To select the previous track press the button ▲, press and hold to FAST REWIND
- Press the DISP button to display song ID3 information



AUX-INPUT

- Press the SRC button to select AUX IN
- Press ▶/II to MUTE, press again to UNMUTE



Tips: Ensure to adjust the level of your devices master volume to 75%