

**Quick Start of LK58** 


### Content

LK58 Features	1
USING YOUR LK58: BASICS	6
POWERING ON AND OFF	
Using ST24 to Control LK58	7









HDMI Cable(MICRO HDMI+MINI HDMI)

## **USING YOUR LK58: BASICS**

## **POWERING ON AND OFF**

To Power ON:

Slide the power switch to ON, system indicator lights, wifi indicator lights, LK58 boot completed To power OFF:

Slide the power switch to OFF, all the lights go out, LK58 shutdown completed

# Using ST24 to Control LK58 (with camera SONY N7)

- 1. LK58 plug in the power, plug in the HDMI cable to connect the camera and infrared sensors to detect the position of the infrared camera is placed.
- 2. Power on LK58
- 3. Bind ST24 and Ik58:Connect Wi-Fi in PAD interface, and input the correct password(87654321).
- 4. When binding is complete, enter FPV→Model Select→Select a Model or choose a model you have set in advance(sony N7). Return to FPV screen and press Take Off to connect video.

#### **FCC STATEMENT**

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

### **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body