



**LED LIGHTS**

STATUS LIGHT	DESCRIPTION
Fast Blink Blue:	Camera is turning On.
Solid Red:	Camera is in smartphone mode. Camera will communicate with a smartphone.
Slow Blink Green:	Camera is recording video and audio.
Fast Blink Yellow:	Camera is low on battery power or memory is almost full. Camera is recording video and audio.
Solid Yellow:	Camera is not recording. Battery is out of power or memory is full.
Slow Blink White:	Camera is installing firmware. Do not turn the camera Off or disconnect it from power or the camera firmware update may fail and cause the camera to become unresponsive.
Solid Blue:	Camera is connected and in queue to download.
Slow Blink Blue:	Camera is downloading video.
CHARGING LIGHT	
Solid Red:	Battery is charging.
Solid Green:	Battery is fully charged.

If Covert Mode is enabled, LED lights will not illuminate. Vibration will be enabled to indicate when the camera starts and stops recording.

**RECORDING INDICATION STICKER (OPTIONAL)**

A red sticker is included that can be placed between the camera lens and microphone. This will give others a visual indication when the camera is recording video.

**NEED HELP?**

Phone: **888-285-4548**  
Email: **support@viewu.com**

Rev1  
VIEVU  
645 Elliott Ave W Ste 370 Seattle WA 98119

