GPS device

Users Manual

Welcome to use our GPS navigator

- We reserve the final explanation right on this User's Manual.
- Specifications are subject to change without notice. Sorry for any inconvenience caused!
- •Please make a copy of the important data. We assume no responsibility for the data loss.
- This manual has been carefully checked. Please contact our service center when any typing mistake is found.
- •Please read the operating instruction carefully and use the accessories only provided by the original factory to avoid any unexpected damage. No warranty will be executed if you are not following the instruction or connecting with the incompatible accessories, we assume no responsibility for any loss and damage caused hereby.
- •The electronic navigation data may be not in conformity with the actual transporting marks due to the traffic construction development. Please be sure to comply with the real road condition and follow the traffic rules. Operating and viewing the GPS during driving may cause severe traffic accident. Our company will not be responsible for any loss caused by the unexpected accident.
- •Users can update and upgrade software from website at his/her option.
- •Any discrepancy between the pictures with real products hereinafter, the real one prevails.

Chapter One Product introduction

1. 1 Introduction

Welcome to use the GPS navigator, which is mainly used for navigating and also has the optional function of video playing, audio playing, Bluetooth hands free, FM, Bluetooth, photo viewing, and E-Book etc.

- ◆High performance, low-power consumption MediaTek MT3351C CPU;
- ◆ Comfortable user interface: simple, easy to operate;
- ◆Power management: keep the product to work longer and more steadily;
- ◆ Data transmitting: communicate with computer through USB cable;
- ◆Excellent in receiving signal: accurate position fixing provides you the satisfied navigating service;
- ◆ Compatible with Bluetooth mobile: the navigator can also be used for making and answering call with hands-free (Optional);
- ◆Entertainment: MP3 and MP4 function can relieve your fatigue;

You can use it when driving, walking, riding, or waiting for a meeting; the perfect "GPS + entertainment" function can make your life and work more splendid.

1.2 Package

The packing box contains the following accessories, please confirm:

- 1. GPS navigator
- 2. Car charger
- 3. MINI USB cable
- 4. User's manual
- 5. Car bracket

For the items listed above, please confirm the actual products. If any damage, Please contact with the distributor or the agent as soon as possible.

Instruction

Please read this user's manual carefully to be familiar with all the operation details and to make the GPS navigator performs well:

[Remark]: The instruction relates to the theme;

[Relative information]: The extending information relates to the theme;

Note 1: The notes and warnings relate to the theme. Please value and follow these notes, otherwise it will possibly bring damage to you and others.

This user manual only adapts to our GPS navigator products.

Chapter Two Features and specifications

2.1 Main features

- ◆Operating system: Microsoft Windows CE 6.0;
- ◆5" TFT LCD display with resolution of 800*480 pixels;
- ◆Hi-Fi stereo earphone and built-in Hi-Fi speaker, volume adjustable;
- ◆Button and touch-screen operation;
- ◆Built-in sensitive GPS antenna;
- ◆ The navigating software could run the SD card directly;
- ◆ Video format supported: ASF,AVI,WMV,3GP,MP4,FLV;
- ◆ Photo format supported: BMP, JPG, PNG;
- ◆E-book format supported : TXT;
- ♦MINI USB port;
- ◆Built-in rechargeable Li-battery which can be powered by travel and car charger.

2.2 Specification

CPU	MediaTek MT3351C		
flash memory	128 MBytes		
EMS memory	128 MBytes		
LCD display	5"	LCD	display,

	Resolution :800RGB(H)x480(V)		
Touch-screen	High-accuracy, endurable touch-screen		
USB	USB Client 2.0, MINI USB port		
	SD / MMC slot, the maximum		
SD	capacity of SD Card supported reaches		
	to 8GB		
Audio	A: Built-in high fidelity speaker		
Audio	B: High fidelity stereo earphone		
	Cold start: <42s		
GPS	Hot start: <3s(in the open area)		
	Warm start: <36s		
Battery	Built-in rechargeable Li-battery		
Battery Charging port	DC 5V port		
AC Charger	100/230V charger, 5V / 1.5A		
Car Charger	DC9-24V, 5V / 1.5A		
Status of the LCD	When charging, the red light is on;		
	when charge finished, the blue light is		
light	on.		
Operating System	Microsoft Windows CE 6.0		
Navigation Software	SD card		
Video Player	ASF,AVI,WMV,3GP,MP4,FLV;		
	MP3 and WMA		
Audio Player			
Photo viewer	E-Album, JPG, BMP, PNG		
EBook Viewer	TXT		
	[FM Transmitter] [Screen adjustment] [Default		
System setting	set] [Volume] [Power] [Backlight] [Time and		
	Date] [Language] [Sys Info]		
Temperature	Operating Temperature : 0° C to 60° C		
_	Storage Temperature : -20°C to 60°C		
Working humidity range	45% to 80%RH		
Storage humidity range	30% to 90%RH		
Atmospheric pressure	86KPa to 106KPa		

This chapter will give an introduction of the apparent components and basic function of the GPS Navigator and it will help you to be familiar with the basic operation quickly.

2.3 Product appearance

Chapter Three Manual Instruction

3.1 Power supply and charge

If this navigator is first used, please use AV adaptor to fully charge it.

3.1.1 Power supply

There are three types of supplying power: battery, adaptor, USB cable.

GPS navigator uses the Li-battery to supply power when it is not connected with adaptor. The mark [on the up right of interface indicate the current electric volume.

GPS navigator uses the external power when it is connected with the adaptor.

GPS navigator uses the USB cable to supply power when the GPS connects to the PC.

[Remark] This machine adopt built-in, unchangeable Lithium battery. At normal condition (if the back light is not so bright), the actual supply hour can be different because of the different way using the navigator. Some function (audio playing, video playing, bright back light) will consume a large power, which will reduce the using hour.

Note This machine adopts built-in, unchangeable Lithium battery. In order to avoid fire and burning, please do not poke, bump or take it apart or throw it into fire or water.

3.1.2 Use the travel charger to supply power

When the GPS navigator is first used, please use the AC adaptor to charge it.

1. Connect the DC part of the adaptor with the power interface at the left side

of the unit (The power interface is same as USB interface);

2. The other part connect to the power socket, it supplies power while charging.

【Remark】Red LED indicates it's being charged. Please wait until it is fully charged and don't pull out the adaptor while charging. When it is fully-charged, the LED will turn to Blue. If low battery or no battery, please charge it immediately.

3.1.2 Use the car charger to supply power

- 1. Connect the DC part of the adaptor with the power interface;
- 2. The other part connect to the power socket, it supplies power while charging.



[Note] Please insert the car adaptor after running the car so as not to damage the machine by electricity collision.

3.2 Power on/off

Power on/off is controlled.

3.2.1 Power on:

Please check: The battery is enough, or it is connected to external power source; Please press the button on the top of the unit to boot.

Note If bring the unit form one place to another place, please boot until it adapts to the environment. Big humidity fluctuation will make the mainframe short circuited.

3.2.2 Power off

Press the button on the top of the unit to turn off, the unit will enter the power saving mode and maintain the last operation status when boot next time.

3.3 Reset system

If the system cannot work, you can reset the system by the following way:

Click the reset key on the right part of the machine to reset the system by using the stylus.

Trelative information 1: it can be no response in the following condition:

- 1. The shift between pictures is delayed or stopped.
- 2. The program select function cannot work normally, such as long time to carry out or cannot be activated.
- 3. The power button can not work

Note The unsaved data will be lost as you reset the system when the system has no response. Please copy the data every other time.

3.4 Use bracket to fix navigator

When use GPS in the car, you should fix the device to the part of window besides the panel by using the bracket.

[Note] When use the bracket, please take care of the position. Please don't fix the navigator to the position where the driver's sight is being influenced. Please do not lay it aside freely; do not fix it to the air bag, do not lay it on the expand range of the air bag.

3.5 Stylus

The stylus is the tool for you to use your navigator. Please keep it carefully.

1. Single click:

Singly click the screen with the stylus point.

2. Double click:

Double click the screen with the stylus point.

3. Drawing:

Click one point and hold to move on the screen.

[Note] Any broken stylus, ball pen or any acute and harsh object will destroy the LCD if you use it to operate the device.

3.6 SD/MMC card

The attached SD/MMC card contains the navigation software, map data and media file. Please insert the card correctly when use it.

[Note] Please do not take out the SD/MMC card when the system is navigating or playing.


[Note]

- 1. Don't stress or curve the SD/MMC card, avoid loss and bulge.
- 2. Avoid high temperature or high humidity when use and store the card, don't expose the card directly to sun light, let the card far away from liquid and corrosive material.
- 3. Please pay attention to the heading when insert the SD/MMC card. If you insert the card improperly, you will damage the card.

3.7 Connect with computer

The device can be connected with the computer through the MINI USB on its left part. You can copy the document between navigator and computer or copy the data from GPS navigator to computer so as to recover the data in GPS when you are in need of them.

- 1. Please confirm the GPS navigator is power on;



3 Please pull out the MINI USB cable after you finished your operation, the GPS navigator will return to the pre-operation interface.

[Note] Data security: Please copy the data to the outer storage device every time before you update your system data. Our company takes no responsibility to any loss of data.

【Remark】 The GPS navigator will stop the operation when it is connected with computer.

[Note] In the process of communication, the following operations will break off the connection with computer, the unfinished data will be lost.

- 1. Pull out the MINI USB cable;
- 2. Power off
- 3 Reset the system by using reset button or electric switch

Chapter Four Primary function

4.1 The main interface and the function

4.1.1. Main menu:



4-1

Click the top left corner of the interface Desktop display the date, show in Figure 4-2




4-2

12 Sunday

2003 - 01

Double-click the date icon Sunday enter the date setting interface, show in Figure 4-3




4-3

Click the top left corner of the interface change the desktop display background, show in Figure 4-4



4-4



quick access to navigation map



Click the left button Music open audio player quick

4.1.2 Function introduction

Navigation	Provide navigation service	
Divisto eth	This device can answer and make phone after connecting with	
Bluetooth	mobile phone via Bluetooth	
Vidaa playar	Support ASF, AVI, WMV, 3GP, MP4 and FLV format. Support progress adjust, pause	
Video player	and full screen play	
Photo viewer	Support JPG、BMP and PNG format. Support photo rotate, enlarge/shrink pictures,	
riioto viewei	automatic play and so on	
E-book	Text format: txt.	
E-000K	Support page selection	
	Audio playing format: WMA, MP3.	
Audio player	Support random playing, sequential playing, repeat playing, pause,	
	previous/next, volume	
Game	Support game	
Sotting	Brightness, Volume, Languages, Power, Time, System, Default,	
Setting	GPS Info, Navipath.	

This chapter will introduce the navigation function and notes.

4.2 Navigation functions and features

According to your choice of navigation system, the GPS navigator can make position by GPS satellite signal receiver and display on the navigation map. The system can calculate a best route after setting the destination, which can help users to arrive the destination safely and rapidly.

The system can let you enjoy the individual charm and enjoy your trip by many different ways such as vision map, vivid animation, voice indication, and words indication.

The specific navigation functions are depended on your choice of navigating software. Please refer to the Navigation Software Instruction.

Notes

1. Map information


It is probably that the electronic navigation data is not consistent with the real traffic instructions because of the traffic construction development. Please do comply with the highway condition and the actual traffic rules.

2. Navigation

The navigator offers the route for the reference; determine the route by yourself, the driver may be more familiar with the route than GPS navigator.

3. Receiving signal

Many factors such as high, dense buildings (in the tunnel, between the high building, underground parking, under the trestle), various weather condition, and closure of the satellite will affect the ability to receive signal so as to result in inaccurate position, inefficiency of navigation operation and system function.



4.3 Video operation Interface

This chapter introduced how to use the GPS video player.

4.3.1Functions and features

- 1. Support ASF, AVI, WMV, 3GP, MP4 and FLV
- 2. Support full-screen playing, progress choosing and file selection;

Before using the Video player, please copy your video file (ASF, AVI, WMV, 3GP, MP4 and FLV) to any folder

4.3.2 Operation:

Single click the Video button video to enter the video file list as the picture,



Choose the video to enter the playing interface as 4-5





ResidentFlash	Video folder name	Video folder name
	Player models	Click play entered the frequency type
∢ I	Previous	Play the previous video;
Ш	Play	It shows stop playing. Single click will continue to play.
I ▶	Next	Play next video.
	Volume	Single click volume. It shows volume is decreased when it shift toward left. While volume is increase when it is shifted toward right.
•	Playing progress	Adjust the progress by slide the progress-displaying bar; go left for backwards, go right for forwards;
	Play interface	Full screen play. Double click to return normal play status.
[WMV 8] Movie	Video name	Show current Video name
00:00:16	Time	Show the time consumed
00:04:26		The total time of the video

4.4 Audio player operation interface

This chapter introduces how to use the GPS video player to play your favorite music, and let it be your personal MP3.

4.4.1 Functions and features

The audio player supports MP3 and WAV format, you could set the playing sequence as you wish.


Before using the audio player, please copy the files to any folder.

4.4.2 Operation method

1. Single click the button to enter Music file list, Choose the song to enter the playing interface as 4-6

Function instruction

E	Close	Close current file
A	Last	Show last page
· ·	next	Show next page;
Part I(38-72)	Song name	Show song name



(Close	Single click to close the audio player;
	Homepage	
≣≣	Full screen play interface	Click the change to the audio frequency play interface all, The right to the display area
4 I	Previous song	Play the previous song;
Ш	Play/pause	To play and pause, single click to pause, click again to play continuously;
I ▶	Next song	Play the next song;
Volume		Adjust volume. It shows volume is decreased when it shift toward left. While volume is increase when it is shifted toward right.
→	Setting the playing mode	Support sequencial playing, loop playing, repeat playing and random playing.
	Playing progress	Adjust the progress by slide the progress-displaying bar; go left for backwards, go right for forwards;
teXet sample music	Songs id3 information	Shows the track album / track name / artist
Time consumption		Show the time progress;
00:02:13	Total time	Show the total time for playing the song;

4.5 Photo viewer operation interface

This chapter introduces how to use the photo viewer to browse pictures.

4.5.1 Function features:


- 1. Supports JPG BMP and PNG
- Support picture rotate, picture enlarge/shrink and automatic play.
 Before using the photo viewer, please copy your photos to any folder.


4.5.2 Operation method

Single click the button



to view to open the photo list as picture 4-7





4-8

Choose the picture to enter play interface as 4-9



4-9

←	Close	Click to close the viewer
⊕,	Enlarge	Enlarge current picture in proportion
Q	Shrink	Shrink current picture in proportion
4 I	Previous	Show the previous picture

I	Next	Show the next picture
31	Rotate	Click to rotate the picture by 90 degree
-	Automatic	Play all the pictures circularly on full screen from the current
P	Play	picture

4.6 E-book reader interface and operation

This chapter introduces how to use GPS to read e-book.


4.6.1Function


- 1. Support TXT
- 2. Support turning over page, page browse, and file choosing. Before using e-book function, please copy your TXT file and save it to any folder.

4.6.2Operation



to enter Ebook list as 4-10





4-11

←	Close	Click to close current file
	Last page	Show the last page;
	Next page	Show the next page;
ResidentFlash	Name of file	Show name of file

1. Choose file name to enter e-book reader as 4-12




4-12


←	Close	Single click and close e-book reader
■ I	Last page	Read last page
I ▶	Next page	Read next page
≔	File	Single click to enter Ebook list to choose favorite book
A/B	Font set	As 4-13
≡ A	Color set	As 4-14
=/	Add book mark	It needs open e-book and choose TXT.
A	Open book mark list	As 4-15




4-13Font set interface

Bold	Set font as bold
Normal	Set font as normal
	Decrease font size





111	
G 74 B 170	Set color RGB
Text Color	Choose background color, font color or set background color
	Choose background color, font color or set background color with reverse order or sequential order
	Color review
←	Return to e-book homepage



4-15

With strong softwarehardware RD 4%	Single click and choose book mark
←	Return e-book interface
=	Rolling book mark list
	Return e-book homepage.
4%	Showing current reading ratio

4.7 Game interface and operation




Single click Game o choose different games as 4-16:



4-16

4.8 Unit Conversion


Single click Unit tools into Unit conversion interface as shown 4-17:



4-17

4.9 Calculator

Single click Calculator into the calculator interface as shown 4-18:




4-18

4. 10 USB Setting



Click the button on the main interface USB setting, Open to the USB interface setting mode as 4-19



4-19


4. 11 Volume adjust

le click Volume


Single click volume into the vlume adjust interface as shown4-20:

"Volume adjustment" includes:

- 1. Speaker volume adjustment
- 2. "Screen click tone" setting.



4-20




4-21

←	Close	Exit "volume setting" interface;
	Volume	Single click to decrease the volume gradually; there are 10 ranks for volume from mute to maximum. Single click will decrease one rank/ Single click to increase the volume gradually; there are 10 ranks for volume from mute to maximum. Single click will increase one rank.
LOUD	Click the screen tone	By clicking the left/right shift button to set the on/off key tone, with loud, soft, and off the three states, AS4-21;


4. 12 Backlight setting

Single click Backlight


Single click Backlight to enter backlight setting interface as 4-22;



4-22



←	Close	Exit "backlight setting" interface;
	Brightness	Click to decrease backlight gradually to the lowest level/ Click to increase backlight gradually to the highest level;



4.13 Date and time setting




Single click Date Time into the date time interface as shown4-24:

Date and time include:

- 1. System time set;
- 2. System date set;

3 ytem time zone set.



- 1. Click on the screen with the stylus to drag up and down year, month, day, hour, minutes of the parameters.
- 2. Click to select the Time Zone field as 4-25.



4-25

4.14 Screen Calibration


Click the Calibration to enter the screen calibration as 4-26.



4-26

Click YES it will move from in the sequence of the center, left up, left down, right down and right up till the calibration succeed, then click any where on the screen to

save the calibration and exit to the main interface automatically. If not save the information, please wait 30 seconds and it will exit from current interface automatically.




4-27

4.15 FM Transmitter



to enter the FM setting as 4-28



FM Transmitter will send out the audio signal to the radio devices. Take 88.7MHZ frequency for example, both the GPS transmitting frequency and the received frequency of the radio should be 88.7MHZ, then all the sounds of the GPS will be input through the amplifier system of the radio.


4. 16 System information



Click the Sys Info to enter the System information as 4-29:

System information includes:


- 1. Firmware version:
- 2. APP version;
- 1. System ID.



+	Exit system information
Rom Version	Show ROM version
APP Version:	Show the APP version;
System ID	Show the system ID.

4.17 Language setting

Single click anguage into the language settings interface as shown4-30,Language setting including:Syetem prompt language selection;



Single click language column to do language choose.

4.18 Navigation path

Click the Navi Path set the interface into navigation path , set the default navigation paths as shown in Figure 4-31:



4-31

4.19 Default set


Single click RestoreS... to enter the default setting as 4-32:




4 - 32

Single click YES to restore the default settings, single click NO to exit the default settings.

4.20 GPS Information



k the button GosInfo and enter GPS information interface as 4-33;



4.21 ISDBT Instruction:

Click the "TV" icon in Function Menu to enter figure 1




Figure 1

Click "Continue" to enter the TV channels broadcast interface, then click button to enter settings interface. The channel options interface is shown in figure 2



Figure 2 Click the button "scan" to enter the scanning channels interface as figure 3



Figure 3
Select the TV channel you search for to enter the broadcast interface as figure 4



Figure 4

Button Function:

=	Open the file list	Click to switch to the folder interface, select your favorite program
~	Setting	Click to set ISDBT
=	Display ESG Menu	Enter ESG menu

+	Volume +	Click to increase the system volume one level
_	Volume _	Click to decrease the system volume one level
= (3)	Mute	click to open Mute
	Volume size instruction	9 levels altogether
×	Off	Click to turn off ISDBT
	Snapshot picture	Snapshot current broadcasting picture
	Record program	Record current broadcasting program
	Play/Pause	Indicate program pause / play, click to continue to play, click again to pause
_	Stop	Click to stop playing program
_	Previous channel	Click to play previous channel
—	Next channel	Click to play next channel
19:35	Time	System current time
	Broadcast picture	Full-screen play mode, double-click the screen to return to normal play mode
T .	Signal strength	Display signal strength information



button to enter file list as figure 5



Figure 5

Select your favorite program to enter broadcast interface, click to exit file list, click to enter ESG menu

1. Display channel list



Figure 6

2. Display your favorite channel list



Figure 7

Click "general" on Settings interface to enter the General Settings interface as figure 8



Figure 8

Set the language and screen proportion

Language	English, Japanese and Portuguese three options
Audio stream switch	Audio system switching
Audio Channel Config	Main Audio Sub Audio and Dual three options

Click "about" to enter the version information interface as figure 9



Figure 9

Note: please be sure to pull out the whip antenna of body when using the digital TV function! This function is optional, and some models have no such function. Please refer to the real subject!

4.9 Bluetooth setting and operation description:

This chapter introduces how to connect the Bluetooth function and the phone to makes calls and receive calls.

Operation methods:



1 Click

buttons open to Bluetooth interface, as Picture 4-36:



Picture 4-36

C	Close	click it to exit current interface
Dialing	Dial	to dial phone numbers
Phonebook	Phone book	Display phone book
Call history	Phone record	display current phone record
S.F. Q A2DP	Bluetooth	
SMS	information	lead the text message
DUN	Dial internet	
Pair/Connect	Bluetooth setting	set search mobile phones, lead the information management
Close	Open Bluetooth	open/close Bluetooth function


2 Click Bluetooth setting Pair/Connect button, open Bluetooth setting as Picture 4-37:

Picture 4-37




3 Click "Modify the name" button, enter into modify the name interface, as Picture 4-38:

Picture 4-38





Picture 4-39



Picture 4-40



Disconnecte	click it to disconnect Bluetooth device
Connect	click it to connect Bluetooth device
Delete	click it to delete selected Bluetooth device
Clear up	click it to clear up all the history Bluetooth

6 Click "Search button to search Bluetooth device, as Picture 4-41:

Picture 4-41



C	Close	click it to exit current interface
Re-search	Search Bluetooth	Search Bluetooth device
Stop	stop	stop Bluetooth search
Connect	connect	Connect Bluetooth
Disconnect	disconnect	Disconnect Bluetooth

7 Click selected mobile phone "N73gps" click " Connect, input the passaords to connect the Bluetooth device, close current interface, enter into below interface, as Picture 4-42:

Picture 4-42



8 Close current interface, enter into below interface, all the buttons will turn to colorful pictures, it indicates it is paired, as Picture 4-43:

Picture 4-43



C	close	click it to close current interface
Dialing	dial	dial phone numbers
Phonebook	Phone book	display phone book of paired phones
Call history	Call history	display current call history
A2DP	A2DP	
SMS	SMS	Lead into the SMS of paired phones
DUN	DUN	

Pair/Connect	Bluetooth	set to search mobile phones, lead to the information management of paired phones
Open	Open Bluetooth	open/close Bluetooth



9 Click Bluetooth interface Dialing button, open keyboard interface, as Picture 4-44:

Picture 4-44



C	Close	click it to exit current interface
	number display area	display the phone number you are inputting
1 2 3 4 5 6 7 8 9 * 0 #	Numeric keyboard	.it is made of ten numbers from zero to nine and "*""#" "+"
\leftarrow	backspace	click it to delete the last number
(Dial phone numbers	Click phone numbers
	Hang up	click it to cancel the dialing call

4-	Volume-	Click it to decrease volume
4 +	Volume+	Click it to increase volume
	Transfer calls, keep current call online	Transfer calls, keep current call online

10 Click "button in keypad, phones will be called(remind: calling), as Picture 4-45:

Picture 4-45



11 If there is any call, display call and the phone number, as Picture 4-46:

Picture 4-46




Hang up "button to reject calls, click hand button to answer; Enter into below interface, as

Picture 4-47:

Picture 4-47



When the phone is connected, you can hear the talker through the GPS, and you can talk to him via the microphone,




12 Click / Phonebook in Bluetooth interface, open the phonebook interface, as Picture 4-43:

Picture 4-48



13 Click Call history button in Bluetooth interface, open call history interface as Picture 4-44:


Picture 4-49



4 Click 立体声 / A2DP

k 立体声 A2DP button enter into Bluetooth interface, as Picture 4-50:


Picture 4-50





15 Click | / SMS button in Bluetooth interface, lead to the information in paired phones, as Picture 4-51:

Picture 4-51



Unread	click it to read unread text message
Read	click it to view the read text message
Sent	click it to view the sent message
Unsent	click it to vie unsent message
Synch	click it to synch with phone
Dialing	click it to dial selected phone number

16 Click multi-media / DUN

DUN to enter into dial internet interface, as Picture 4-52:

Picture 4-52



Click "/ button enter into connect state, as Picture 4-53:

Picture 4-53



Click / Browser button enter into IE explorer; the program will start a browser, as Picture 4-54:




Welcome to Microsoft Pocket Internet Explorer



© 2004 Microsoft Corporation. All rights reserved. Terms of use.

Picture 4-54

	return to previous website	return to previous website
	go to next website	go to next website
@	Refresh interface	Refresh interface
	stop opening the webpage	stop opening the webpage
****	click it to enter into small keypad, as Picture 4-50	click it to enter into small keypad, as Picture 4-50
\windows\default	website	Display the website
•	close	exit the current interface



54

✓

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.