Remote Control User Manual

Remote First Time Use Instructions

1) Battery is pre-installed in the remote control. Pull plastic tab from bottom of remote when ready to use. (Note: If the projector does not respond to the remote, please see troubleshooting below)

Remote Control Battery Replacement

- 1) Open the battery cover on the bottom of the remote by pushing on the tab on the side of the battery tray and pulling the battery tray out from the bottom.
- 2) Clean the battery contacts and also those of the device prior to battery installation.
- 3) Use only type CR2032 or CR2025 3V Lithium battery for replacement, use of other batteries may damage remote.
- 4) Install battery following the polarity shown on the battery compartment.
- 5) Close battery cover by sliding back into place._



Federal Communications Commission (FCC) Interference Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,

the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

Note: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF exposure warning

• The equipment complies with FCC RF exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

CAUTION:

- -RISK OF ELECTRIC SHOCK
- -NOT FOR USE WITH DIMMER
- -NOT FOR TOTALLY ENCLOSED LUMINAIRES
- -SUITABLE FOR DAMP LOCATIONS
- -THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS