## **Quick Guide**



## **Dimension:**

360mmx320mmx245mm(H)mm

#### **Software:**

Android OS

### **Hardware:**

**Screen:** 9.7" Display (1K/2K Optional, TN or IPS Optional)

Touch: Multi Touch (Glass-on-Glass Optional)

**SOC**: 8 Core ARM Soc **Memory**: 2GB DDR3

**Storage:** 8GB(16GB ~ 32GB Upgrade Optional)

**WiFi:** 802.11b/g/n/a

Bluetooth: Included (BLE Upgrade Optional)

**G-Sensor**: Optional

Camera: Front 2M (8M Optional), Rear 5M (Optional),

**Auto-Focus Optional** 

**USB**: 1xUSB Type A, 1xMicro USB (Optional)

Microphone: Optional

Speaker: 1W Internal Speaker

Battery: 5000mAh

**3G/4G**: Optional (Auto - Switch Optional)

Scanner: Optional Card Reader: MSR + IC

**DC IN**: 5V/4A **RJ45**: 10/100M

**USB**: 2.0

Micro USB: Optional for Debug

TF: mSD (Optional)

### Include:

Scanner Locking Ring

# **Specfication:**





## Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- a) This device may not cause harmful interference.
- b) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

## Home screen



Note: Your tablet may have a different wallpaper to the one shown.

- Search
   Widgets
   Favorites bar
- 4. Notification bar
- Apps list
   Navigation (Back, Home, Recent)

#### Using your tablet

 Connect the power adapter Charge your tablet for at least four hours.

**Note**: It is normal for the device surface to become warm during charging or long periods of use.

Press the power button Hold until you see the Acer logo.

#### Connecting to the Internet via Wi-Fi

To connect to a Wi-Fi network, tap (1) to open the *Apps list*, then tap **Settings** (2). Under *Wireless & networks*, tap **Wi-Fi** and ensure it is **On**. Tap the name of your wireless network; if necessary enter a security password to access the network.

#### How to register

To register your Acer product, visit our website at registration.acer.com.

After we receive your product registration, you will be sent a confirmation email with important data that you should keep in a safe place.

#### Your tablet's User's Manual

To download the User's Manual, go to www.acer.com and click Support > DRIVERS AND MANUALS. Select the appropriate items from *Group* (e.g. Tablet) > Series > Products. In the Documents tab, click Download next to the User's Manual.

### Connecting a Bluetooth device

To connect to a bluetooth device, tap 

open the Apps list, then tap Settings 

Under Wireless & networks, tap Bluetooth 
and ensure it is On. Your device 
automatically scans for available Bluetooth 
devices; tap an available device to connect.

**Note:** A2DP stereo headsets are supported for playback only. Please check for updates to the tablet's software that may add support for additional Bluetooth devices.

#### Restoring to factory settings

To format your tablet, tap ⊕ to open the Apps list, then tap Settings ♀ Tap Backup & reset > Factory data reset; tap RESET TABLET and then ERASE EVERYTHING.

# Updating your tablet's operating system

To check for updates, tap 

to open the Apps list, then tap Settings 

tablet > System updates > CHECK NOW.

#### **IMPORTANT SAFETY INSTRUCTIONS**

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- 5. Do not use this apparatus near water.
- 6. Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8. Do not install near any heat sources such as radiators, heaters, stoves, or another apparatus (including amplifiers) that produces heat.
- 9. Do not override the safety features of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong, are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles and at the point that they exit from the apparatus.
- 11. Only use attachments/accessories specified by the manufacturer.
- 12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- 13. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when a power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
  - Refer to the manufacturer's operating instructions for power requirements. Be advised that different operating voltages may require the use of different line cords and/or attachment plugs.
  - Do not install the unit in an unventilated rack, or directly above heat-producing

- equipment such as power amplifiers. Observe the maximum ambient operating temperature listed in the product specifications.
- Never attach audio power amplifier outputs directly to any of the unit's connectors.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and radiates radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. This can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different to the one that the receiver is connected to.
- Consult the dealer or an experienced radio/television technician for help.

#### **WARNING:**

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. Do not place objects containing liquid, such as vases, on this apparatus.

The appliance coupler is used as disconnect device, the disconnect device shall remain readily operable.

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such vases, shall not be placed on apparatus.

The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.