

Test setup photo of EUT



A. Photo of Test setup (9 kHz ~ 30 MHz): X-axis



B. Photo of Test setup (30 吨 ~ 1 吨): X-axis





C. Photo of Test setup (1 \times ~ 4.5 \times): X-axis



* To get a maximum emission level from the EUT, the EUT was moved throughout the X-axis, Y-axis, and Z-axis. The worst case is X-axis.