# Call -Answer a call Mute on/off Reject a call Switch between the earphone and phone End a call Press the Multifunction button once.

### Redial the last call

## Voice dial (Need phone support)

Music ---

### Music play / pause

Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first) .

## Track back/forward

Press the Volume "-" for 2 seconds once to skip track backward, press Volume "+" for 2 seconds once to skip track forward.

# Basic operation –

## Status indicator

Instruction	LED status	Voice prompts
Power on	Stay blue about two second	Power on
Power off	Stay red about two second	Power off
Standby	Blink blue twice every 5 seconds	1
Pairing	Flashes red and blue alternately	Pairing

Volume up/down Press the volume "+" to turn volume up Press the volume "-" to turn volume down

Press and hold Multifunction button for about 2 seconds, the LED flashes blue twice.

## Power off

Prower off Press and hold Multifunction button for about 5 seconds, the LED flashes red twice. Tips: When the distance between the earphone and phone is beyond effective range, earphone disconnects with phone. Earphone will power off automatically once no active for 20 minustral

Turn off voice prompts: enter pairing mode: Press the volume\*-button for 3 seconds, the red LED lights flash 3 times.

## Clear paired list

### Hard reset

If the earphone cannot be turned on even when fully charged or does not respond during use, follow the instructions below to reset it. I. While pressing and holding the multifunction button, connect the earphone to your PC's USB port or a USB power adapter with the

Z.Keep pressing and holding the Multifunction button until the earphone turns on. The earphone is now reset.

# Safety and care —

Using earphone at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety.

Earphone may not work properly under high temperature or high humidity conditions.

If the earphone comes in contact with liquids, quickly wipe away .If submersed in water, do not turn the earphone on until completely dried Tips:liquid submersion voids the warranty.

Keep the earphone and packaging out of reach of children

## Bluetooth Sports Headset for calls and music

MEE audio X8 INSTRUCTION

# Start here -

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

End current call and answer new call

On hold current call and answer new call

When a new call rings during a call, press the Multifunction button once to answer new call and end current call

(2) this device must accept any interference received,

by the party responsible for compliance could void the user's


### Product overview

including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved authority to operate the equipment.



Charging



# Pairing -

# Pair one phone

release Multifunction button.

2.Activate Bluetooth on your phone (See below for more details).

### iPhone

a.On your phone, open the Setlings menu. b.Select Bluetooth. If Bluetooth is off, turn it on. The iPhone will search for new devices automat

### Android phone

a.On your phone, open the Selfings menu.
b. Select Bluetooth For old Android phone, Bluetooth is found in the
Wireless & Networks). If Bluetooth is off, turn it on. Select Search for
Devices if your phone does not automatically search for new devices

a.On your phone, open the Settings menu.
b.Select Bluetooth. If Bluetooth is off, turn it on.
The Phone will search for new devices automa











### Pair another phone

Multipoint technology enables you to pair another phone and take a call from either.







