


SEEME HERE

USER MANUAL

BV350

Bluetooth Speaker

SEEME HERE



7 On/Off with Long press for 3 seconds: On: Vocie prompt "bluetooth mode" after "Ding-dong", blue light start to OFF 8 9 Connect with other bluetooth device Valid distance is 10 meters Bluetooth disconnected Long press (**) to disconnect the speaker depends on environment) with other device, LED blue light start to flicker with vocie prompt"bluetooth disconnected" Connected and play BV350 Vocie prompt"Connected" after Turn on the mobile, pad or other device bluetooth connected successful, LED bluetooth connection, searching BV350 blue light is lit. to connect. 1.type"0000"to connect 2.Bluetooth speaker will automatical reconnect the when it requests connected Bluetooth reconnected previous device before password. Short press (to reconnect the previous device. 11 10 TF card music play Handfree call

Speaker connected with mobile Insert TF card and turn on the speaker The music will pause when mobile call Insert TF card with stored music files, is ringing, short press () to answer the long press the power key, voice prompt"bluetooth mode"after sound call,long press to hang up or refuse. "Ding-dong" Connect to player device Connect to speaker Audio cable Change to TF card mode Short press $\binom{\mathbb{M}}{\mathbb{O}}$ to change the mode, voice Line in mode prompt"TF card mode", play the music files stored in TF card Long press power key, vocie prompt "bluetooth mode" after sound SEEME HERE "Ding-dong";short press $\binom{\mathbb{M}}{\mathbb{O}}$ to change the mode,voice prompt "Line in mode", connect the speaker with play device via audio cable. Notice:The speaker will change to TF card mode automatically when insert the TF card during operation. 12 13

FCC Certification Requirements Charge Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority Support DC5V≥500mA to operate the equipment. **USB** charging This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a Connect the speaker with computer via USB cable to charge particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the the built-in battery. user is encouraged to try to correct the interference by one or more of the following measures: Notice: Please charge the speaker before using. -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. Warranty Card Please fill up the "Warranty card" and keep it well after purchasing the product

Purchase date: Name: _____ Address: Telephone: _____ Zip code: _____ Dealer: ____ Address: _____ Principal: Telephone: _____ Zip code: _____ Authorized stamp: Period of validity: 1 year since purchase date Note:This warranty is null and void if the unit or its components therein have been damaged or tampered by improper handling use or unauthorized repair. 16