### Wireless mouse user manual

# Ø Battery installation:

- 1, use two AAA1.5 V batteries.
- 2. 1.Open the battery cover at the bottom of the mouse
- 3. 2. Insert two AAA1.5 V batteries, (please pay attention to is the cathode of the battery to insert in the direction across the electrodes of labeled correctly).
- 4. 3. Cover the mouse battery cover

### **Ø** hardware installation:

- 1. the receiver directly or via USB extension cord from the USB interface of a computer...
- 5. move the mouse can be used, such as can't use please see ID code and mouse failure lifting method.

## Ø ID code:

- 6, move the mouse close to the receiver;
- 7. first press the mouse button to the code on the "Connect", then click on the receiver on the code key "Connect", move the mouse, then automatically Connect with computer, please do not reverse this process.
- 8. the setup process must be completed in 8 seconds, if the timeout please repeat the above steps.
- **Save electricity:** mouse over 5 minutes when not in use, the mouse will automatically enter power saving mode, which is the mouse will not electricity, photosensitive element does not shine, when you want to use, click on the left or right to use.
  - 1. **Using the environment:** in order to prevent environmental disturbance caused by the mouse can't normal use, please pay attention to the following aspects:
- 1 please don't put the mouse or receiver in a metal cabinet or on the table, the metal will produce the RF interference, thereby weakening the RF transmission and shortening the distance between the mouse.
- 2. in order to prevent interference, please keep the mouse and other RF electronic products in the distance of 1.5 meters.
- when placed on a mirror, glass or other reflective surface, can cause the mouse light sensors don't work properly.

#### 2. Faults and remove meth:

1. The mouse is not working .confirm whether battery, such as no electricity,

please charge according to the battery installed.

- 2. The mouse receiver connected to the computer USB interface is good.
  - May be the receiver and the distance of the mouse over the scope of work, move the mouse close to the receiver can be used
  - ID code is set up, please reset the ID code.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.