Features

Headphone

HP-03

This headphone can function as a speakerphone for your mobile phone(while connected in Bluetooth mode)

Short press the play/pause icon of parent to pause/play or answer a phone call.

Short press again to end call.



Charging

A full charge is recommended before the first use.

Connect the standard USB plug into a USB wall charger, or into a powered USB outlet on a computer.

Connect the micro USB plugs into both speakers. The USB charging port is located under the rubber cover on the side.

The LED indicators on the pause/play button will blow red while May&June headphone is charging. When the light turns off. The units are finished charging.

WARNING: Do not use USB chargers that provide more than 1 Amp(1A) of electricity. Doing so could severely damage the battery of May&June and potentially cause maltunctions.

Connecting

Pairing May&June headphone

Connecting with device

- Turn on your device's Bluetooth function and search for Bluetooth devices; select May and June from the device list, and press connect.
- 2. After successfully connecting, the LED of May&June headphone changes to solid blue.

Safety and Maintenance

- Do not use this device near any heat sources such as radiators, heaters, stoves, or other heat –producing machinery.
- Do not leave May&June headphone in direct sunlight.
- Keep May&June headphone out of children's reach to avoid a choking hazard
- Clean with a soft cloth. Do not use harsh chemicals to clean
- Do not clean this device when it is charging. Always unplug from the power source and ensure the protective rubber cover is tightly sealed before cleaning.
- Do not insert any metal object into the device. Risk of short circuiting.
- Do not try to repair or open this device yourself. Contact
 FRESHeTECH customer service.
- Do not submerge May&June headphone under water. Changes in pressure can cause water to leak into the device and potentially damage the speaker.
- Do not charge with a USB charger that provide more than 1 Amp(1A)
 of electricity.

Trouble shooting

The headphone does not play.

1. Make sure the headphone is fully charged.

- Make sure the headphone and device are connected. Please refer to your device's Bluetooth menu and "Connecting" section of this manual.
- 3. Make sure the volume is turned up.

I cannot pair my device to May&June headphone

- 1. Make sure the headphone is charged.
- 2. Make sure the Bluetooth of our device is on; please refer to your device's user manual.
- 3. Make sure the headphone and device are in pairing mode.
- 4. Make sure the headphone and your cell phone are within controllable range. We recommend within 1 meter form each other.

If problem persists, please do as follows:

- Recharge the May&June headphone.
- Turn off your cell phone, take out the battery, and put it back
- Turn the Bluetooth of your device and delete all the pairing histories
- Re-pair your device and the headphone

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.