WATERRPOOF BAG **BLUETOOTH SPEAKER**

SPECIFIC PARAMETERS

Waterproof bag with bluetooth speaker Size: 235. 00*114. 14*31. 05mm

Material: PP and ABS Link mode: Bluetooth Speaker style: Dynamic Speaker quantity: 1 pc Impedance: 4 Ohm

Frequency range: 100 Hz to 10KHz

Output power: 1.8W

Power: Lithium-ion rechargeable battery 300mAh Battery Charging: Micro USBDC5V 300mA

PRODUCT STRUCTURE BUTTON FUNCTION


















2 Open both buckle put your mobile phone in the bag.

3 Long press & 2 seconds to turn on or turn off the speaker.








Back side





IOS Android

OPERATION FEATURES:



turn on , and the power LED indicator



■ Open bluetooth function of your device, search for bike speaker device with name "BLUETOOTH SPEAKER"




Click pairing with found device BLUETOOTH SPEAKER"




After successful pairing, you can play music.



Press the power key tuming call under linked bluetooth status.




Within hands-free calls can be realized.




Using Micro USB cable for charging, and charging time is


INSTALLATION:




1 Turn on both buckle of bag



2 Then open the bag.



3 Put your mobilephone into the bag



Finish. You can enjoy this product brings about to experience the fun.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.