
Star view Tech STB XM-A208 user guide

Chapter 1 Connecting the XM-A208

The XM-A208 STB shoule be connect as follow:



Chapter2 Introduction of remote control


2.1 Installing the remote control

Need two models for AA5 batteries, installation steps are as follows:

- 1. Press the card slot on the battery cover and open it gently;
- 2. Puttwo models for AA5 batteries in the battery box, pay attention to whether the pole is correct;
- 3. Press the battery cover upwards until it gets stuck.

2.2 Button functional specification

Button	Function	
()	Press this button, STB will change status between standby and	
	working.	
	Turn on/off mute function.	
Home Channel Demand Screen	Home: Press this button to enter system menu home page.	
	Channel: Press this button to enter broadcast channel list page.	
	On Demand: Press this button to enter VOD page.	
	Full screen: Press this button will switch small window to full	
	screen.	
	Apps: Press this button to enter application page.	
	Browser: Press this button to enterbrowser, by the help of input	
	method, you can browse the webpage on TV.	
Apps Browser Display Settings	Display: In full screen mode, press this button can switch length-width	
	ratio.	
My TV My Favorite Language Subtitle	Settings: Press this button to enter setting page.	
	MyTV: Press this button to enter"My TV"page.	
Page Up Page Down •	My Favorite: Press this button to enter"My Favorite"page.	
	Language: Press this button will switch the voice mode.	



Chapter3 Troubleshooting

Problems	Possible reasons	Solutions
	The power socket without power.	Ensure the power socket work
Power light is off		normal.
	The power adapter is not	Connect the power adapter
	connected.	correctly.
	The power adapter is broken.	Ask your service provider to replace
		the power adapter.
Cannot connect to the network	Cable is not connected.	Reconnect the cable.
	Cable problem.	Replace cable.
	Network problem.	Waiting for the recover or contact
		network provider.
The TV screen has no image	STB is in standby status.	Press , switch to working status.
	Video line has not connected or	Connect video line again by user
	connected in wrong way.	guide.
	Select incorrect kind of video input	Switch the kind of video input
	source.	source, until desktop appears.

Speaker has no sound	STB is in standby status.	Press , switch to working status.
	Audio line has not connected or	Connect audio line again by user
	connected in wrong way.	guide.
	STB or audio equipments arein	Raise volume of STB and audio
	mute state or minimum volume	equipments, or press to close
	state.	mute function.
Remote control cannot work	There is no battery in it or install	Install the battery correctly by user
	battery in wrong way.	guide.
	Battery is low.	Replace the battery.
	STB has not receive the signal from	Move closely to STB when use it,
	remote control.	and remove obstacles between
		them.
Audio and videoare asynchronous	Some programs adopts multiple	Press "Language" button to switch
	audio broadcast mode.	voice mode.
Others		Restart and try again, if the problem
		is still, please contact the customer
		service hotline.

Chapter4

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

