

## Water Dancing Speaker:

Speaker  $[4\Omega 3W/M40mm]$ 


- 1. Micro USB port
- 2: Indicatory LED light
- 3: Master unit Mini USB port
- 4: On/Off Switch
- 5: Slave unit Mini USB port
- 6. Mini USB cord
- 7. Micro USB charging cord



## Packing included:

- 1. Water Dancing Speaker----1 pair
- 2. Mini USB connection cable----1pc
- 3. Micro USB to USB charging cable----1pc

## Instruction:




- 1. Connect two speakers via the Mini USB connection cable
- 2. USB input allows the speaker to be charged from a computer USB port or from a USB wall or car charger.
- 3. Charge it: Plug in the USB cable into either a computer USB port or to a USB-compatible car or wall charger. Solid red LED light will appear to indicate when the speaker is charging, even while speaker is turned off.

When charging is complete, the red LED light will turn off.

- 4. Turn on the speaker, located on the back of the master speaker. The speaker will emit a tone and the speaker's LEDs on the front will light up.
- 5. Your Nuvelon is now ready to be paired with your media player.
- 6. On your Bluetooth-enabled smart phone, tablet or media player, navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices.
- 7. After a few seconds you will see "NUVELON" listed.
- 8. Tap this model to select it, the speaker will emit a tone that it has been successfully paired with your device.
- 9. You are now paired, connected and ready to play.

- 10. Control your track and volume from your device and enjoy the music and water dancing lighting.
- 11. All audio, including music, games, videos, and notifications will be routed through the Nuvelon.
- 12. The speaker will automatically reconnect to the last Bluetooth device it was connected to.
- 13. If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth settings menu on your device, turn on the Bluetooth feature, and select"NUVELON" from your list of paired Bluetooth devices.



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.