

User Guide

AV-075



I .Function instructions

Power button: A. Un-match: when the current time, long press the power switch, the blue and red light flashing alternately, in the matching state, long press power key to turn it off again. This cycle.
B. Re-matched, when the current time, long press the power switch, the blue lights flashing, base automatic back to connect device. Press the power button enter a state of automatic matching, blue red light flashing, long press power key to turn it off, this cycle.

Loudness: audio input selection mode, increased or reduced

Audio input: input audio interface


Audio output: audio output interface

DC output: 5 v DC 5 v output interface (mobile devices rechargeable)
The line in function, with the line in cable to connect, priority in all conditions play line in connecting devices

Bluetooth and NFC function
Bluetooth connection bluetooth mobile: open mobile search function, device show name: BlueGATE CVT, confirmed and matching, after the success of blue light flashing, mobile phone enter standby state, pairing play music. If matching error, cut off the power supply and the device to turn it off after the restart, match again. Matching if prompted for password for 0000.

Connect this device with NFC mobile phones, cell phone have NFC function in the search condition, keep the cell phone near the device with NFC words position. Mobile phone can automatically open the bluetooth and connected devices, the connection is successful, the blue lights flash, phone display connected or bluetooth logo, enter the standby state, play the music OK. If matching failure, need to cut off the power to restart operations

II 、 Use schematic connection diagram



List of Annexes :

1.3.5mm AUX cable	1PCS
2.3.5mm to RCA cable	1PCS
3.3.5mm Audio splitter	1PCS
4.2A AC adapter.	1PCS

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.