

P.A. System Transmitter EW001 Procedure

1.TRANSMITTING.

Frequency Range: 638.35MHz to 643.475MHz

1.1FREQUENCY ADJUSTMENT

- a) Connect the frequency counter to the pot F1.
- b) Replace the crystal Y1 for the operating frequency.
- c) Adjust L9.
- d) Specification: EW001 Frequency +/-0.005%

1.2 EW001 POWER CHECK:

- a) Connect the RF power meter to the pot F1.(RF impedance 50 ohm).
- b) Switch on the transmitter.
- c) Check the EW001 power.
- d) Specification: 3dBm +/-1dBm

1.3MAX. DEVIATION ADJUSTMENT:

- a) Connect the deviation meter to the pot F1.
- b) Apply the audio signal 400Hz,30mV to the MIC point.
- c) Adjust VR1.
- d) Specification: 20KHz, Dev. +/-2KHz.
- 1.4 Generate the 32.768KHz signal through the Q2,Q1,Y2 and output to Audio.

宁波音王电声股份有限公司

Ningbo Soundking Electronics and Sound Co.,Ltd 地址: 宁波市鄞州区投资创业中心诚信路 818 号

Tel.: +86-574-88235195-526 Fax: +86-574-83064715 http://www.soundking.com