

# Payment Express® BRF300 Hardware Guide

Version 0.3



# **DOCUMENT REVISION INFORMATION**

Version	Revision Information
0.1	Initial version.
0.2	
0.3	

# **RELATED DOCUMENTS**

Version	Document Title



#### **COPYRIGHT**

© Copyright 2017, Payment Express Limited 33 Wilkinson Road, Ellerslie PO Box 8400 Auckland, 1150 New Zealand www.paymentexpress.com

All rights are reserved. No part of this work may be reproduced or copied in any form or by any means, electronic or mechanical, including photocopying, without the express written permission of Payment Express Limited.

#### PROPRIETARY NOTICE

The information described in this document is proprietary and confidential to Payment Express Limited. Any unauthorised use of this material is expressly prohibited except as authorised by Payment Express Limited in writing.



# **CONTENTS**

Document Revision Information	2
Related Documents	2
Copyright	3
Proprietary Notice	
1 Overview	
2 BRF300 ANTENNA LANDSCAPE ASSEMBLY (AB0163)	1
<ul><li>2.1 Dimensions</li><li>2.2 Machine CutOut</li></ul>	
3 BRF300 ANTENNA PORTRAIT ASSEMBLY (AB0164)	
3.1 Dimensions	
4 Installation	7
5 Secure Acceptance	g
6 Maintenance 6.1 Tradeouts & Deactivation Process	
7 Appendix	10



#### 1 OVERVIEW

The BRF300 contactless antenna is an optional receiver that can be plugged into the SCR300 to support contactless payments (e.g. Visa PayWave, MasterCard PayPass, Amex ExpressPay). The BRF300 also supports closed loop proprietary payment cards such as MiFare RFID. The BRF300 can also be used as a standalone device.

The Payment Express BRF300 solution comes in two models. The only difference is mounting orientation. One landscape and one portrait.

## 2 BRF300 ANTENNA LANDSCAPE ASSEMBLY (AB0163)



#### **Hardware Overview**

- The BRF contactless antenna is an optional receiver that can be plugged into the SCR to support contactless payments (e.g. Visa PayWave, MasterCard PayPass, Amex ExpressPay).
- Supports closed loop proprietary payment cards (e.g. MiFare)
- 32-Bit Cortex M3 120MHz processor

- Display LEDs x4
- Landscape design.

#### **Physical Link Interface**

• Connection with the SCR300 unit is via the attached cable located on the back of the BRF300 unit.

#### **Power Requirements**

The device accepts DC regulated from +9VDC to +45V SEL (Safety Extra Low Voltage).

#### **Operating & Storage Temperature Ratings**

Storage: -35 to 80 degrees (Celsius) Operating: -25 to 75 degrees (Celsius)

#### **Additional Comments**


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



#### 2.1 DIMENSIONS



#### 2.2 MACHINE CUTOUT



MACHINE CUTOUT HORIZONTAL MOUNT (VIEWED FROM MACHINE FRONT)



## 3 BRF300 ANTENNA PORTRAIT ASSEMBLY (AB0164)



#### **Hardware Overview**

- The BRF contactless antenna is an optional receiver that can be plugged into the SCR to support contactless payments (e.g. Visa PayWave, MasterCard PayPass, Amex ExpressPay).
- Supports closed loop proprietary payment cards (e.g. MiFare)
- 32-Bit Cortex M3 120MHz processor

- Display LEDs x4
- Portrait design.

#### **Physical Link Interface**

Connection with the SCR300 unit is via the attached cable located on the back of the BRF300 unit.

#### **Power Requirements**

The device accepts DC regulated from +9VDC to +45V SEL (Safety Extra Low Voltage).

#### **Operating & Storage Temperature Ratings**

Storage: -35 to 80 degrees (Celsius) Operating: -25 to 75 degrees (Celsius)


#### **Additional Comments**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- 3. This device may not cause harmful interference, and
- 4. This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



### 3.1 **DIMENSIONS**



#### 3.2 MACHINE CUTOUT



MACHINE CUTOUT VERTICAL MOUNT (VIEWED FROM MACHINE FRONT)




# 4 INSTALLATION

Description	Quantity
BRF300 Antenna	1
Customer equipment with BRF300 mounting cut-out (see X and X).	1
Sheet Metal BRF300 Mounting Plate	1
Nut M4 Flange Serrated	4
BRF300 Controller Only	1
Screw M4 x 8mm Cap 3.0mm Hex SS304	2
Silicone BRF300 Controller Plug Bung	1
BRF300 Power & Comms Cable, 700mm	1
Silicon BRF300 Controller Plug Cover	1
	BRF300 Antenna  Customer equipment with BRF300 mounting cut-out (see X and X).  Sheet Metal BRF300 Mounting Plate  Nut M4 Flange Serrated  BRF300 Controller Only  Screw M4 x 8mm Cap 3.0mm Hex SS304  Silicone BRF300 Controller Plug Bung  BRF300 Power & Comms Cable, 700mm

TIGHTENING TORQUES:

M4 FLANGE NUTS = 1.5 Nm M4 CAP SCREWS = UNTIL SNUG





#### 5 SECURE ACCEPTANCE

The BRF300 solution is a secure payment device and therefore before any units are installed the customer must check the following.

#### 5.1 SERIAL NUMBERS

Each BRF300 device has their own unique serial number. Upon receiving the unit, the customer must check to ensure that the serial number on the box matches the serial number on the unit.

Any discrepancies need to be reported to Payment Express (see appendix 7.1 for contact numbers).

#### 5.2 SIGN OF TAMPERING

Customers need to check each unit for signs of tampering.

The following should be checked:

- The exterior of the device should have no (new) holes, signs of adhesives or stickers other than the device label.
- The device label should be straight and smooth.
- LED lights. The 4 green LED's will blink 3 times on power up if tampered.

Any signs of tampering or concerns must be reported to Payment Express (see appendix 7.1 for contact numbers).

#### 6 MAINTENANCE

#### 6.1 TRADEOUTS & DEACTIVATION PROCESS

In the event that the BRF300 devices need to be swapped out or deactivated, please follow instructions below.

- 1. Call Payment Express Support to log a ticket (see appendix 7.1 for contact numbers). Please provide the following information.
  - Serial Number of BRF300 device(s).
  - Brief description of fault / reason for deactivation.
  - Contact Name.
  - Contact Phone Number.
  - Shipping Address (for replacement if needed).
- 2. Physically remove the device(s).
- 3. Ship the device(s) back to Payment Express.



# 7 APPENDIX

## 7.1 CONTACT PAYMENT EXPRESS

#### **Phone**

International	+64 9 309 4693
Australia	1 800 006 254 or +61 2 8268 7700
Hong Kong	+852 3 678 6766
New Zealand	0800 PAYMENT (729 6368) or 09 309 4693
Singapore	+65 3 158 1353
South Africa	+27 10 500 8784
United Kingdom	+44 (0) 20 3176 5551
USA	+1 310 670 7299

#### E-mail

Sales	sales@paymentexpress.com
Support	support@paymentexpress.com
Dev Support	devsupport@paymentexpress.com

