













BS2 BS1 BS0

000: NAND with RS ECC

001: Boot card (Select by BOOT CARD)

010: eMMC (SDIO2_2) 011: USB full speed

100: SPI flash

101: USB high speed

110: NAND with Hamming ECC

111: BMC (SPI)

BS5 : GPIO/EJTAG

NOVATEK MICROELECTRONICS CROP.

2F,No. 13,Innovation Road 1, Science-based industrial Park, Hsichu 300, Taiwan

DSC NT96650 series

Size Document Number Rev
A Boot & Debug

Date: Tuesday, June 23, 2015 Sheet 3 of 11

1

UART TX

UART RX

BS2

UART TX>>

UART_RX <<-

BS2 <







