User manual

Star LTE G60:

Statement

To make the best use of your phone is in the state, please read this manual carefully.

For the sake of accuracy, this manual has been validated and reviewed. This manual contains instructions and descriptions of publication is accurate. But after the phone and manual may change without notice. The Company reserves the rights related to this manual!

Directory

One. An Important safety precautions	6
Two. your phone	
1. Mobile Appearance	
1.1 mobile phones appearance	
2.Display	
2.1display site map	
Three. Start using1	10
1. A phone is switched on / off	10
2. installation and removal battery/SIM card/memory card 1	
3. Battery charging 1	
Four. Quick Start Guide1	14
1. Calling features	14
1.1. Call 15	
1.2. An incoming call1	15
1.3. call options 1	
1.4. Call records1	6
1.5. Adjust the volume1	7
2. Enter text	7
Five. Function menu1	18
1. Phone	18
2. People	
2	

3. Messaging	23
3.1. Write new message	24
3.2.Reply to message	24
3.3. New MMS	
3.4. Forwarding information	25
3.5. Delete information	26
3.6. Remove the session	26
3.7. Information setting	26
4. Browser	26
5. Camera	27
Restore the default values: the initial settings	s of the camera
27	
6. Gallery	27
7. Settings	28
7.1 WLAN	28
7.2 Bluetooth	29
7.3 VPN 30	
7.4 Mobile networks	30
7.5 Dual Sim Settings	32
7.6 Display	32
7.7 Date & Time	33
7.8 Language & input	33
7.9 Audio Profiles	33
7.10 Security	34
7.11 App	35
7.12 Factory data reset	36
7.13 Storage	36

7.14 Smart Settings	36
7.15 Timer Switch Machine	36
7.16 About phone	36
8. Calculator	37
9. Calendar	37
10.Clock	37
11.Downloads	37
12.Email	38
Account settings: set E-mail parameters	38
13. File Explorer	38
14. FlashLight	39
15. FM Radio	40
16. History	40
17. Music	41
18. Notes	42
19. Search	42
20.Sound Record	
21. Video player	43
Six. Common problems and solutions	43
Seven .Reference information	47
1. Access password	47
2 Cell phone password	
1.2 .PIN code	
1.3. PIN2 code	
1.4. PUK code	49

1.5. PUK2 code	49
1.6. Barring password	50
2. Health and safety information	50
2.1. Battery	50
2.2 Traffic Safety	50
2.3 Use of the environment	53
2.4 Electronic equipment	53
2.5. Other important information	55
3. Explanation of terms	56

One. An Important safety precautions

Read the following simple instructions, and comply with, Beware of dangerous or illegal. Detailed safety information, see the P48 "Health and safety information"

Traffic Safety first

Do not use the car phone, should be used after stopping

To turn off when refueling

Do not use the phone at the gas station, or near flammable liquids and chemicals agents,

On the plane to shut down

Mobile phones can cause signal interference, cell phone use on planes is not only illegal and dangerous

 ν This set the phone into flight mode, aircraft communication systems, interference can not shut down

In the hospital to shut down

To comply with the various rules and regulations of the hospital, shut down in the vicinity of the medical set

Interference

Mobile communications may be subject to radio interference, radio interference will affect the phone's performance Comply with the special provisions

Comply with the special provisions, and in any place that prohibit the use of cell phones or anything that may cause interference or danger, the phone is turned off (for example, in the hospital)

Rational use of

Use the phone in the normal position (near the ears). Phon e is switched on for no reason, do not touch the antenna Accessories and batteries

Applies only to mobile phone accessories and batteries

Professional services

Installation or repair must be performed by service profess ionals

Two. your phone

The phone is a GSM / EGPRS digital mobile phones. You can read this manual, a comprehensive understanding of the use of mobile phones, a taste of its perfect function and simple operation. Music player

The smart phone. In addition to the basic call and SMS f unctions, also provide you with intelligent text input, cloc k / alarm, front and rear camera, music player (Micro SD card), tape recorders, calculators, browsers, e-mail, FM sc enarios, timer on / off, including a variety of practical fea tures to facilitate your work and leisure activities. In addition, the phone using a personalized man-machine interface design, improved functionality to meet your needs.

1. Mobile Appearance

1.1 mobile phones appearance

2.Display

2.1 display site map

The display consists of three parts:

Range	Description
The first line	Display a variety of stand-icon
	Display the network information, stand
The middle o f the content	by small tools (such as the clock, poi
	nt the king 'and so on, according to

	different type change) desktop functio n icon
The last line	Currently assigned to the function of the t wo soft keys and dial touch buttons

Three. Start using

1. A phone is switched on / off

Press and hold button on phone boot or shut down.

2. installation and removal battery/SIM card/memory card

When you apply for a network, you will get a SIM card, which contains proprietary information, such as the PIN, you can get the service options.

use a SIM card please note the following informatio n:

- all miniature SIM cards should be placed on the c hildren of the reach;
- the SIM card and its contacts can easily scratch o r be damaged due to bending, so
- Carry, to be extra careful when you insert or remove the SIM card;
- Before installing the SIM card, be sure to turn off th e phone and then remove the battery
- Installation and removal of the battery and SIM as follows
 - If necessary, press and hold button until shutdown;
 - > 1, the upward pull from the battery cover;
 - $\mathbf{2}_{\nu}$ lift the battery from the battery to the left buc kle, remove the battery;
 - 3, the SIM card into the SIM card holder, until not move.
 - ♦ The gold contacts of the SIM card face down;
 - The gap of the SIM card, such as the shell at the eidentification;

- To install the battery
- Metal contacts on the first battery at the battery-d eck shrapnel, and then press the battery can be d own:
- Install the battery cover

The first battery cover both ends of the buckle at the back shell groove away, and then the battery cover a nd push down the back cover as shown, to hear the buckle sound can be.

- Installation and removal of the T-flash card.
 - > The phone uses a the clamshell Micro SD deck;
 - Install the T-flash card. Open the clamshell T-Flash card connector, the metal of the T-flash card face down, according to the identity of the shell at the memory card into the slot, will deck down to hear the "label" sound can;
 - Remove the T--flash. Push up the deck to hear t he sound release the "label", you can Remove the memory card

3. Battery charging

- Connect the charger to plug in the power;
- The top of the charger connector into the phone's USB interface.
 - If the charger is turned off, the screen displays c harging video and indicates that the battery charg e
 - If the phone power is low, is still excessive use, charging starts, it may take some time before the charging indicator appears on the screen;
 - When the battery indicator icon is displayed on the screen is full, and no longer flashing, indicates that the charge has been completed.
- During charging, batteries, cell phones and charger s may have a fever, is a normal phenomenon;
- After charging is completed, disconnect the AC p ower outletand mobilephone charger.

Note: The phone battery charge approximately 50% of capacity, which can be used apart. Completely filled i

n and then run out of the first completely; fully charge d and then have to completely run out of second, whi ch requires three consecutive cycles, the battery is ea sy to achieve the best use of the state.

Four, Quick Start Guide

1. Calling features

- When the network provider's logo appears on the d isplay, you can call or answer the phone
- Three interfaces: dial, caller ID and call this function;
- Display the upper-left corner of the information bar shows the network signal strength.
- The call quality by the impact of obstacles, so the move in a small area can effectively improve the si gnal strength.

Note:

 ν In any country using the digital GSM network, if you ar e in the network coverage area (you can check the phon e display network signal strength indicator in the upper I

eft corner learned), you should be able to use the call function.

v If your network provider does not provide roaming services in the region, will be displayed on the display "can make emergency calls (Emergency)", to tell you that only such call 112/911.

 ν If you are in network coverage, even without a SIM car d to make emergency calls.

1.1. Call

- •Click the dial-up icon, enter the dial-up interface
- •Press the number keys, enter the phone number
- •Press the dial key to call
- •Press the end key to end the call.

1.2. An incoming call

New calls when the phone non-standby, press the green answer button Or the side buttons to answer the call; reject a ca Il press the red hang up button

Description:

Insert the headset, you can use the headset key to answer.

1.3. call options

During a call, press the screen display touch screen "opt ion" button to enter the call option.

In the call option, you can proceed as follows:

- > Show dialpad
- Add call
- **▶** Hold
- Mute: turn off the microphone, so the other can no t hear their own voice
- Speaker
- > Record
- > End

1.4. Call records

- Call records in the function menu, View specific information
- Dial-up interface view call records option

1.5. Adjust the volume

Press the side buttons adjust the volume size.

2. Enter text

When editing text, using the Android keyboard or input method of the network to download to edit Chinese, Engl ish, numbers, symbols. Such as adding contacts, editing information.

Switch the input method:

- · Enter the text editing interface;
- · Text editing area, pop-up menu of the edit text;
- Input method in the Input menu, select the input method.

Description: press the number sign key, switch numbers an d symbols input input mode, click on the file to toggle the case of letters.

Five. Function menu

1. Phone

- ·Click the dial-up icon, enter the dial-up interface
- ·Press the number keys, enter the phone number
- •Press the dial key to call
- •Press the end key to end the call
- Call Settings
 - ➤ SIM card 1/2 call settings
 - Fixed Dialing Numbers: Manage Fixed Dialing Number
 - ♦ Voicemail service: My carrier
 - ♦ Voicemail settings: Settings for My carrier
 - ♦ Fast call setting: Edit the Fast call list
 - Reply message Hangup: when you click Inco ming UI, will auto send a message to who call you.
 - ♦ Automatically send information: Whether to auto

- matically send a preset message
- Edit message content: Edit message content a nd point special person
- ♦ Call forwarding: Call Transfer can be set to different circumstances
 - Always forward
 - Forward when busy
 - Forward when unanswered
 - Forward when unreachable
- Call barring settings: Call Transfer can be set to d ifferent circumstances
 - All outgoing: select barring all outgoing, inter national calls or international excluding dome stic;
 - Outgoing international: barring outgoing intern ational
 - Outgoing international roaming: barring outgoing international roaming
 - All incoming : reject all incoming calls, roami

ng reject;

- Incoming calls when roaming: reject incoming calls when roaming
- Deactivate all: the abolition of all the options set. Operation of these options, you need to disable the password;
- Change password: Change Password, enter yo ur password

♦ Additional settings

- Call ID: Use default operator settings to displ
 ay my number in outgoing calls
- Call waiting: During a call, notify me of incoming calls
- IP dialing: open/close IP dialing.
- > IP number list: add/edit IP number
- Vibration: vibration feedback for calls and notifications.
- Auto sleep call screen:Through the g-sensor control during call screen light.

Line2 is to allocate telephone network operators related

Note:

Some settings require network support. Call barring loca I network and SIM card opening of this function to mak e the setting effective

2. People

This feature allows you to browse the address book, store, edit, delete the name and phone number in the phone and SIM card. For the convenience of the records management, the phone set group function and related items in the same group.

Options:

New: New number to the phone, SIM1, SIM2

Contacts to display: Display options settings

Import/Export: Import/export contacts

Accounts: Add, edit accounts

Settings: Set display options

Send contacts by sms/mms: Use sms/mms Send contacts

Batch delete: Batch delete contacts

New:

The function to add a new phone addresses book record. Can be added to the SIM card 1. SIM card or phone, as follows:

 \odot add records in the SIM card memory

Select to SIM card 1 or SIM card 2

ļ

Enter your contact information

ļ

Enter the name and phone number

Enter the Email and groups

↓

Click <SAVE> and save the contact information.

ļ

Select to phone

Ų.

Enter your contact information

1

Name: enter the name

Mobile: enter mobile phone

Edit photo: Take photo or choose photo from

Gallery(Notice: you can remove photo)

E-mail: enter e-mail

Groups:Create new group

More: birthday, Notes, Website, address ...

Click <SAVE> and save the contact information.

3. Messaging

Screen in the standby interface point to enter the main menu, and then select the information, and will enter the 23 information center interface.

- formation Center, including the sub-menu: establishm ent of information, Inbox, Outbox, templates, text mes saging is set;
- This phone can store 5000 SMS, and can store up t o the amount of information due to the SIM is differe nt;

3.1. Write new message

The main screen standby screen, click the information ic on, enter the information interface;

Click the new information, enter New message interface;

Enter the recipient number or select a contact from the phonebook as a recipient

Enter the message content

Click to send, send text messages

Note: The information session in the form of the mobile ph one in order to access the inbox and outbox.

3.2.Reply to message

When new information is received, the top event notificat

ion indication bar display and the corresponding prompt reply, you can view information

Short message list interface, click the corresponding ses sion records

Enter the reply

Click Send to complete the reply

3.3. New MMS

- The main screen standby screen, click the information ic on, enter the information interface;
- Click the new information, enter the new editing interfac e;
- Enter the recipient number or select a contact from the phonebook as a recipient
- Press the Menu key, choose to add the theme to input MMS theme;
- Editorial content, insert images, audio;
- Click to send, send MMS.

3.4. Forwarding information

- main standby screen interface, click the information icon, enter the information interface;
- Open a session record, tap and hold a message, select the forwarding information.

3.5. Delete information

- main standby screen interface, click the information butt on, enter the information interface;
- The point hold the record of a session, choose to delet e the session;
- > Press OK to delete the message.

3.6. Remove the session

- main standby screen interface, click the information butt on, enter the information interface:
- open a session record, tap and hold a message, choose to delete the session;
- Click the confirmation to remove the session

3.7. Information setting

The relevant parameters of the setup information, such a s: SMS limit, send a report.

4. Browser

Open a Web page

- 1. On the home page, click your browser
- 2. Click on the URL input field.

3. Enter a URL, click here

Tip: Press the menu key, but also more features.

5. Camera

- The camera options are as follows:
 - > Photo: Open the photo to view the photos.
 - > Photo settings: set the photo size and photo quality
 - > Picture quality:Super fine,Fine, Normal
 - Scene mode:Action,Night,Auto,Normal,Portrait,Landsc ape
 - Burst:3,6,9,off

White Balance: White balance settings, you can choo se incandescent,sunlight, fluorescent,auto,daylight,cloudy

> Color Effect:None,Mono,Negative,Sepia,Cold,Antique

Restore the default values: the initial settings of the camera

6. Gallery

- 1. Click the gallery on the home interface
- 2. You want to see the picture
- 3. Sliding around in the horizontal direction, touch screen,

you can switch to the previous or next image.

- 4. If you want to play slide, please click the slide show
- To share or edit images, please click on the menu to s elect the appropriate option.
- If you want to set picture as contact photo or wallpaper, pleace click on "set as" option

7. Settings

In the idle screen, tap the screen to enter the main menu, then select Settings, and will enter the setting interface.

You can you use this menu option used to set up your phone.

7.1 WLAN

- In the Home interface, click Settings>Wireless and network.
- 2. Click the WLAN to turn on the WLAN capability.

Tip: When the phone battery is very low, in order to pr otect the data in the system, will be prohibited to open Wi-Fi capability.

3. Click on the WLAN settings, Wi-Fi network will display t 28

he search to the network name and security settings.

Tip: When you select an open network, the phone will auto matically connect to the network; if you select an encrypte d network, you must first enter the password for the (securit y), and then click the link.

4. Click on a Wi-Fi network can be connected.

Tip: After a successful connection, the status bar will displ ay the Wi-Fi icon and displays the signal strength at this ti me, your phone has access to the network.

7.2 Bluetooth

- 1.Click on the home interface Settings> Wireless and net working.
- 2. Click the Bluetooth to turn on the Bluetooth function.

Tip:

- Opens the phone to automatically search for visi ble Bluetooth devices nearby, and display the Bl uetooth icon in the status bar.
- · When the cell phone battery is low, in order to

protect the data in the system will be prohibited to open the Bluetooth function.

- Click on the Bluetooth settings Bluetooth devices scan t o select the equipment you want to connect
 - 4. Enter a pass code to pair connection.

Tip: When paired and connected after the success of the status bar will display the Bluetooth transmission ic on, you can with the Bluetooth devices transfer data.

5. You can rename a bluetooth by rename phone ,set Visibility timeout or view the receiving or sending files by Show receives files

7.3 VPN

Add, setup and manage virtual private network.

7.4 Mobile networks

- Airplane mode
 - Open / close airplane mode.
- Portable hotspot

Use your phone as a Portable WLAN hotspot

- Mobile networks
- 1.Click on the Settings
- Click on the mobile networks into the mobile network se ttings.
- Data enabled: Check this box to connect to login_After successful login, Phone status bar will appear to the 3
 G network connection icon, After that you can normal use of the Internet-related applications on the phone.
- Data roaming: Check this when the phone is in roa ming state can also be the normal use of the Inter net-related applications on the phone.
- UPLMN setting
- Preferred network type:Preferred network mode:WCDM
 A preferred
- Access Point Names: Select Access Point.
- Network operators: To enter this menu, you can cond uct a web search and automatic selection of network operation.

Tip: the opportunity according to the user to insert personal identification card (USIM/SIM/UIM) to automatically select the network. Tip: the opportunity according to the user to insert personal identification card (USIM / SIM / UIM) to automatically select the network.

7.5 Dual Sim Settings

Dual SIM settings: voice telephony, information and data con nections need to set the use of

7.6 Display

- Brightness: the brightness slider to the left to reduce the brightness of the screen, drag to the right you can increase the brightness.
- Auto-rotate screen: the screen will automatically rotating horizontal screen or vertical screen
- Wallpaper: Change wallpaper
- Sleep: adjustment screen to be automatic locking the delay before

- Font size: Select a font size
- Notification Calendar: Check or cancel Notification Calendar

7.7 Date & Time

Set the city, time and date display format

7.8 Language & input

Select a language and keyboard settings

7.9 Audio Profiles

- Profile: The scene modes include: General, Silent, Vibration, outdoor
- Volume: adjust the volume
- SIM 1 Phone ringtone: Set SIM1 ringtone
- SIM 2 Phone ringtone: Set SIM2 ringtone
- Notification ringtone : Select the notification you want to use ring tones
- Dial pad touch tones: Play tones when using dial pad

- Touch sounds: Play sound when marking screen selection
- Screen lock sounds: lock and unlock the screen to play a sound
- Vibrate on touch: Vibrate when pressing soft keys and on certain UI interactions.

7.10 Security

- You can set up your phone menu security options, to a void illegal use of your phone or SIM card.
- Set up screen lock: use pattern, PIN or password to lock the screen
- Set up SIM1 card lock: open that need to enter a PIN lock password every time you start, otherwise you cannot us e the SIM card; settings, enter the correct PIN code. Thre e input error when asked to enter the PUK (Personal Unbl ocking Key). PUK code is used to unlock and change a bl ocked PIN code and PUK code is not provided or missin g please contact the network operator.
- Set up SIM2 card lock: The same as SIM1

- Visible passwords: the password visible when the input
- Select device administrators: Add or remove device administrators
- Manage applications: management and remove the instal led applications
- Use secure credentials: Allows applications to access the e security credentials and other documents
- Install from SD card: Install encrypted certificates from SD card
- Clear storage: clear all the contents of the certificate store and reset their passwords

7.11 App

- Running services: view and control services that are curr ently running
- Storage use: Check the storage space used by the application

7.12 Factory data reset

Factory date reset: Clear all the data on the phone

7.13 Storage

Show the total mobile phone SD card capacity, free space

- Install the SD card: Insert the SD ca rd to install
- Formatting the SD card: clear all data in the phone's SD card, such as music and photos

7.14 Smart Settings

Assistive Touch: Turn on/off Assistive Touch

7.15 Timer Switch Machine

Can be set to the time of the Switcher, off by default

7.16 About phone

Display the phone's some basic information, such as: stat us messages, electricity usage, legal information, phone mo del, version, etc.

8. Calculator

Display prompts, press the number keys on the screen calculator function.

9. Calendar

Open or close of the calendar view, but also the option to vie w a note, skip a specified date.

10.Clock

Set time and date, and alarm clock

11.Downloads

You can download some new content to your phone (Hint: Use only the services of your credit and their sup pliers can provide the necessary security protection, to r esist the intrusion of unwanted software, please contact your service provider offers different services and charge s)

12.Email

Before using the e-mail function, please set the e-mail account

- Send and receive: automatically send e mail in the Outbox and receive new mail.
- Edit E-mail: edit an e-mail
- Inbox: Displays the current account to receive mail.
- Refresh: Refresh the inbox.
- Compose: Edit an e-mail
- Folders: Switch Inbox, Drafts, Inbox, Sent.
- Accounts: Add or edit an account.

Account settings: set E-mail parameters

13. File Explorer

In the standby interface points into the main menu, then select the file management, access to the file management interface.

This feature needs to insert the T-FLASH card can be u 38

sed. Tone file and image files to be managed through this module.

- Graphics files can be sent to the wallpaper, screen s aver on / off animation can also be sent as an MM S;
- Tone file can be sent to the scene mode, set caller r ing tones, SMS ring tones, alarm tones can also be sent as an MMS
- File management options include:
 - > Open: open the folder or file
 - > Folder: new folder in the storage card or folder
 - > Formatting: Formatting the memory card
 - This operation will delete all the data in the stora ge
 - Remove: Select the memory card, you can perform t o remove function to remove the memory card in a safe.

14. FlashLight

Turn on/off Flashlight

15. FM Radio

FM radio , Must to be plug in your headphones into the FM radio interface can listen to FM radio

Search Channel: Please click the Search button, it will a utomatically search for channels, when the search will a utomatically stop after a channel searched.

Fine-tune the channel: When search to a channel please click on the search button next to the fine-tuning, fine-t une the operation of the channel can be.

Speaker Play: when click the headset button, switch to the speaker playing the radio

Background Play: Touch HOME key to exit the FM radio.
Play FM radio into the background.

16. History

When you place, answer, or miss a call, a record of the call is saved in the History.

Deleting Call log records

1.From the Home screen, touch i → History

- 2.While viewing the Call log, touch Menu→Clear call logs
- 3.Touch call records to mark them for deletion, or touch Select all. A check appears in the check box to show marked records.
- 4. Touch **Done** to delete marked records.

Filtering Call log records

- 1.From the Home screen, touch **→** History
- 2.While viewing the Call log, touch **Menu→View**
- 3.Select a filter type, from All call logs, SIM1 call logs, SIM2 call logs Filtering Call log records

17. Music

- Play: Play the OK key or press the play button.
- Pause: pause the music player, press the OK but ton or point press the pause button.
- Stop: press the pause button to stop playing pres s the * key or point.
- Switch songs: according to the list to select a so ng, press the option key to switch songs in the p

layer interface.

- volume adjustments: up and down the side button s to adjust the volume or pen point increase and decrease the volume icon
- Use as phone ringtone: Press a musical can be set as ringtones

18. Notes

Create / Use notes

19. Search

You can use the Google Search on the home page to search for information on the network.

- 1. Click on the Google Search Gadget
- Enter in the Google Search bar, enter the text you want to s earch.

20.Sound Record

"record " button to select the cursor where the corresponding functions through the screen in accordance with the dis

play prompts, Can be realized recording, playback, attach, r ename, delete, send and other functions, you can also set t he audio file storage format.

21. Video player

Play the videos in the storage device.

Six. Common problems and solut ions

Before and after-sales service contact, follow these simple checks, you might be able to avoid unnecessary maint enance time and cost of waste.

Frequently	Causes and solutions
Asked Que	
stions	
Cannot boot	■ n check whether to hold the power butto
	n for at least one second;
	■ Check the battery connection is bad, ple
	ase remove and then reinstall and retry t
	he boot;
	■ Check the battery power is exhausted, pl
	ease charge ;

Unable to c	■ n signal weak, please move to the stron
onnect to th	3 , , ,
e network	outside the network service provider's net
e network	
	work to cover;
	SIM card is invalid, contact your network
	provider;
Boot time, t	,,
he display i	whether SIM card is installed correctly
nformation	■ phone lock password, set the phone loc
	k, phone password must be entered prior to use;
	■ enter the PIN, chose to enter the PIN ev
	ery time you turn, you must enter the PI
	N code:
	■ PUK code: the connection three times t
	o enter the wrong PIN code will lock the
	SIM card, you should enter the network
	operators to provide the PUK code;
Poor call g	
uality	ropriate
	use of mobile phones in poor reception
	areas, such as high-rise near or baseme
	nt, radio waves can not be effectively co
	mmunicated;
	use of mobile phones in the call-intensive
	period, the above working hours, line co
	ngestion caused not call;

Standby tim	■ Standby time network system settings, w
e is shorter	hich may in a poor reception area. When no signal is received, the phone will continue to launch in order to find the base station, consume a large amount of battery power, resulting in the standby time is shorter. Move to a strong signal or tem porarily turn off the phone; need to replace the battery, replace the
SIM card er	new battery
	■ SIM card metal surface dirt, with a clea
ror	n cloth, wipe the SIM card metal contact points;
	■ the SIM card is not installed; n SIM car
	d is damaged, contact your network servi ce provider.
Can not ma ke calls	Make sure whether to press the dial key after dialing;
	■ Make sure whether to be banned due to arrears call:
	■ Please Confirm SIM is valid;
	■ Please confirm whether the call barring
	feature is set;
	■ Make sure to set fixed dialing;

The recipie	■ Make sure the phone is switched on, an
nt is unable	d connect to the network;
to contact	■ Make sure whether to be banned due to
you	arrears incoming;
	Make sure the SIM card is valid;
	■ Please confirm whether the call barring
	feature is set;
	■ Make sure to set fixed dialing;
Can not be	■ bad contact, check the plug is connecte
charged	d;
	■ charge in less than 40 ° C or above 55
	° C environment, to change the chargin
	g environment;
	■ battery or charger is damaged, in need o
	f replacement
Some featur	operating error;
es can not	
be set	■ network provider does not support this fe
	ature, or you did not request this

Seven .Reference information

1. Access password

The phone and SIM card to use several access passwords. These passwords help protect your phone from unauthorized use.

Security Settings option in the main menu settings can be used to modify the access password (PUK and PUK2 codes excluded), see page P11.

2 Cell phone password

The phone password can be used to prevent unauthoriz ed use of mobile phones. Select Phone Password featur e, every time you turn the phone automatically locked, y ou need to use a password to open the phone lock.

- Before start using the phone, it is recommended that you modify the phone password.
- A new password for confidentiality and kept in a safe place, the best mobile phone separate.

1.2 .PIN code

PIN (Personal Identification Number) protects your SIM c and stolen. Usually provided with the SIM card PIN code.

Need to enter the PIN code every time you turn to sel ect the PIN test.

If the PIN code three times in a row input errors, sh ould enter the PUK code, then enter the new PIN co de to confirm re-enter the new PIN code again and c onfirm.

1.3. PIN2 code

Some SIM cards may provide PIN2, the PIN2 code, cert ain features are in use, such as call billing. Only the SI M card supports these features in order to use these fe atures.

If the PIN2 code three times in a row to enter the w rong PUK2 code, then enter the new PIN2 code conf irmation, re-enter again a new PIN2 code and confir m.

1.4. PUK code

The PUK (Personal Unblocking Key) used to change you r PIN locked. The PUK code is provided with the SIM c ard. If not provided, please contact your local service provider to ask for the PUK code.

- If the connection is ten times enter the wrong PUK c ode, SIM card can not continue to use please contac t your ISP to replace the new SIM card.
- The PUK code can not be changed. If you have lost the PUK code, please contact the service provider.

1.5. PUK2 code

PUK2 code, supplied with some SIM cards. Used to change the locked PIN2 code.

- If the connection is ten times enter an incorrect PUK 2 code, SIM card will no longer continue to use the new SIM card,
- PUK2 code can not be changed. If lost, please conta ct the service provider.

1.6. Barring password

Call barring, 4 barring password. To apply this function, you can get the password from your service provider.

2. Health and safety information

2.1. Battery

- Do not short-circuit the battery device, which will dam age the battery to generate heat and may cause fire.
- Prohibit the battery in hot or thrown into the fire, this will cause an explosion. Used batteries should be re turned to the supplier or on the designated collection points, and can not be placed in household garbag e.

2.2 Traffic Safety

The wireless phone has a powerful voice communication function, almost at any time, anywhere communications and liaison. But there are a number of important respons ibilities, have the advantage of the wireless phone, each 50

user must fulfill these responsibilities.

While driving, driving is your primary duties, answer the phone while driving should be vigilant and keep in mind the following tips:

- Understanding of the wireless phone and its features, such as speed dial and redial. If these features can help you make a call, rather than to make your drivi ng hours of heart.
- If hands-free device, you should use a hands free. If possible, use either supply hands-free accessories th at you can improve the convenience and security of wireless phone use.
- Wireless phone is placed in an easy-to-find place. Do not need to divert attention from the road, you can use the phone. If you receive an incoming call at an inconvenient time, as much as possible to apply the voice mail answers the phone.
- Told to call each other in your car; hang up when ne

cessary, in the case of traffic jams or bad weather. R ain, sleet, snow, ice and even heavy traffic is very d angerous.

- Airbags, brakes, speed control system and fuel injecti on system should be free from the influence of wirele ss transmission. If you are experiencing the problems mentioned above, please contact the car dealer.
- Please turn off your phone when refueling, the same situation also applies to prohibit the use of two-way wireless devices. Please do not flammable, explosive materials and the phone on with the internal spark m ay cause a fire.
- Turn off the phone before the plane took off. In order to prevent interference with aircraft communications systems, never allowed to use the phone in flight. Co nsent in accordance with the safety requirements for the crew to allow before take-off of the aircraft did n ot use the phone.

Set to flight mode of the phone will not communic ation system of the aircraft interference can not s hutdown.

2.3 Use of the environment

- Should comply with this no matter where the special provisions, and turn off the phone when in use or m ay be dangerous.
- When connected to the mobile phones and other devices, you should read the user manual to learn more about the safety instructions, you can not connect with incompatible products.
- As with other mobile radio transmitting equipment, it is s recommended that users: For satisfactory use of the e equipment and personnel security, and should only be used in the normal work location.

2.4 Electronic equipment

Most electronic equipment is shielded from RF signals. However, some electronic equipment may not be shielde 53 d against the RF signals generated by the wireless hand set.

Pacemakers

- When the phone is switched on, must be kept aw ay from pacemakers six inches (15cm) above the distance:
- phone should not be carried in a breast pocket;
- use of the pacemaker on the other side of the ear to answer, may cause interference to reduce to a minimum.

■ Hearing aids

Some digital wireless phones may interfere with some he aring aids, if there is such interference, the deliberations of substitutes can be used with your hearing aid manuf acturer.

Other medical devices

If other personal medical devices, please consult the device manufacturer, to confirm these equipment is shielded from external RF energy. Physician can help you obtain

this information.

Posted notice of the place

Posted a notice to shut down places to turn off the phone.

2.5. Other important information

- Use only the first wife or by the manufacturer approved accessories. The use of any unauthorized accessories, there may affect the use of the phone's perform ance, damage your phone, and even lead to physical danger or violation of the relevant provisions of the national communication terminal products.
- Clean your phone use a slightly damp or antistatic cl oth, do not use dry or easy to produce static cloth.
 Clean the surface of the phone, be careful not to us e cleaning agents, chemicals. Cleaning your phone, p lease turn off.
- Your phone will generate electromagnetic fields, pleas

e do not place magnetic storage medium such as co mputer disks and the like. Use the phone near the te levision, telephone, radio and personal computers and other electrical equipment may cause interference, th us affecting the performance of the phone.

- Do not your mobile phone exposure in strong sunligh t, avoid heat.
- Avoid all kinds of liquid into the phone's internal, so as not to cause damage.
- Do not drop, knock the phone Rough handling can b reak internal circuit boards.
- Please do not connect with other ancillary equipment.

3. Explanation of terms

To help you understand the main technical terms and ab breviations in this manual, as well as better use of the phone functions, the following provides a definition of the meaning of some words.

ALS (Exchange line services)

ALS provides a function to join two lines with one SIM c ard. The use of the services needed to make and receiv e calls with any one line.

Dual card dual standby

Support dual card dual standby mobile phone user to ins ert two cards and two cards can be properly registered, can realize the two card standby at the same time and normal calls, SMS and other functions, including the realization of the two cards will also call the function.

Call barring

Limit cell phone to make and receive calls the function.

Call Transfer

Calls go to another mobile phone or fixed line telephone functions.

Call on hold

Receive or make calls, keep another phone; when you n

eed it to switch between the two calls.

Call Waiting

During the call, inform the user there was another call.

Line Identification Service (Caller ID)

Through the service, users can view the Caller ID or do not make their numbers displayed in each other's phon e network functionality..

GSM (Global System for Mobile Communications)

Cellular communications international standards to ensure compatibility between different network operators. The G SM system covers most European countries and in man y places around the world.

Multi-party call

Create up to 5 people at the same time participate in the call of the conference call function.

Roam

Use of mobile phones (such as tourism) in the local ser vice area.

SIM (Subscriber Identity Module)

The SIM card contains a chip, in which there is required to use the phone (network and memory information, and user personal data). The SIM card can be inserted into the small slot of the phone behind the battery protection.

SMS (Short Message Service)

To another network user to send or receive information f rom another user no need to call with the other network service functions. Information can be generated or received, receive, edit or send.

Voice mail

Computer answering service. When you can not answer a call, the service functions of automatic answering their own voice (optional) sends greetings, and record inform ation.

Other

GPRS General Packet Radio Service

SMS-CB Broadcast messages

WAP Wireless Application Protocol

FDN Fixed number dialing

IMEI International Mobile Equipment Identity, 15 digit

s, a mobile phone corresponds to a unique IM

El number

FCC Warning:

This device complies with Part 15 of the FCC rules. Op eration is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may c

ause harmful interference to radio communications. Howe ver, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, whi ch can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and re ceiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technici an for help.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue.

Device types Star LTE G60 (FCC ID: 2AC7IEKOSG60) h as also been tested against this SAR limit. The highest

reported SAR values for head, body-worn accessory are 0.67 W/kg, 0.78 W/kg respectively. The Max simultaneou s SAR is 0.93W/kg. This device was tested for typical b ody-worn operations with the back of the handset kept 1 0mm from the body. To maintain compliance with FCC R F exposure requirements, use accessories that maintain a 10mm separation distance between the user's body an d the back of the handset. The use of belt clips, holster s and similar accessories should not contain metallic co mponents in its assembly. The use of accessories that d o not satisfy these requirements may not comply with F CC RF exposure requirements, and should be avoided. The antenna(s) used for this transmitter must not be co-l ocated or operating in conjunction with any other antenn a or transmitter.

Canada Warning:

This device complies with Industry Canada license-exem pt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful i nterference, and (2) this device must accept any interference received, including interference that may cause und esired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment. This radio transmitter (identify the device by certification number or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

The SAR limit for Industry Canada is 1.6 W / kg averag

ed over one gram of tissue. The Star LTE G60 device t vpes (IC No .: 23321-EKOSG60) were also tested again st these values. The highest SAR values reported for th e head, the accessory worn on the body are 0.67 W / k g, 0.78 W / kg, respectively. The maximum value of the simultaneous SAR is 0.93W / kg. This device has been tested for typical operations using the accessory worn on the body with the rear part of the handset kept at 10m m from the body. To maintain compliance with RSS-102 requirements, use accessories that maintain a separation distance of 10 mm between the user's body and the ba ck of the handset. The use of belt clips, cases and simil ar accessories shall not contain any metal components a s a whole. The use of accessories that do not meet the se requirements can not meet the requirements of RSS-102, and should be avoided.

Cet appareil est conforme à la aux normes RSS de l'Industrie du Canada. Son fonctionnement est soumis aux d

eux conditions suivantes : (1) cet appareil ne doit pas c auser des interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interfér ences qui peuvent provoquer un fonctionnement indésira ble.

Le fabricant n'est pas responsable des toutes interférenc es radio ou télévision causées par des modifications non autorisées apportées à cet appareil. De telles modificati ons peuvent empêcher l'utilisateur d'utiliser l'appareil.

Le présent émetteur radio (identifier le dispositif par son numéro de certification ou son numéro de modèle s'il fai t partie du matériel de catégorie II) a été approuvé par I ndustrie Canada pour fonctionner avec les types d'anten ne énumérés ci-dessous et ayant un gain admissible ma ximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

La limite DAS de l' Industrie du Canada est de 1,6 W / ka en movenne par gramme de tissu. Les types de péri phériques Star LTE G60 (IC No.: 23321-EKOSG60) été é galement testécontre ces valeurs. Les plus haut valeurs SAR reportés pour la tête, l'accessoire porté sur le corp s sont de 0.67 W/kg, 0.78 W/kg, respectivement. La val eur maximale du DAS simultanée est 0.93W/kg. Ce disp ositif a été testé pour les opérations typiques en utilisant l'accessoire porté sur le corps avec la partie postérieur e du combiné gardé à 10mm du corps. Afin de maintenir la conformité aux exigences de la RSS - 102, utilisez d es accessoires qui maintiennent une distance de séparati on de 10 mm entre le corps de l'utilisateur et la partie p ostérieure du combiné. L'utilisation de pinces de ceinture, étuis et accessoires similaires ne doivent pas contenir d e composants métalliques dans son ensemble. L'utilisatio n d'accessoires qui ne satisfont pas à ces exigences ne peut pas se conformer aux exigences de la RSS - 102, et devrait êtreévitée.