Anker® Ultra-Slim 2.4G Wireless Keyboard and receiver

Welcome Guide

FCC ID:2AC9LHW098-R

Package Contents

Anker Ultra-Slim 2.4G Wireless Keyboard USB wireless receiver Welcome Guide

Product Overview



- 1. Media
- 2. Play / Pause
- 3. Last Song
- 4. Next Song
- 5. Volume Up
- 6. Volume Down
- 7. Mute
- 8. Home
- 9. Search
- 10. Bookmark Webpage
- 11. Power Off
- 12. Insert
- 13. Print Screen
- 14. LED Indicator
- 15. Battery Insertion Slot
- 16. USB Wireless Receiver
- 17. On / Off Switch

Specifications

Wireless Specification	2.4G wireless
Product Dimensions	285 × 122 × 19mm / 11.2 × 4.8 × 0.7in (L × W × H)
Product Weight	189g / 6.7 oz
Operating Range	Up to 10 meters / 33 feet
Modulation System	MSK
Battery Type	2 AAA batteries
Working Temperature	-10°C to +55°C
Key Life	3 million clicks
System Requirements	Windows 8 / Windows 7 / Windows Vista / Windows XP

Setup Instructions

- 1. Open the battery cover on the back of the keyboard and take it off.
- 2. Insert two AAA batteries (not included).
- 3. Take out the USB wireless receiver from the battery slot and plug it into your computer's USB port.
- 4. Replace the battery cover and you are ready to begin typing.

Replacing Batteries

When the batteries are running low, the LED indicator will turn red and begin to flash. Replace the AAA batteries to continue typing.

Troubleshooting

If you have any problems using the keyboard, or you're using a new Anker receiver, try the following steps to pair the keyboard and receiver together again:

- 1. Unplug the USB receiver and then plug it back into the computer USB port.
- 2. Press the ESC and Q keys at the same time. The LED indicator will flash rapidly for about 5 seconds and then go off. The receiver is now successfully paired to your keyboard.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.