GETTING STARTED

- 1. Make sure all items listed in the BOX CONTENTS are included in the box.
- 2. READ ASFETY INSTRUCTIONS BEFORE USING THE PRODUCT.
- 3. MAKE SURE THAT YOU HAVE COMPLETELY CHARGED THE BATTERY PROR TO FIRST USE FOR MAXIMUM BATTERY LIFE.

Go to <u>www.playwithyourproxy.com</u> for product registration.

BOX CONTENTS

- Proxy
- Wristband
- Micro USB Cable
- **Power Adapter**

BUTTON FUNCTIONS



Power On: Press and hold button for 4 seconds to power on Power Off: Press and hold button for 2 seconds to power off

Press button to activate Siri/S-Voice Launch Siri/S-Voice: Press button to cancel Siri/S-Voice Cancel Siri/S-Voice:



Lower Volume: Press and hold button to lower volume Previous Song/Video:

Press button to play previous song/video



Answer: Press button to answer incoming call

Hang-up Call: Press button to hang-up call

Ignore Incoming Call: Press and hold button for 1 second Play Song/Video: Press button to play song/video Pause Song/Video: Press button to pause song/video Connect Proxy: Press button (Must already be paired) Press and hold button for 3 seconds Disconnect Proxy:



Increase Volume: Press and hold to increase volume Next Song/Video: Press button to play next song/video

PAIRING A BLUETOOTH DEVICE

- 1. Press and hold the power button for 4 seconds. The Proxy's Red and Blue LEDs will blink rapidly.
- 2. Navigate to your Bluetooth device's setup screen, find "The Proxy" and connect.
- 3. If your device asks for a password or pin, skip or cancel the password or pin input screen.
 - **Note:** The next time you approach The Proxy with your Bluetooth device, it will automatically re-pair.
- 4. To pair a new device, press and hold the phone button for 3 seconds to break the current connection. The red and blue LEDs will flash repeatedly. Repeat Step 2.
- If your Bluetooth device is not able to pair to The Proxy, hold phone button for 3 seconds to break previous Bluetooth c connections and power the Proxy off, then back Note: If you experience trouble pairing or playing music update your devices's OS.

PROXY LED ACTIVITY

- Blinking Red and Blue LEDs Not Paired/No Connection
- Blinking Blue LED Paired and Connected
- Solid Red LED Charging
- Blinking Red and Blue LEDs In Broadcast Pairing Mode
- No LED activity
 No Powered on/Sleep Mode

The Proxy Model No: TP0603V1 Safety Information

IC

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Modification or changes to this equipment not expressly approved by Radio Systems® Corporation may void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a specific installation. If interference does occur to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- a) Reorient or relocate the receiving antenna.
- b) Increase the separation between the equipment and the receiver.
- c) Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- d) Consult customer care, the dealer, or an experienced radio/TV technician for help.