



Visit http://ikegps.com/ike-4/ for software updates • manuals • tutorials • videos

contents

introduction X
what's in the box X
IKE 4 system overview X
system setup X
IKE 4 tripod X
IKE Field – how it works
IKE Office X
IKE Field X

Introduction

Thank you for purchasing the IKE 4 Your IKE 4 is a location-based measuring solution that will greatly increase your productivity when undertaking utility asset management surveys and related measurements. The IKE 4 integrates a digital camera, compass, laser range finder, mobile computer, and precision GPS.


With your IKE solution you can quickly:

- Collect geo-located pole photos
- Measure wire span heights, even across busy roads
- Determine wire clearances from vegetation or buildings
- Make accurate attachment height measurements on captured photos

This document will guide you through:

- Setting up your IKE system
- Making in-field measurement tasks
- Transferring data from the IKE Field to IKE Office
- Measuring attachment heights from a photo
- Outputting data in industry standard file formats


What's in the box



- 1 IKE device
- 2 USB car charger
- 3 power cable
- 4 micro USB cable
- 5 AC charger with plug adapter
- 6 screwdriver
- 7 shoulder strap for hard case
- 8 hard case (not shown)

A SIM card and SD card are not included.

IMPORTANT: The IKE 4 device is designed to be used with the IKE Tripod. It should not be used while being held by hand or placed close to the user's body.



IKE 4 system overview

Plan

Design a form or import a Spida Client file



Capture

Make measurements and capture data in your forms using the IKE Field device



Upload

Upload data to IKE Office over Wi-Fi



Measure

Use Photo Measure in IKE Office to measure pole attachment heights



Export

Export your collections to one of the following formats: KML, JSON, PDF or SPIDA

system setup

IKE 4 software

IKE Office

IKE Office makes data transfer from your IKE Field device simple. Customize and deploy forms directly to your IKE Field device and export various file types from captured data. Make accurate photo measurements and save marked-up photos.

IKE Field

Your device has been shipped with the latest factory software — your installed version shows on the IKE Field device main screen. However, the team at IKE regularly makes product improvements. Updates will be delivered to your device via the Google Play store. You only need to update the software when prompted, and you will stay up to date.

IKE 4 documentation

IKE 4 setup guide

A guide to getting started with your IKE field device

IKE 4 user manual (this guide)

The most comprehensive A-Z guide to using your IKE device

IKE 4 fieldcraft guide

How to get the best results from your IKE, tips and tricks to improve performance, accuracy, and productivity

additional software

- Web Browser IKE Office supports Internet Explorer 11+, Firefox and Chrome browsers.
- Google Earth™ View your data and measurements by clicking on their location on aerial photographs.

IKE 4 tripod

Your device is designed to be used with the IKE 4 tripod, which provides a stable platform to obtain the most accurate results when measuring objects such as target poles and wires. The tripod has a low magnetic signature that will not affect the IKE device's compass, which helps provide accurate measurements.

Important: Tripods other than the IKE tripod will likely produce less accurate results than the IKE tripod.




IKE Field – how it works



IKE Field

IKE Field
Signing In
Settings
Creating a job
Downloading forms
Starting a collection
Viewing the map
Uploading data
Making measurements

signing In



1. Sign in to the application with the same email and password as you used for IKE Office.

This user information will be saved, so the next time the application is opened it will already be logged in to the most recent account.

settings



After turning on the IKE, navigate to the device's **Settings**.


There are four (4) separate **Settings** sections:

- Wireless & networks
- Device
- Personal
- System


Each will be discussed briefly, in general.


Wireless & networks

- Wi-Fi touch Wi-Fi, and then touch the slider to move it to the On position. Chose a wireless connection.
- Turbo download touch Turbo download to download large files (>20 MB) faster, using the Wi-Fi and 4G/3G networks simultaneously. Touch the slider to move it to the On position.
- Bluetooth touch Bluetooth, and then touch the slider to move it to the On position. Choose a Bluetooth device
- Data usage touch Data usage to check daily and total data usage. Default is OVERVIEW. Touch Wi-Fi to view app usages. Touch available monthly segments to compare across time.



- *** More Touch *** More to access
 - Airplane mode
 - Tethering & portable hotspot
 - VPN
 - Cellular networks





settings




1. After turning on the IKE, navigate to the device's **Settings**.

- 2. Move to the Wireless & networks section.
- 3. Select the router you want.
- 4. Enter the router's password and select **CONNECT**.

For extended Internet coverage, use a standard AT&T SIM card, or a micro or nano card with an adapter, in the IKE SIM card slot under the battery.

Refer to **IKE 4 Training Module 4** for further details.




Settings > Device > Display


There you can change

- Brightness level
- Adaptive brightness
- Sleep

Change the **Brightness** level for easy viewing.

Adjust the **Adaptive brightness**, depending on the light in your environment.





Change the **Sleep** mode setting to save battery life during periods of inactivity.

6. Navigate:


Settings > Personal > Location


Touch **Location** to manage:

- Location settings
- Satellite-based augmentation systems (SBAS)

For the IKE device's GPS to function correctly, SBAS must be turned on

- **Location** touch **Location**, and then touch the slider to move it to the **On** position.
- **SBAS** touch the **SBAS** slider to move it to the **On** position.





IKE Settings

1. Sign in to the IKE Field app, using the same sign in information as the IKE Office account.

The app opens to the **My Jobs** screen.

2. On the My Jobs screen, touch the


More icon () in the upper-right of the screen.

3. Touch **Settings**.

Now you can change

- the **Date Format**
- the Measurement Unit.
- 4. Touch **Date Format** to choose between MM/dd/yyyy and dd/MM/yyyy formats.
- 5. Touch **Measurement Unit** to choose between feet and meters.


creating a job




- 3. Enter the name of the Job.
- 4. Touch ATTACH FORM.

When connected to the Internet, the page will automatically check for available updated and new forms.

- 1. To create a job, navigate to the My Jobs screen.
- 2. Touch the orange plus icon •.







5. Tap DOWNLOAD to download the latest forms.

When forms are downloaded, you have access to them, even without Internet connectivity.

6. Select the form you want to use.









7. When the job has a name and a form attached to it, tap the **CREATE** button in the top right.

To ensure you have the resources for data collection, we recommend creating a job and applying the form before going on site. If your IKE device has a SIM card or Wi-Fi connectivity in the field, you will be able to receive form updates.

8. The **My Jobs** screen shows all of the jobs on the device. Select the Job you wish to work on to proceed.







9. Now you are ready to start collecting form data. Tap the • button to create your first collection.

10. You can enter data directly into the on-screen form and use tools to make measurements.


Anything with a plus button can be repeated multiple times.






11. Tap the • next to equipment sub-form to start collecting data about that attachment.

12. When you have collected all of the information about the equipment, click the done button at the top right.








13. You can see that one piece of equipment has been captured.

Tap the **Save** icon to keep this information. Tap the **Back** icon to go back to the Job screen.

14. The Job screen shows all of the collections you have made for this job in both a list and on a map.


Tapping the down arrow next to a collection shows a summary.






15. The summary gives you an overview of a collection by showing which sub-forms have been collected.

- 16. Tapping the Map tab shows your collections for this job on a map.
- 17. Tapping the will take you to the form screen to add another collection.
- 18. Tapping on the location balloon will take you to that collection.



uploading data



After you've collected the data, you will want to upload the data to the IKE Office.

- 1. Re-establish a Wi-Fi connection or utilize a data package through an AT&T SIM card, if necessary.
- 2. Return to the jobs list on the **My Jobs** screen.
- 3. Touch the gray, outlined circle to the left of the job name.
- 4. Ensure the number to the left of the job becomes highlighted in gray and the correct number of selected files is indicated at the top of the screen.
- 5. Touch the upload arrow to upload your job.

A dialog box indicates the status of the upload and indicates when successful.

After uploading, the job is paired with an orange, uploaded circle.


Now you can view the job in IKE Office.

After uploading your files, we recommend exiting the IKE Field app prior to powering down the IKE device.




making measurements

Local GPS Position




2. For the Local GPS position tool, the current accuracy shows the expected accuracy of the position. Pressing **START** begins averaging GPS data over 30 seconds to get the best accuracy. Try not to move or cover the device during this process.



3. Counting down

4. Location captured. The green pin on the map shows the location captured. The blue dot shows your current location.



Target GPS Position




- 1. Aim at the target with the crosshair to ensure the laser is hitting the object you want to locate.
- 2. Ensure the crosshair color is green which indicates that all of the instruments (GPS, Compass and Laser) are providing information
- 3. Tap the blue capture button at the bottom of the screen to take a picture and capture the location.

Note: you can zoom in using the slider on the right to help with aiming


Note: tapping on different areas of the camera will change the brightness/focus, like a standard Android camera.


Point to Point




1. Aim at the first target and capture when the crosshair turns green.

2. Aim at the second target and capture when the crosshair turns green.









- 3. The distance and bearing from Point A to Point B are calculated.
- 4. Click **RETAKE** if you're not satisfied with your results.


Point to Point



2. Use the orange guide arrows to locate the position directly below the wire.

1. Aim at the wire, wait for the crosshair to turn green and tap the capture button.






4. The results screen shows the height of the wire

and a photo with the crosshair.

3. When the arrows disappear and both the crosshair and the height measurement area turn green, tap the capture button.






Photo Measure



- 1. Aim at the pole with the crosshair.
- 2. Ensure the guideline that runs down the whole screen matches the angle of the pole.
- 3. When the crosshair is green tap the blue capture button at the bottom of the screen.

IKE Office

IKE Office is a cloud-based file management system with which you can

- create customizable forms
- upload and download field data
- measure heights of utility poles and their attachments

logging in

When signing into IKE Office for the first time use the admin login and password provided by ikeGPS. Enter these details, then click LOGIN.




IKE Office tools

On the left side of the IKE Office page are the various IKE Ofice tool tabs:

- Summary
- Jobs
- Forms
- Accounts
- Settings


When a tab is accessed, it will be highlighted in orange.

The following section will examine each tab in detail.



summary screen

The Summary screen shows the most recently uploaded collections and jobs. From here you can navigate to an individual job or collection. To access the summary, click Summary.




Now you see the following highlights of the uploaded jobs:

- Number of features (A)
- Pole ID (B)
- Date and time of collection (C)
- Thumbnail sets of collection captures (D)
- More information (E)


Clicking on a right arrow for more information shows you that pole's complete information.

jobs screen

The Jobs screen shows all the data uploaded from the IKE 4 device to the specific account. Jobs are displayed chronologically, based on the date they were collected. To access the jobs, click Jobs.




By selecting a Job name, the job's summary appears.



Now you see the following highlights of the uploaded jobs:

- Number of features (A)
- Pole ID (B)
- Date and time of collection (C)
- Thumbnail sets of collection captures (D)
- More information (E)

Clicking on a right arrow for more information shows you that pole's complete information.




Now you see all the data collected for this feature, such as

- Pole ID
- Location data
- True Size capture
- Sub-forms

This data is shaped by form creation and field data collection. Therefore, it is very important to be mindful of requirements when creating forms, via the IKE Office Forms tab.

forms screen

The Forms screen shows all the available forms. From this screen you can add customizable forms to your account. To access the forms, click Forms.



By selecting a form's edit button, the Form menu appears, and you can

Test a new form against a pole, to ensure you have all the necessary information for pole-loading analysis.

IKE Office quick guide


logging in

When signing into IKE Office for the first time use the admin login and password provided by ikeGPS. Enter these details, then click LOGIN.




managing accounts


1. To add a new user, click on Accounts then on •.




2. Enter the user details, then click create.



3. When the confirmation message appears, copy the login details (username and password) and pass them on to the user. Click OK to close the window.




To delete a user or reset a password, click the More icon (•) to the right of the account and select the option required.




summary screen

The summary screen shows the most recently uploaded collections and jobs. From here you can navigate to an individual job or collection.



customising the date format and measurement units


You can change the date format and measurement units. To do this, click Settings then click ▼ to select the preferred date format and/or measurement units.



creating a form

Note: It is important to set up the Internet connection to access your forms, especially the first time using the network.


1. To create a form, click on Forms then on •.




2. Select the type of form you want to create.

If you have a client.json file from ikeGPS, you can select Import SPIDACalc Client file to create a form specifically to be used with SPIDACalc.


To create a form from scratch, select New Blank Form.



3. When the form is created, click SAVE to make the form available for download onto the IKE device.



The created forms are displayed as shown below.




jobs and collections


To display all the jobs collected for your organisation, click Jobs.




Selecting a job shows all of the collections for that job.




Selecting an individual collection (>) will show all of the data collected on the form.



Mousing over an image shows a menu that allows you to view or go to Photo Measure




Selecting a view shows a summary of the capture, including the photo, location and measurement details.




Click outside the image to close the image.

measuring from a photo


1. Set the base of the pole by clicking on the photo near the bottom of the pole.




2. Select the first orange link on the right.



3. Click on the image to calculate the height for that field. Continue doing this for the other height fields in the form.






- For accurate placement, use the zoom window on the right for a closer view.
- To edit the name of the marker on photo, double click on it.
- To save your measurements, click [save icon].
- To go back to the collection screen, click [X icon]
- To delete all measurements on the photo, click [trashcan icon].

exporting

An individual collection can be exported to KML, JSON, Print (PDF) or to SPIDACalc format.



Multiple collections can also be exported, by checkmarking them.

